

# **Operation Manual**

# Goodrive350A Series High-performance Multifunction VFD



#### **Preface**

Thank you for choosing Goodrive350A series variable-frequency drive (VFD).

If not otherwise specified in this manual, the VFD always indicates Goodrive350A series VFD, which is a high-performance multifunctional VFD that can drive both synchronous motors (SMs) and asynchronous motors (AMs) and supports torque control, speed control, and position control. The VFD is armed with advanced vector control technology and the latest digital processor dedicated for motor control, thus enhancing product reliability and adaptability to the environment. The VFD adopts customized and industrialized design to realize excellent control performance through optimized functions and flexible applications.

In order to meet diversified customer demands, the VFD provides abundant expansion cards including programmable expansion card, PG card, communication card and I/O expansion card to achieve various functions as needed. Each VFD can be installed with three expansion cards at most.

The programmable expansion card adopts the mainstream development environment for customers to carry out secondary development easily, fulfilling varied customized needs and reducing customer cost.

The PG card supports a variety of encoders like incremental encoders and resolver-type encoders. In addition, it also supports pulse reference and frequency-division output. The PG card adopts digital filter technology to improve EMC performance and to realize stable transmission of the encoder signal over a long distance. It is equipped with encoder offline detection function to contain the impact of system faults.

The VFD supports multiple kinds of popular communication modes to realize complicated system solutions. It can be connected to the internet with optional wireless communication card, by which you can monitor the VFD state anywhere any time through mobile App.

The VFD uses high power density design. Some power ranges carry built-in DC reactor and braking unit to save installation space. Through overall EMC design, it can satisfy the low noise and low electromagnetic interference requirements to cope with challenging grid, temperature, humidity and dust conditions, thus greatly improving product reliability.

This operation manual presents installation wiring, parameter setup, fault diagnosis and trouble shooting, and precautions related to daily maintenance. Read through this manual carefully before installation to ensure the VFD is installed and operated in a proper manner to give full play to its excellent performance and powerful functions.

If the product is ultimately used for military affairs or manufacture of weapon, it will be listed on the export control formulated by Foreign Trade Law of the People's Republic of China. Rigorous review and necessary export formalities are needed when exported.

We reserve the right to update the manual information without prior notice and have the final interpretation for the manual content.

# **Contents**

Pre	Prace	I
Со	ntents	ii
1 S	afety precautions	1
	1.1 What this chapter contains	1
	1.2 Safety definition	1
	1.3 Warning symbols	1
	1.4 Safety guidelines	2
2 Q	uick startup	5
	2.1 What this chapter contains	5
	2.2 Unpacking inspection	5
	2.3 Checking before applying	5
	2.4 Environment	5
	2.5 Installation confirmation	6
	2.6 Basic commissioning	6
	2.7 Safety standard related data	7
3 P	roduct overview	8
	3.1 What this chapter contains	8
	3.2 Basic principle	8
	3.3 Product specifications	9
	3.4 Product nameplate	12
	3.5 Model designation code	12
	3.6 Product ratings	13
	3.7 Structure diagram	14
4 Ir	nstallation guidelines	15
	4.1 What this chapter contains	15
	4.2 Mechanical installation	15
	4.3 Main circuit standard wiring	21
	4.4 Control circuit standard wiring	25
	4.5 Wiring protection	28
5 B	asic operation guidelines	30
	5.1 What this chapter contains	30
	5.2 Keypad introduction	30
	5.3 Keypad display	34
	5.4 Operating the VFD through the keypad	
	5.5 Basic operations	47
6 F	unction parameter list	138
	6.1 What this chapter contains	138
	6.2 Function parameter list	138

7 Troubleshooting	288
7.1 What this chapter contains	
7.2 Indications of alarms and faults	
7.3 Fault reset	288
7.4 Fault history	288
7.5 VFD faults and solutions	288
7.6 Analysis on common faults	298
7.7 Countermeasures on common interference	304
8 Maintenance	309
8.1 What this chapter contains	309
8.2 Periodical inspection	309
8.3 Cooling fan	311
8.4 Capacitor	312
8.5 Power cable	314
9 Communication	315
9.1 What this chapter contains	315
9.2 Modbus protocol introduction	315
9.3 Application	315
9.4 RTU command code and communication data	321
9.5 Common communication faults	338
Appendix A Expansion cards	339
A.1 Model definition	339
A.2 Dimensions and installation	348
A.3 Wiring	351
A.4 IO expansion cards	351
A.5 Programmable expansion card (EC-PC502-00)	356
A.6 Communication cards	359
A.7 PG cards	369
A.8 GPRS card (EC-IC501-2)	388
Appendix B Technical data	389
B.1 What this chapter contains	389
B.2 Derated application	389
B.3 Grid specifications	390
B.4 Motor connection data	390
B.5 Application standards	390
B.6 EMC regulations	391
Appendix C Dimension drawings	
C.1 What this chapter contains	393
C.2 Keypad structure	393
C.3 VFD structure	394

C.4 VFD structure	394
Appendix D Optional peripheral accessories	399
D.1 What this chapter contains	399
D.2 Wiring of peripheral accessories	399
D.3 Power supply	400
D.4 Cables	401
D.5 Breaker and electromagnetic contactor	405
D.6 Reactors	406
D.7 Filters	408
D.8 Braking system	411
Appendix E STO function description	415
E.1 STO function logic	415
E.2 STO channel delay description	415
E.3 STO function installation checklist	416
Appendix F Energy efficiency data	417
Appendix G Further information	419
G.1 Product and service queries	419
G.2 Feedback on INVT VFD manuals	419
G.3 Documents on the Internet	419

# 1 Safety precautions

## 1.1 What this chapter contains

Read this manual carefully and follow all safety precautions before moving, installing, operating and servicing the VFD. If these safety precautions are ignored, physical injury or death may occur, or damage may occur to the equipment.

If any physical injury or death or damage to the equipment occur due to neglect of the safety precautions in the manual, our company will not be responsible for any damages and we are not legally bound in any manner.

# 1.2 Safety definition

Danger: Severe personal injury or even death can result if related requirements are not followed.

Warning: Personal injury or equipment damage can result if related requirements are not followed.

**Note**: Actions taken to ensure proper running.

**Trained and qualified professionals**: People working on the VFD must have received professional electrical and safety training and obtained the certificates, and must be familiar with all steps and requirements of VFD installing, commissioning, running and maintaining and capable to prevent any emergencies.


# 1.3 Warning symbols


Warnings caution you about conditions which can result in serious injury or death and/or damage to the equipment, and advice on how to avoid the danger. Following warning symbols are used in this manual.

Symbols	Name	Instruction	Abbreviation
Danger	Danger	Serious physical injury or even death may occur if related requirements are not followed	A
Marning	Warning	Physical injury or damage to the equipment may occur if related requirements are not followed	$\triangle$
Forbid	Electrostatic discharge	The PCBA may be damaged if related requirements are not followed	
Hot	Hot sides	The VFD base may become hot. Do not touch.	
5 min Electric shock		As high voltage still presents in the bus capacitor after power off, wait for at least five minutes (or 15 min / 25 min, depending on the warning	<u>^</u> € 5 min

Symbols	Name	Instruction	Abbreviation
		symbols on the machine) after power off to prevent electric shock	
	Read manual	Read the operation manual before operating on the equipment	
Note	Note	Actions taken to ensure proper operation	Note


# 1.4 Safety guidelines







VFD model	Minimum waiting time			
1R5G/2R2P-110G/132P	5 min			
132G/160P-315G/355P	15 min			
355G/400P and higher	25 min			





♦ Do not refit the VFD unless authorized; otherwise, fire, electric shock or other injuries may occur.



♦ The base of the radiator may become hot during running. Do not touch to avoid hurt.



♦ The electrical parts and components inside the VFD are electrostatic. Take measures to prevent electrostatic discharge during related operation.

# 1.4.1 Delivery and installation

♦ Install the VFD on fire-retardant material and keep the VFD away from combustible materials.



- ♦ Connect the optional braking parts (braking resistors, braking units or feedback) units) according to the wiring diagram.
- ♦ Do not operate on a damaged or incomplete VFD.
- ♦ Do not touch the VFD with wet items or body parts; otherwise, electric shock may occur.

#### Note:

Select appropriate tools for delivery and installation to ensure a safe and proper running of the VFD and avoid physical injury or death. To ensure physical safety, the installation staff should take mechanical protective measures like wearing safety shoes and working uniforms

- Protect the VFD against physical shock or vibration during delivery and installation.
- ♦ Do not carry the VFD by its front cover only as the cover may fall off.
- ♦ The installation site must be away from children and other public places.
- When the installation site altitude exceeds 1000m, derate by 1% for every increase of 100m; when the installation site altitude exceeds 3000m, consult local INVT dealer or office.
- ♦ Use the VFD in proper environment. (For details, see "Installation environment".)
- ♦ Prevent the screws, cables and other conductive parts from falling into the VFD.
- As leakage current of the VFD during running may exceed 3.5mA, ground properly and ensure the grounding resistance is less than 10Ω. The conductivity of PE grounding conductor is the same as that of the phase conductor (with the same cross sectional area).
- R, S and T are the power input terminals, and U, V and W are output motor terminals. Connect the input power cables and motor cables properly; otherwise, damage to the VFD may occur.

#### 1.4.2 Commissioning and running

- Disconnect all power sources applied to the VFD before terminal wiring, and wait for at least the time designated on the VFD after disconnecting the power sources.
- High voltage presents inside the VFD during running. Do not carry out any operation on the VFD during running except for keypad setup. The product control terminals form extra-low voltage circuits. Therefore, you need to prevent the control terminals from connecting to accessible terminals of other devices.
- The VFD may start up by itself when <u>P01.21</u>=1. Do not get close to the VFD and motor.
- ♦ The VFD cannot be used as "Emergency-stop device".




- The VFD cannot act as an emergency brake for the motor; it is a must to install mechanical brake device.
- During driving a permanent magnet SM, besides above-mentioned items, the following work must be done before installation and maintenance:
  - Disconnect all the input power sources including main power and control power.
  - b) Ensure the permanent-magnet SM has been stopped, and the voltage on output end of the VFD is lower than 36V.
  - c) After the permanent-magnet SM stops, wait for at least the time designated on the VFD, and ensure the voltage between + and - is lower than 36V.
  - d) During operation, ensure the permanent-magnet SM cannot run again by the action of external load; it is recommended to install effective external brake device or disconnect the direct electrical connection between permanent-magnet SM and the VFD.

#### Note:

- ♦ Do not switch on or switch off input power sources of the VFD frequently.
- If the VFD has been stored for a long time without being used, set the capacitance (see "Maintenance" and carry out inspection and pilot run on the VFD before use.
- ♦ Close the front cover before running; otherwise, electric shock may occur.

#### 1.4.3 Maintenance and component replacement





- Disconnect all the power sources applied to the VFD before terminal wiring, and wait for at least the time designated on the VFD after disconnecting the power sources.
- Take measures to prevent screws, cables and other conductive matters from falling into the VFD during maintenance and component replacement.

#### Note:

- ♦ Use proper torque to tighten the screws.
- Keep the VFD and its parts and components away from combustible materials during maintenance and component replacement.
- Do not carry out insulation voltage-endurance test on the VFD, or measure the control circuits of the VFD with megameter.
- Take proper anti-static measures on the VFD and its internal parts during maintenance and component replacement.

#### 1.4.4 What to do after scrapping



♦ The heavy metals inside the VFD should be treated as industrial effluent.



When the life cycle ends, the product should enter the recycling system. Dispose of it separately at an appropriate collection point but not place it in the normal waste stream.

# 2 Quick startup

# 2.1 What this chapter contains

This chapter introduces the basic installation and commissioning rules that you need to follow to realize guick installation and commissioning.

#### 2.2 Unpacking inspection

Check the following after receiving the product.

- Whether the packing box is damaged or dampened.
- Whether the model identifier on the exterior surface of the packing box is consistent with the purchased model.
- Whether the interior surface of the packing box is abnormal, for example, in wet condition, or whether the enclosure of the VFD is damaged or cracked.
- Whether the VFD nameplate is consistent with the model identifier on the exterior surface of the packing box.
- Whether the accessories (including the manual and keypad) inside the packing box are complete.

If any problems are found, contact the local dealer or INVT office.

# 2.3 Checking before applying

Check the following before applying the VFD.

- Check the load type to verify that there is no overload of the VFD during work and check whether the power class of the VFD needs to be increased.
- Check whether the actual running current of the motor is less than the rated current of the VFD.
- Check whether the control accuracy required by the load is the same of the VFD.
- Check whether the grid voltage is consistent with the rated voltage of the VFD.
- Check whether expansion card are needed for selected functions.

#### 2.4 Environment

Check the following before the actual installation and use:

Note: For a cabinet-built VFD, the ambient temperature is the air temperature inside the cabinet.

- Check whether the ambient temperature of the VFD exceeds 40°C. If it exceeds 40°C, derate 1% for every increase of 1°C. It is not recommended to use the VFD if the ambient temperature exceeds 50°C.
- Check whether the ambient temperature of the VFD in actual use is lower than -10°C. If yes, use heating facilities.
- When the altitude exceeds 1000m, derate by 1% for every increase of 100m. When the altitude exceeds 2000m, configure an isolation transformer at the VFD input end. It is not

recommended that the VFD be used at the altitude higher than 5000m.

- Check whether the humidity of the actual usage site exceeds 90% and condensation occurs. If yes, take additional protective measures.
- Check whether the actual use site may be exposed to direct sunlight or may have the chance of ingress of foreign objects. If yes, take additional protective measures.
- Check whether there is dust, explosive gas, or flammable gas in the actual use site. If yes, take additional protective measures.

#### 2.5 Installation confirmation

Check the following after the VFD installation:

- Check whether the load ranges of the input power cable and motor cable meet the actual load requirement.
- Check whether correct accessories are selected for the VFD, the accessories are correctly
  and properly installed, and the installation cables meet the requirements of all components
  (including the reactor, input filter, output reactor, output filter, DC reactor, braking unit and
  braking resistor).
- Check whether the VFD is installed on non-flammable materials and the heat-radiating accessories (such as the reactor) are away from flammable materials.
- Check whether all control cables and power cables are run separately and the routing complies with EMC requirement.
- Check whether all grounding systems are properly grounded according to the requirements of the VFD.
- Check whether all the installation clearances of the VFD meet the requirements in the operation manual.
- Check whether the installation conforms to the instructions in the operation manual. It is recommended that the VFD be installed uprightly.
- Check whether the external connection terminals of the VFD are tightly fastened and the torque is appropriate.
- Check whether there are screws, cables, or other conductive items left in the VFD. If yes, get them out.

# 2.6 Basic commissioning

Complete the basic commissioning as follows before the actual use of the VFD:

- According to the actual motor parameters, select the motor type, set motor parameters, and select the VFD control mode.
- Autotune. If possible, de-couple the VFD from the motor load to start dynamic autotuning. If the VFD cannot be de-coupled from the load, perform static autotuning.
- Adjust the ACC/DEC time according to the actual work condition of the load.
- Perform device commissioning by means of jogging and check whether the motor rotational

direction is correct. If not, change the rotation direction by swapping any two phase wires of the motor.

• Set all control parameters and then operate.

# 2.7 Safety standard related data

IEC/EN 61508 (Class A system)								ISO 1	3849**		
SIL	PFH	HFT	SFF	λdu	λdd	PTI*	PL	CCF	MTTFd	DC	Category
2	8.73x10 <sup>-10</sup>	1	71.23%	1.79x10 <sup>-9</sup>	0	1 year	d	57	343.76 years	60%	3

<sup>\*</sup> PTI: Proof test interval

<sup>\*\*</sup> Depends on the the classification defined on the EN ISO 13849-1.

# 3 Product overview

# 3.1 What this chapter contains

This chapter mainly introduces the operation principles, product features, layouts, nameplates and model designation rules.

# 3.2 Basic principle

The VFD is used to control asynchronous AC induction motors and permanent-magnet synchronous motors. The figure below shows the main circuit diagram of the VFD. The rectifier converts 3PH AC voltage into DC voltage, and the capacitor bank of intermediate circuit stabilizes the DC voltage. The VFD converts DC voltage into the AC voltage used by AC motor. When the circuit voltage exceeds the maximum limit value, external braking resistor will be connected to intermediate DC circuit to consume the feedback energy.




Figure 3.1 Main circuit diagram for 015G/018P and lower models




Figure 3.2 Main circuit diagram for 018G/022P-037G/045P




Figure 3.3 Main circuit diagram for 045G/055P-110G/132P




Figure 3.4 Main circuit diagram for 132G/160P and higher models

#### Note:

- 132G/160P and higher models can be connected to external DC reactors. Before connection, take off the copper bar between P1 and (+). 075G/090P and higher models can be connected to external braking units. DC reactors and braking units are optional parts.
- 018G/022P-110G/132P models are equipped with built-in DC reactors.
- 037G/045P and lower models carry built-in braking units. Braking units are optional parts for 045G/055P-055G/075P models and they can be built in or externally connected to the models.

# 3.3 Product specifications

Function description		Specification
	Input voltage (V)	AC 3PH 380V (-15%)-440V (+10%)
Power input	Input current (A) See "Product ratings".	
	Input frequency (Hz)	50Hz or 60Hz, allowable range: 47–63Hz
Power Output voltage (V)		0-Input voltage

Functi	on description	Specification				
output	Output current (A)	See "Product ratings".				
	Output power (kW)	See "Product ratings".				
	Output frequency (Hz)	0–400Hz				
	Control mode	Space voltage vector control, sensorless vector control (SVC), and vector control with sensor feedback (FVC)				
	Motor type	Asynchronous motor (AM) and permanent magnetic synchronous motor (SM)				
	Speed regulation ratio	For AM1: 1:200 (SVC); for SM1, 1:20 (SVC); 1:1000 (FVC)				
Technical	Speed control precision	± 0.2% (SVC); ± 0.02% (FVC)				
control	Speed fluctuation	± 0.3% (SVC)				
performance	Torque response	< 20ms (SVC); < 10ms (FVC)				
	Torque control precision	10% (SVC); 5% (FVC)				
		For AMs: 0.25Hz/150% (SVC)				
	Starting torque	For SMs: 2.5Hz/150% (SVC)				
		0Hz/200% (FVC)				
	Overload capacity	150% for 1 minute (for the G type); 120% for 1 minute (for the P type)				
		Settings can be implemented through digital, analog,				
	Frequency setting method	pulse frequency, multi-step speed running, simple PLC,				
		PID communication, communication and so on.				
		Settings can be combined and the setting channels can be switched.				
	Automatic voltage	The output voltage can be kept constant although the				
Running	regulation	grid voltage changes.				
control	-	More than 30 protection functions, such as protection				
performance	Fault protection	against overcurrent, overvoltage, undervoltage,				
		overtemperature, phase loss, and overload				
		Used to implement impact-free smooth startup for				
	Speed tracking	rotating motors				
	restart	Note: The function is available only for 004G/5R5P				
		and higher models.				
Peripheral	Terminal analog input resolution	No more than 20mV				
interface	Terminal digital input	No more than 2ms				

Functi	on description	Specification			
	resolution				
	Analog input	2 inputs; Al1: 0-10V/0-20mA; Al2: -10-10V			
	Analog output	1 input; AO1: 0-10V/0-20mA			
	Digital input	Four regular inputs; max. frequency: 1kHz; internal impedance: 3.3kΩ Two high-speed inputs; max. frequency: 50kHz;			
		supporting quadrature encoder input; with speed measurement function			
	Digital output	One high-speed pulse output; max. frequency: 50kHz One Y terminal open collector output			
	Relay output	Two programmable relay outputs  RO1A: NO; RO1B: NC; RO1C: common  RO2A: NO; RO2B: NC; RO2C: common  Contact capacity: 3A/AC250V, 1A/DC30V			
	Extended interfaces	Three extended interfaces: SLOT1, SLOT2, and SLOT3 (control board of above 7.5kW) Supporting PG cards, programmable expansion cards, communication cards, I/O cards and so on			
	Mounting method	Wall mounting, floor mounting, and flange mounting			
	Temperature of	-10 – +50°C; derating is required if the ambient			
	running environment	temperature exceeds 40°C			
	Ingress protection rating	IP20			
	Pollution degree	Degree 2			
	Cooling method	Forced air cooling			
Other	Braking unit	The VFD models of 037G/045P and lower contain built-in braking units. The braking units are optional parts for the 045G/055P–055/075P VFD models, and the braking units can be built in or externally connected.			
	EMC filter	The transmission of the VFD meets the IEC/EN 61800-3 C3 requirements.  When optional filters are connected externally, the transmission of the VFD can meet the IEC/EN 61800-3 C2 requirements.  Note: Comply with the EMC requirements and the technical requirements for the motors and motor cables in the appendix in the manual.			

#### 3.4 Product nameplate



Figure 3.5 Product nameplate

#### Note:

- This is a nameplate example of a standard VFD product. The CE/TUV/IP20 marking on the top right will be marked according to actual certification conditions.
- Scan the QR code at the bottom of the right to download the product APP and operation manual.

# 3.5 Model designation code

A model designation code contains product information. You can find the model designation code on the VFD nameplate.



Figure 3.6 Model description

Field	No.	Description	Content
Abbreviation of product series	1)	Abbreviation of product series	GD350A: Goodrive350A series high-performance multifunction VFD
Rated power	2	Power range + load type	5R5: 5.5kW G: Constant torque load P: Variable torque load
Voltage class	3	Voltage class	4: AC 3PH 380V(-15%)-440V(+10%)

#### Note:

Braking units have been built in the 037G/045P and lower models as standard configuration. Braking units are not standard configuration for the 045G/055P–055G/075P models. (If you want to use braking units for these models, add suffix "-B" at the end of the model codes in your purchase orders, for example, GD350A-045G/055P-4-B.)

# 3.6 Product ratings

	Co	nstant torqu	ıe	Variable torque			
VED	Output	Input	Output	Output	Input	Output	
VFD model	power	current	current	power	current	current	
	(kW)	(A)	(A)	(kW)	(A)	(A)	
GD350A-1R5G/2R2P-4	1.5	5.0	3.7	2.2	5.8	5	
GD350A-2R2G/003P-4	2.2	5.8	5	3	11	7	
GD350A-004G/5R5P-4	4	13.5	9.5	5.5	19.5	12.5	
GD350A-5R5G/7R5P-4	5.5	19.5	14	7.5	23	17	
GD350A-7R5G/011P-4	7.5	25	18.5	11	30	23	
GD350A-011G/015P-4	11	32	25	15	40	32	
GD350A-015G/018P-4	15	40	32	18.5	45	38	
GD350A-018G/022P-4	18.5	45	38	22	51	45	
GD350A-022G/030P-4	22	51	45	30	64	60	
GD350A-030G/037P-4	30	64	60	37	80	75	
GD350A-037G/045P-4	37	80	75	45	98	92	
GD350A-045G/055P-4	45	98	92	55	128	115	
GD350A-055G/075P-4	55	128	115	75	139	150	
GD350A-075G-/090P-4	75	139	150	90	168	170	
GD350A-090G/110P-4	90	168	180	110	201	215	
GD350A-110G/132P-4	110	201	215	132	265	260	
GD350A-132G/160P-4	132	265	260	160	310	305	
GD350A-160G/185P-4	160	310	305	185	345	340	
GD350A-185G/200P-4	185	345	340	200	385	380	
GD350A-200G/220P-4	200	385	380	220	430	425	
GD350A-220G/250P-4	220	430	425	250	460	480	
GD350A-250G/280P-4	250	460	480	280	500	530	
GD350A-280G/315P-4	280	500	530	315	580	600	
GD350A-315G/355P-4	315	580	600	355	625	650	
GD350A-355G/400P-4	355	625	650	400	715	720	
GD350A-400G/450P-4	400	715	720	450	840	820	
GD350A-450G/500P-4	450	840	820	500	890	860	
GD350A-500G-4	500	890	860				

- The VFD input current is measured in cases where the input voltage is 380V without an additional reactor.
- The rated output current is the output current corresponding to 380V output voltage.

• Within the allowable input voltage range, the output current and power cannot exceed the rated output current and power.

# 3.7 Structure diagram

The VFD structure is shown in the following figure (using the 030G/037P VFD model as an example):





Figure 3.7 Structure diagram

No.	Item Description	
1	Upper cover	Used to protect internal components.
2	Keypad	For details, see "Operating the VFD through the keypad".
3	Lower cover	Used to protect internal components.
4	Expansion card	Optional. For details, see "Expansion cards".
5	Control board baffle	Used to protect the control board and install expansion cards.
6	Cooling fan	For details, see "Maintenance".
7	Keypad interface	Used to connect the keypad.
8	Nameplate	See "Product nameplate".
9	Control terminals	See "Installation guidelines".
		Optional. Using the ventilation hole cover can enhance
10	Ventilation hole cover	the protection rating but also increase the internal
		temperature, which requires derating.
11	Main circuit terminals For details, see "Installation guidelines".	
12	POWER indicator	Indicator of the power supply.
13	GD350A product series label	See "Model designation code".

# 4 Installation guidelines

# 4.1 What this chapter contains

This chapter introduces the mechanical and electrical installations of the VFD.





regulations. INVT does not assume any liability whatsoever for any installation which breaches local laws and regulations. If recommendations given by INVT are not followed, the VFD may experience problems that the warranty does not cover.

# 4.2 Mechanical installation

#### 4.2.1 Installation environment

Installation environment is essential for the VFD to operate at its best in the long run. The installation environment of the VFD should meet the following requirements.

Environment	Condition
Installation site	Indoors
Ambient temperature	<ul> <li>→ -10—+50°C;</li> <li>→ When the ambient temperature exceeds 40°C, derate 1% for every additional 1°C;</li> <li>→ It is not recommended to use the VFD when the ambient temperature is above 50°C;</li> <li>→ In order to improve reliability, do not use the VFD in cases where the temperature changes rapidly;</li> <li>→ When the VFD is used in a closed space e.g. control cabinet, use cooling fan or air conditioner to prevent internal temperature from exceeding the temperature required;</li> <li>→ When the temperature is too low, if restart an VFD which has been idled for a long time, it is required to install external heating device before use to eliminate the freeze inside the VFD, failing to do so may cause damage to the VFD.</li> </ul>

Environment	Condition		
	→ The relative humidity (RH) of the air is less than 90%;		
Humidity	♦ Condensation is not allowed;		
Humaity	♦ The max RH cannot exceed 60% in the environment where there are		
	corrosive gases.		
Storage	-30—+60°C		
temperature	-30100 C		
	The installation site should meet the following requirements.		
	Away from electromagnetic radiation sources;		
	Away from oil mist, corrosive gases and combustible gases;		
Running	♦ Ensure foreign object like metal powder, dust, oil and water will not fall		
environment	into the VFD (do not install the VFD onto combustible object like wood);		
enviioninent	<ul> <li>Away from radioactive substance and combustible objects;</li> </ul>		
	♦ Away from harmful gases and liquids;		
	♦ Low salt content;		
	♦ No direct sunlight		
	♦ Below 1000m;		
	♦ When the altitude exceeds 1000m, derate 1% for every additional 100m;		
Altitude	♦ When the altitude exceeds 2000m, configure isolation transformer on the		
	input end of the VFD. It is recommended to keep the altitude below		
	5000m.		
Vibration	Max. vibration acceleration: 5.8m/s <sup>2</sup> (0.6g)		
Installation direction	Install the VFD vertically to ensure good heat dissipation effect		

#### Note:

- The VFD must be installed in a clean and well-ventilated environment based on the IP level.
- The cooling air must be clean enough and free from corrosive gases and conductive dust.

#### 4.2.2 Installation direction

The VFD can be installed on the wall or in a cabinet.

The VFD must be installed vertically. Check the installation position according to following requirements. See Appendix C Dimension drawings.




Figure 4.1 Installation direction of the VFD

#### 4.2.3 Installation mode

There are three kinds of installation modes based on different VFD dimensions.

- Wall-mounting: suitable for 315G/355P and lower models
- Flange-mounting: suitable for 200G/220P and lower models
- Floor-mounting: suitable for 220G/250P-500G models





Figure 4.2 Installation mode

- (1) Mark the position of the installation hole. See appendix for the position of installation hole;
- (2) Mount the screws or bolts onto the designated position;
- (3) Put the VFD on the wall;
- (4) Tighten the fixing screws on the wall.

- The flange-mounting plate is a must for 1R5G/2R2P-075G/090P models that adopt flange-mounting mode; while 090G/110P-200G/220P models need no flange-mounting plate.
- The installation base is optional for 220G/250P-315G/355P models. The base can hold an input AC reactor (or DC reactor) and an output AC reactor.

#### 4.2.4 Single-unit installation







Figure 4.3 Single-unit installation

Note: The min. dimension of B and C is 100mm.

#### 4.2.5 Multiple-unit installation






Figure 4.4 Parallel installation

- When you install VFDs in different sizes, align the top of each VFD before installation for the convenience of future maintenance.
- The min. dimension of B, D and C is 100mm.

#### 4.2.6 Vertical installation




Figure 4.5 Vertical installation

**Note:** During vertical installation, you must install windshield, otherwise, the VFD will experience mutual interference, and the heat dissipation effect will be degraded.

#### 4.2.7 Tilted installation




Figure 4.6 Tilted installation

**Note:** During tilted installation, it is a must to ensure the air inlet duct and air outlet duct are separated from each other to avoid mutual interference.

# 4.3 Main circuit standard wiring

### 4.3.1 Main circuit wiring diagram




Figure 4.7 Main circuit wiring diagram

- The fuse, DC reactor, braking unit, braking resistor, input reactor, input filter, output reactor and output filter are optional parts. See Appendix D Optional peripheral accessories.
- P1 and (+) have been short connected by default for 132G/160P and higher models. If you need to connect to external DC reactor, take off the short-contact tag of P1 and (+).
- When connecting the braking resistor, take off the yellow warning sign marked with PB, (+) and (-)
  on the terminal block before connecting the braking resistor wire, otherwise, poor contact may
  occur.
- Braking units are optional parts for 045G/055P-055G/075P models, and they can be built in or externally connected to the models.

#### 4.3.2 Main circuit terminal diagram




Figure 4.8 Main circuit terminal diagram for 022G/030P and lower models




Figure 4.9 Main circuit terminal diagram for 030G/037P-037G/045P models




Figure 4.10 Main circuit terminal diagram for 045G/055P–110G/0132P (optional built-in braking unit means starting PB)




Figure 4.11 Main circuit terminal diagram for 132G/160P-200G/220P models




Figure 4.12 Main circuit terminal diagram for 220G/250P-315G/355P models




Figure 4.13 Main circuit terminal diagram for 355G/400P-500G models

	Terminal				
Sign	037G/045P and lower	045G/055P-110G/132P	132G/160P and higher	Function description	
R, S, T	Main circuit power input			3PH AC input terminal, connected to the grid.	
U, V, W		VFD output	3PH AC output terminal, connected to the motor in most cases.		
P1	Not available	Not available	DC reactor terminal 1	P1 and (+) connect to external DC reactor	
(+)	Braking resistor terminal 1	Braking unit terminal 1 Braking resistor terminal 1		terminals. (+) and (-) connect to external braking unit terminals.	
(-)	/	Braking unit terminal 2		PB and (+) connect to	
РВ	Braking resistor terminal 2	Braking resistor terminal 2	Not available	external braking resistor terminals.	
PE	Grounding resistor less than $10\Omega$			Grounding terminal for safe protection; each machine must carry two PE terminals and proper grounding is required.	

- Do not use asymmetrical motor cables. If there is a symmetrical grounding conductor in the motor cable besides the conductive shielded layer, ground the grounding conductor on the VFD end and motor end.
- Braking resistor, braking unit and DC reactor are optional parts.
- Route the motor cables, input power cables and control cables separately.
- "Not available" means this terminal is not for external connection.
- GD series VFDs cannot share the DC bus with CH series VFDs.
- When sharing the DC bus, the VFDs must be the same in power and must be simultaneously powered on or off.
- In shared DC bus running mode, current balance on the VFD input side must be considered during wiring, and equalizing reactors are recommended to be configured.
- The PB is available for the 045G/055P-110G/132P models only when built-in braking units have been selected for the 045G/055P-055G/75P models.

#### 4.3.3 Wiring procedure of the main circuit terminals

- 1. Connect the ground wire of the input power cable to the PE terminal of the VFD, connect the 3PH input cable to the R, S and T terminals, and tighten up.
- Connect the ground wire of the motor cable to the PE terminal of the VFD, connect the motor 3PH cable to the U, V and W terminals, and tighten up.
- 3. Connect optional parts such as the braking resistor that carries cables to designated positions.
- 4. Fasten all the cables outside the VFD mechanically if allowed.




Figure 4.14 Screw installation diagram

# 4.4 Control circuit standard wiring

# 4.4.1 Basic control circuit wiring diagram




Figure 4.15 Control circuit wiring diagram

Terminal	Description		
name			
+10V	Locally provided +10.5V power supply		
Al1	■ Input range: Al1 voltage/current can choose 0–10V / 0–20mA; Al2: -10V – +10V:		
Al2	<ul> <li>Input impedance: 20kΩ during voltage input; 250Ω during current input;</li> <li>Whether the input is voltage or current is set through P05.50;</li> <li>Resolution ratio: When 10V corresponds to 50Hz, the min. resolution ra 5mV;</li> <li>Deviation: ±0.5% at 25°C, when input is above 5V/10mA.</li> </ul>		
GND	+10.5V reference zero potential		
	Output range: 0–10V or 0–20mA		
AO1	Whether the output is voltage or current is set through the switch SW2		
	<ul> <li>Deviation: ±0.5% at 25°C, when input is above 5V/10mA.</li> </ul>		
RO1A	PO1 relay outputs PO1A is NO PO1P is NC PO1C is common terminal		
RO1B	RO1 relay output; RO1A is NO, RO1B is NC, RO1C is common terminal Contact capacity: 3A/AC250V, 1A/DC30V		
RO1C	Contact capacity. SA/A0230V, TA/D030V		
RO2A	RO2 relay output; RO2A is NO, RO2B is NC, RO2C is common terminal		
RO2B	Contact capacity: 3A/AC250V, 1A/DC30V		
RO2C			
HDO	<ul> <li>Switch capacity: 50mA/30V</li> <li>Range of output frequency: 0–50kHz</li> <li>Duty ratio: 50%</li> </ul>		
CME	Common terminal of open collector output; short connected to COM by default		
Y1	Switch capacity: 50mA/30V		
- ''	Range of output frequency: 0–1kHz		
485+	RS485 communication port, RS485 differential signal port and standard RS485		
485-	communication port must use twisted shielded pair; the 1200hm terminal matching resistor of RS485 communication is connected by the switch SW3.		
PE	Grounding terminal		
PW	Used to provide input digital working power from the external to the internal.  Voltage range: 12–30V		
24V	User power provided by the VFD, maximum output current 200mA.		
COM	Common terminal of +24V		
S1	Digital input 1 Internal impedance: 3.3kΩ		
S2	Digital input 2  Accept 12–30V voltage input Bi-directional input terminal, supporting NPN/PNP connection		
S3	Digital input 3 modes		
S4	<ul> <li>Max. input frequency: 1kHz</li> <li>All are programmable digital input terminals, the functions of which be set through function codes</li> </ul>		
HDIA	<ul> <li>Besides S1–S4 functions, the terminals can also act as high frequency pulse input channels</li> </ul>		

Terminal name	Description				
	<ul><li>Max. input frequency: 50kHz;</li><li>Duty ratio: 30%–70%;</li></ul>				
HDIB	<ul> <li>Supporting</li> </ul>	24V-power quadrature encoder input; equipped with			
	speed-measurement function				
+24V—H1	STO input 1	Safe torque off (STO) redundant input, connected to the			
		<ul> <li>external NC contact. When the contact opens, STO acts and the VFD stops output;</li> <li>Safety input signal wires use shielded wires whose length is within 25m;</li> </ul>			
+24V—H2	STO input 2	● The H1 and H2 terminals are short connected to +24V by			
		default. Remove the short connectors from the terminals before			
		using STO function.			

#### 4.4.2 Input/output signal connection diagram

You can select the NPN/PNP mode and internal/external power through the U-type short connector. NPN internal mode is adopted by default.




Figure 4.16 Position of U-type short connector

**Note:** The USB port can be used to upgrade the software, and the keypad port can be used to connect an external keypad. The external keypad cannot be used when the keypad of the VFD is used.

If input signal comes from NPN transistors, set the U-type short connector between +24V and PW based on the power used according to the following figure.




Figure 4.17 NPN mode

If input signal comes from PNP transistor, set the U-type short connector based on the power used according to the following figure.




Figure 4.18 PNP mode

# 4.5 Wiring protection

#### 4.5.1 Protecting the VFD and input power cable in short circuit

The VFD and input power cable can be protected during short-circuit to avoid thermal overload.

Carry out protective measures according to the following requirements.




Figure 4.19 Fuse configuration

**Note:** Select the fuse according to operation manual. During short-circuit, the fuse will protect input power cables to avoid damage to the VFD; when internal short-circuit occurred to the VFD, it can protect neighboring equipment from being damaged.

#### 4.5.2 Protecting the motor and motor cable in short circuit

If the motor cable is selected according to the VFD rated current, the VFD can perform short-circuit protection for the motor and motor cable, without the use of other protective devices.



If the VFD is connected to multiple motors, an additional thermal overload switch or breaker must be used to protect the motor and motor cable. Such a device may use the fuse to cut off the short-circuit current.

#### 4.5.3 Protecting the motor from thermal overload

According to the requirements, the motor must be protected to prevent thermal overload. Once overload is detected, you must cut off the current. The VFD is equipped with motor thermal overload protection function, which will block output and cut off the current (if necessary) to protect the motor.

#### 4.5.4 Bypass connection

In critical occasions, power-variable frequency conversion circuit is necessary to ensure proper operation of the system when VFD fault occurs. In some special cases, for example, only soft startup is needed, it will convert to power-frequency operation directly after soft startup, corresponding bypass link is also needed.



Do not connect the power supply to the VFD output terminals U, V and W. The voltage applied to the motor cable may cause permanent damage to the VFD.

If frequent switchover is needed, you can use the switch/contactor which carries mechanical interlock to ensure motor terminals are not connected to input power cables and VFD output ends simultaneously.

# 5 Basic operation guidelines

# 5.1 What this chapter contains

This chapter describes how to operate the VFD by using the keypad.

# 5.2 Keypad introduction

The VFD has been equipped with the LCD keypad as a standard configuration part. You can use the keypad to control the start and stop, read status data, and set parameters of the VFD.



Figure 5.1 Keypad diagram

- The LCD keypad is equipped with a real-time clock, which can run properly after being installed with batteries even if the power line is disconnected. The clock battery (type: CR2032) is user purchased.
- The LCD keypad has the parameter copying function.
- If you need install the keypad on another position rather than on the VFD, use M3 screws or a
  keypad installation bracket for fixing, and use a keypad extension cable with a standard RJ45
  crystal head.

Item	Description		
Status indicator	1	RUN	VFD running status indicator. LED off: The VFD is stopped.

Item	Description			
				LED blinking: The VFD is autotuning parameters.
				LED on: The VFD is running.
				Fault indicator.
	2	F	RIP	LED on: in fault state
	2	<u> </u>	IXIF	LED off: in normal state
				LED blinking: in pre-alarm state
	3	QUIC	CK/JOG	Short-cut key indicator, which displays different state under different functions, see definition of the QUICK/JOG key for details.
	4			The function of function key varies with the
	5		Function key	menu; The function of function key is displayed in the
	6			footer.
Key area	7	QUICK	Short-cut key	Re-definable. It is defined as JOG function by default, namely jogging. The function of short-cut key can be set by the ones of P07.12, as shown in the following.  0: No function  1: Jogging (linkage indicator 3; logic: NO);  2: Reserved  3: FWD/REV switch-over (linkage indicator 3; logic: NC)  4: Clear UP/DOWN setting (linkage indicator 3 logic: NC)  5: Coast to stop (linkage indicator 3; logic: NC);  6: Switching running command reference mode in order (linkage indicator 3; logic: NC)  7: Reserved  Note: After restoring to default values, the default function of short-cut key 7 is 1.
	8	Enter	Confirmation	The function of the confirmation key varies
	U	-	key	with menus, such as confirming parameter

Item			De	escription
	9	RUN 🔷	Run key	setting, confirming parameter selection, and entering the next menu.  When the VFD is controlled by the keypad, this key is used to run the VFD or perform
	10	STOP RST	Stop/ Reset key	autotuning.  In running state, pressing this key can stop running or autotuning; this key is limited by P07.04. In fault alarm state, all the control modes can be reset by this key.
	11	( ) v	Direction key Up: Down: Left: Right:	Up: Its function varies with the interface (Example: shifting up the displayed/selected item and changing digits)  Down: Its function varies with the interface (Example: shifting down the displayed/selected item and changing digits)  Left: Its function varies with the interface (Example: switching the monitoring interface, shifting the cursor leftward, and returning to the previous menu)  Right: Its function varies with the interface (Example: switching the monitoring interface, shifting the cursor rightward, and entering the next menu)
Display area	12	LCD	Display screen	240*160 dot-matrix LCD, able to display three monitoring parameters or six sub-menu items simultaneously.
	13	RJ45 interface	RJ45 interface	The RJ45 interface is used to connect to the VFD.
Other	14 Battery Clock batter cover	Clock battery cover	To replace or mount the clock battery, remove this cover, and then close the cover after the battery is mounted.	
	15	USB terminal	Mini USB terminal	The mini USB terminal is used to connect to the USB flash drive through an adapter.

The LCD has different display areas, which show different contents under different interfaces. The following figure shows the main interface in stop state.




Figure 5.2 Main interface of LCD

Area	Name	Displayed contents
Header A	Real-time display area	Display the real-time; clock battery is not included; the time needs to be reset when powering on the VFD.
	VFD running state	Display the running state of the VFD:  1. Display motor rotating direction: "Fwd" – Run forward during operation; Rev – Run reversely during operation; "Disrev" – Reverse running is forbidden.  2. Display VFD running command channel: "Local" –
Header B	display area	Keypad; "Trml" – Terminal; "Remote" - Communication  3. Display current VFD state: "Ready" – The VFD is in stop state (no fault); "Run" – The VFD is in running state; "Jog" – The VFD is in jogging state; "Pre-alarm" – the VFD is under pre-alarm state during running; "Fault" – VFD fault occurred.
Header C	VFD model display area	VFD model display: "GD350A" - current VFD is GD350A series VFD
Display D	Parameter names and function codes on the VFD homepage	Display a maximum of three parameter names and function codes on the homepage. The parameters diplayed on the homepage can be managed.
Display E	Values of parameters on the VFD homepage	Display the values of parameters on the VFD homepage, which are updated in real time.
Footer F	Corresponding menus of function keys (4), (5) and (6)	Indicate the menus corresponding to function keys (4), (5) and (6). The corresponding menus of the keys vary with interfaces, and the content displayed in this area varies also.

# 5.3 Keypad display

The VFD keypad can display the stopped-state parameters, running-state parameters, function parameter editing status, and fault alarm status.

#### 5.3.1 Displaying stopped-state parameters

When the VFD is in stopped state, the keypad displays stopped state parameters, and this interface is the main interface during power-on by default. In stopped state, parameters in various states can be displayed. Press or to shift the displayed parameters upward or downward.




Figure 5.3 Stopped-state parameter display 1

Press or to switch between different display styles, including list display style and progress bar display style.




Figure 5.4 Stopped-state parameter display 2

The stopped-state parameter display list is user defined, and each state variable function code can be added to the stopped-state parameter display list as needed. A function code which has been added to the stopped-state parameter display list can also be deleted or shifted.

#### 5.3.2 Displaying running-state parameters

After receiving a valid running command, the VFD will enter running state, and the keypad displays running state parameter with RUN indicator on the keypad turning on. Under running state, multiple kinds of state parameters can be displayed. Press or to shift up or down.




Figure 5.5 Running state parameters

Press or to switch between different display styles, including list display style and progress bar display style.




Figure 5.6 Running parameter display state

In running state, multiple kinds of state parameters can be displayed. The running display parameter list is user defined, and each state variable function code can be added to the running display parameter list as needed. A function code which has been added to the running display parameter list can also be deleted or shifted.

#### 5.3.3 Displaying fault information

The VFD enters fault alarm display state once fault signal is detected, and the keypad displays fault code and fault information with TRIP indicator on the keypad turning on. Fault reset operation can be carried out via STOP/RST key, control terminal or communication command.

The fault code will be kept displaying until fault is removed.




Figure 5.7 Displaying a fault

# 5.4 Operating the VFD through the keypad

You can perform various operations on the VFD by using the keypad, including entering/exiting

menus, parameter selection, list modification and parameter addition.

## 5.4.1 Entering/exiting menus

The keypad displays three main menus at the home interface by default: **Parameter**, **About**, and **Menu**. The following figure shows how to enter the **Parameter** main menu and how to operate under this main menu.



Figure 5.8 Enter/exit menu diagram 1

The following figure shows how to enter the **Menu** main menu and operate under this main menu.




Figure 5.9 Enter/exit menu diagram 2

The keypad menu setup is shown in the following.

Level 1	Level 2	Level 3	Level 4
Parameter groups	Basic	P00: Basic Function	P00.xx
	parameters	P01: Start/stop control	P01.xx

Level 1	Level 2	Level 3	Level 4
		P03: Motor1 Vector Ctrol	P03.xx
		P04: V/F Control	P04.xx
		P07: HMI	P07.xx
		P08: Enhanced Function	P08.xx
		P09: PID Control	P09.xx
		P10: PLC&Mul-stepSpCtrl	P10.xx
		P11: Protection Param	P11.xx
		P13: SM Ctrl Param	P13.xx
		P14: Serial Comm Func	P14.xx
		P21: Position Ctrl	P21.xx
		P22: Spdl Positioning	P22.xx
		P23: Motor 2 Vector Ctrl	P23.xx
		P02: Motor 1 Param	P02.xx
	Motor and	P12: Motor 2 Param	P12.xx
	encoder	P20: Motor 1 EEncoder	P20.xx
	parameters	P24: Motor 2 Encoder	P24.xx
	Factory parameters	P99: Factory Func	P99.xx
	Terminal	P05: Input Terminals	P05.xx
	function	P06: Output Terminals	P06.xx
	parameters	P98: AIAO Calibration	P98.xx
		P15: Comm Ex-card 1	P15.xx
		P16: Comm Ex-card 2	P16.xx
	Optional card parameters	P25: Ex I/OCard InpFunc	P25.xx
		P26: Ex I/OCard OutpFunc	P26.xx
		P27: PLC Func	P27.xx
		P28: Master/slave Ctrl	P28.xx
		P90: Tension control speed mode	P90.xx
	Factory customized	P91: Tension control torque	P91.xx
	parameters	P92: Tension control optimization	P92.xx
User defined parameters	/	/	Pxx.xx 

Level 1	Level 2	Level 3	Level 4
		P07: HMI	P07.xx
	State monitoring parameters	P17: State Viewing Func P18: CI-IpCtrlStateView P19: Ex-card StateView	P17.xx P18.xx P19.xx
		P93: Tension control state viewing func	P93.xx
State monitoring	Fault types	/	P07.27: TypeofLatelyFault P07.28: Typeof1stLastFault P07.29: Typeof2ndLastFault P07.30: Typeof3rdLastFault P07.31: Typeof4thLastFault P07.32: Typeof5thLastFault
	Fault recording parameters	1	P07.33: RunFreq atLatelyFault P07.xx: xx state of fault xx
	Clear fault records	/	Sure to clear fault records?
	Modified parameters	/	Pxx.xx: Modified parameter  1  Pxx.xx: Modified parameter  2
	1		Pxx.xx: Modified parameter xx
	Customize Home parameters	Stopped-state parameters  Running-state parameters	<i>I</i>
Motor parameter autotune	/	Ensure motor nameplate parameters are set correctly.	Complete para rotary autotune  Complete para static autotune
			Partial para static autotune

Level 1	Level 2	Level 3	Level 4
			Complete para rotary autotune 2 (for AM)
			Partial para static autotune 2 (for AM)
			Upload local func para to keypad
		A A BAGIGIBOA	Download all func para from keypad
		MemArea1: BACKUP01	Download NonMotor func para from keypad
			Download motor func para from keypad
			Upload local func para to keypad
		MemArea2: BACKUP012	Download all func para from keypad
		/ WellAleaz. BACKOPU12	Download NonMotor func
Copy parameter/Restore	/		para from keypad  Download motor func para from keypad
default		MemArea3: BACKUP03	Upload local func para to keypad
			Download all func para from keypad
			Download NonMotor func para from keypad
			Download motor func para from keypad
		Restore default (excl	Sure to restore defaults
		motor para)	(excl motor para)?
		Restore default (test mode)	Sure to restore default (test mode)?
		Restore default (incl motor para)	Sure to restore default (incl motor para)?
		[F-15]	Language
	,		Time/date
System settings	/	/	Backlight brightness
			Backlight time

Level 1	Level 2	Level 3	Level 4	
			Enable power-on setup	
			wizard	
			Power-on setup wizard	
			Keypad programming	
			Fault time setting	
			Control board programming	
			Up/Down key sensitivity	

## 5.4.2 Editing a parameter list

The parameters in the parameter list in stopped state can be added as needed (through the menu of user defined home parameters), and the list can also be edited such as "Move up", "Move down", "Delete from the list", and "Restore default". The edit function is shown in the following.



Figure 5.10 List edit diagram 1

Press key to enter edit interface, select the operation needed, and press key, key or key to confirm the edit operation and return to the previous menu (parameter list), the returned list is the list edited. If key or key is pressed in edit interface wihouth selecting edit operation, it will return to the previous menu (parameter list remain unchanged).

**Note:** For the parameter objects in the list header, move-up operation will be invalid, and the same principle can be applied to the parameter objects in the list footer; after deleting a certain parameter, the parameter objects under it will be moved up automatically.

The items in the parameter list in running state can be added as needed (through the menu of user defined home parameters), and the list can also be edited such as "Place top", "Move up", "Move down", "Delete from the list", and "Restore default parameters". The edit function is shown in the interface below.



Figure 5.11 List edit diagram 2

The parameters of user defined parameter setting can be added, deleted or adjusted as needed, such as "Place top", "Move up", "Move down", "Delete from the list", and "Restore default parameters"; the adding function can be set in a certain function code in a function group. The edit function is shown in the figure below.



Figure 5.12 List edit diagram 3

## 5.4.3 Adding parameters to the parameter list displayed in stopped/running state

You can choose **Menu** > **State monitoring**, choose a submenu, and enter a specific function group and then a specific function code to add the parameter to the list of parameters displayed in stopped state or parameters displayed in running state.




Figure 5.13 Adding parameter diagram 1

Aftering selecting a specific function code, press key to enter parameter addition interface, and press key, key or key to confirm the addition operation. If this parameter is not

included in the list of parameters displayed in stopped state or list of parameters displayed in running state, the parameter added will be at the end of the list; if the parameter is already in the list of parameters displayed in stopped state or list of parameters displayed in running state, the addition

operation will be invalid. If key or key is pressed without selecting addition operation in "Addition" interface, it will return to monitoring parameter list menu.

Part of the monitoring parameters in P07 HMI group can be added to the "parameter displayed in stop state" list or "parameter displayed in running state" list; all the parameters in P17, P18 and P19 group can be added to the "parameter displayed in stop state" list or "parameter displayed in running state" list.

Up to 16 monitoring parameters can be added to the list of parameters displayed in stopped state; and up to 32 monitoring parameters can be added to the list of parameters displayed in running state.

# 5.4.4 Adding parameters to the user defined parameter list

You can choose **Menu** > **Parameter groups**, choose a submenu, and enter a specific function group and then a specific function code to add the parameter to the user defined parameter list.




Figure 5.14 Adding parameter diagram 2

Press key to enter addition interface, and press key, key or key to confirm the addition operation. If this parameter is not included in the original user defined parameter list, the newly-added parameter will be at the end of the list; if this parameter is already in the user defined parameter list, the addition operation will be invalid. If key or key is pressed without selecting addition operation, it will return to parameter setup list menu.

All the function code groups under the submenu can be added to user defined parameter list. Up to 64 function codes can be added to the user defined parameter list.

#### 5.4.5 Editing user defined parameters

After accessing a specific function code under the **User defined parameters** menu, you can press the key, key or key to enterthe parameter edit interface. After entering the edit interface, the present value is highlighted. Press the key and key to edit the parameter value, and the corresponding parameter item of current value will be highlighted automatically. After the edit operation is completed, press or key to save the selected parameter and return to the previous menu; or press key to maintain the value and return to the previous menu.



Figure 5.15 Editing user defined parameters

In the interface, the "Auth" field on the top right indicates whether this parameter is editable or not.

" \lambda" indicates the set value of this parameter can be modified under the present state.

#### 5.4.6 Editing parameters in parameter groups

You can choose **Menu** > **Parameter groups**, enter a specific function group and then a specific function code, and then press key, key or key to edit the parameter setting interface. After entering edit interface, set the parameter from low bit to high bit, and the bit under setting will be highlighted. Press key or key to increase or decrease theparameter value (this operation is valid until the parameter value exceeds the max. value or min. value); press or key to save the set parameters and return to the previous menu; press to maintain the original parameter value and return to the previous menu.



Figure 5.16 Editing parameters in parameter groups

In the parameter edit interface, the "Auth" field on the top right indicates whether this parameter can be modified or not.

## 5.4.7 Monitoring states

You can choose **Menu** > **State monitoring** > **State monitoring parameter**, enter a specific function

group and then a specific function code, and press key, key or key to enter the state monitoring interface. After entering the state monitoring interface, the actual parameter value will be displayed in real time, this value is the actually detected value which cannot be modified.

In the state monitoring interface, you can press key or key to return to the previous menu.

<sup>&</sup>quot;x" indicates the set value of this parameter cannot be modified under the present state.

<sup>&</sup>quot;Present" indicates the present value.

<sup>&</sup>quot;Default" indicates the default value of this parameter.

<sup>&</sup>quot; \ " indicates the set value of this parameter can be modified under the present state.

<sup>&</sup>quot;x" indicates the set value of this parameter cannot be modified under the present state.

<sup>&</sup>quot;Present" indicates the present value.

<sup>&</sup>quot;Default" indicates the default value of this parameter.



Figure 5.17 State monitoring interface

## 5.4.8 Autotuning motor parameters

You can choose **Menu** > **Motor parameter autotune** and press key, key or key to enter motor parameter autotuning interface. However, before entering the motor parameter autotuning interface, you must set the motor nameplate parameters correctly. After entering the interface, select a motor autotuning type to carry out motor parameter autotuning. In motor parameter autotuning interface, you can press key or key to return to the previous menu.



Figure 5.18 Selecting a parameter autotuning type

After selecting a motor autotuning type, enter motor parameter autotuning interface, and press RUN key to start motor parameter autotuning. After autotuning is done, a message will pop up indicating autotuning is succeeded, and then it will return to the main interface of stop. During autotuning, you can press STOP/RST key to terminate autotuning; if any fault occur during autotuning, the keypad will display a fault interface.



Figure 5.19 Parameter autotuning

#### 5.4.9 Backing up parameters

You can choose **Menu** > **Copy parameter/Restore default**, and press key, key or key to enter the function parameter backup interface and function parameter restoration interface to upload/download VFD parameters, or restore VFD parameters to default values. The keypad has three different storage areas for parameter backup, and each storage area can save the parameters of one VFD, which means the keyapd can save parameters of three VFDs in total.



Figure 5.20 Parameter backup

# 5.4.10 System setup

You can choose **Menu** > **System settings**, and press key, key or key to enter system setting interface to set the keypad language, time/date, backlight brightness, backlight time and restore parameters.

**Note:** Clock battery is not included, and the keypad time/date needs to be reset after power off. If time-keeping after power off is needed, you should purchase the clock batteries separately.



Figure 5.21 System setting diagram

#### 5.4.11 Power-on setup wizard

The keypad supports the power-on setup wizard function, mainly for the first power-on situation, instructing you to enter the setting menu, and gradually implementing basic functions such as basic parameter setting, direction judgment, mode setting and autotuning.

For first power-on, the keypad automatically enters the setup wizard interface. See the following.




Figure 5.22 Power-up setup wizard

If you want to change the guiding settings, you can choose **Menu > System settings**, and then choose **Enable power-on setup wizard** or **Power-on setup wizard**, and then make changes.

# 5.5 Basic operations

## 5.5.1 What this section contains


This section introduces the function modules inside the VFD.



- Ensure all the terminals are fixed and tightened firmly.
- ♦ Ensure the motor matches with the VFD power.

## 5.5.2 Common commissioning procedure

The common operation procedure is shown in the following (taking motor 1 as an example).



Note: If fault occurred, rule out the fault cause according to "fault tracking".

The running command channel can be set by terminal commands besides <u>P00.01</u> and <u>P00.02</u>.

Current running command channel P00.01	Multi-function terminal function (36) Command switches to keypad		Multi-function terminal function (38) Command switches to communication
Keypad	/	Terminal	Communication
Terminal	Keypad	/	Communication
Communication	Keypad	Terminal	/

Note: "/" means this multi-function terminal is invalid under current reference channel.

## Related parameter list:

Function code	Name	Description	Default
P00.00	Speed control mode	O: Sensorless vector control (SVC) mode 0  1: Sensorless vector control (SVC) mode 1  2: Space voltage vector control mode  3: FVC  Note: To select 0, 1, or 3 as the control mode, enable the VFD to perform motor parameter autotuning first.	2
<u>P00.01</u>	Channel of running commands	0: Keypad 1: Terminal 2: Communication	0
P00.02	Communication mode of running commands	0: Modbus/Modbus TCP 1: PROFIBUS/CANopen/DeviceNet 2: Ethernet 3: EtherCAT/PROFINET/EtherNet IP 4: Programmable card 5: Wireless communication card	0
<u>P00.15</u>	Motor parameter autotuning	O: No operation 1: Rotary autotuning. Comprehensive motor parameter autotuning. It is recommended to use rotating autotuning when high control accuracy is needed. 2: Static autotuning 1 (comprehensive autotuning); static autotuning 1 is used in cases where the motor cannot be disconnected from load. 3: Static autotuning 2 (partial autotuning); when	0

Function code	Name	Description	Default
		the present motor is motor 1, only P02.06, P02.07 and P02.08 are autotuned; when the present motor is motor 2, only P12.06, P12.07 and P12.08 are autotuned.  4: Rotary autotuning 2, similar to rotary autotuning 1, but valid only to AMs  5: Static autotuning 3 (partial autotuning), valid only to AMs	
P00.18	Function parameter restore	O: No operation  1: Restore default values (excluding motor parameters)  2: Clear fault records  3: Reserved  4: Reserved  5: Restore default values (for factory test mode)  6: Restore default values (including motor parameters)  Note: After the selected operation is done, this parameter is automatically restored to 0.  Restoring the default values may delete the user password. Exercise caution when using this function. The option 5 can be used only for factory testing.	0
P02.00	Type of motor 1	0: Asynchronous motor (AM) 1: Synchronous motor (SM)	0
<u>P02.01</u>	Rated power of AM 1	0.1–3000.0kW	Model depended
P02.02	Rated frequency of AM 1	0.01Hz-P00.03 (Max. output frequency)	50.00Hz
P02.03	Rated speed of AM 1	1–60000rpm	Model depended
P02.04	Rated voltage of AM 1	0–1200V	Model depended
<u>P02.05</u>	Rated current of AM 1	0.8–6000.0A	Model depended


Function code	Name	Description	Default
<u>P02.15</u>	Rated power of SM 1	0.1–3000.0kW	Model depended
<u>P02.16</u>	Rated frequency of SM 1	0.01Hz-P00.03 (Max. output frequency)	50.00Hz
<u>P02.17</u>	Number of pole pairs of SM 1	1–50	2
<u>P02.18</u>	Rated voltage of SM 1	0–1200V	Model depended
P02.19	Rated current of SM 1	0.8–6000.0A	Model depended
P05.01-P 05.06	Function selection of multifunction digital input terminals (S1–S4, HDIA, HDIB)	36: Switch the running command channel to keypad 37: Switch the running command channel to terminal 38: Switch the running command channel to communication	
P07.01	Reserved		
P07.02	QUICK/JOG key function selection	Range: 0x00–0x27  Ones place: Function of QUICK/JOG  0: No function  1: Jog  2: Reserved  3: Switch between forward and reverse rotating  4: Clear the UP/DOWN setting  5: Coast to stop  6: Switch command channels in sequence  7: Reserved  Tens place: Reserved	0x01

#### 5.5.3 Vector control

AMs feature high order, nonlinearity, strong coupling and multi-variables, which increase difficulty to control AMs during actual application. The vector control technology solves this situation as follows: measures and controls the stator current vector of the AM, and then decomposes the stator current vector into exciting current (current component that generates internal magnet field) and torque current (current component that generates torque) based on field orientation principle, and therefore controls the amplitude values and phase positions of the two components (namely, controls the stator current vector of the AM) to realize decoupled control on exciting current and torque current, thus achieving high-performance speed regulation of the AM.

The VFD uses the sensor-less vector control algorithm, which can be used to drive AMs and permanent-magnet SMs simultaneously. As the core algorithm of vector control is based on accurate motor parameter models, the accuracy of motor parameters affects vector control performance. It is recommended to enter accurate motor parameters and autotune motor parameters before executing vector control.

As the vector control algorithm is complicated, exercise caution before modifying vector control function parameters.



Function	Name	Description	Default
code			
		0: Sensorless vector control (SVC) mode 0	
		1: Sensorless vector control (SVC) mode 1	
D00.00	Speed control	2: Space voltage vector control mode	2
<u>P00.00</u>	mode	3: FVC	2
		Note: To select 0, 1, or 3 as the control mode, enable	
		the VFD to perform motor parameter autotuning first.	
		0: No operation	
		1: Rotary autotuning 1.	
	Motor	Comprehensive motor parameter autotuning. It is	
P00.15	parameter	recommended to use rotating autotuning when high	0
	autotuning	control accuracy is needed.	
		2: Static autotuning 1 (comprehensive autotuning);	
		static autotuning 1 is used in cases where the motor	

Function code	Name	Description	Default
		cannot be disconnected from load.  3: Static autotuning 2 (partial autotuning); when the present motor is motor 1, only P02.06, P02.07 and P02.08 are autotuned; when the present motor is	
		motor 2, only <u>P12.06</u> , <u>P12.07</u> and <u>P12.08</u> are autotuned.  4: Rotary autotuning 2. Similar to rotary autotuning 1, but it is valid only for AMs.  5: Static autotuning 3 (partial autotuning), valid only for AMs.	
<u>P02.00</u>	Type of motor	Asynchronous motor (AM)     Synchronous motor (SM)	0
<u>P03.00</u>	Speed-loop proportional gain 1	0–200.0	20.0
P03.01	Speed-loop integral time 1	0.000–10.000s	0.200s
<u>P03.02</u>	Low-point frequency for switching	0.00Hz- <u>P03.05</u>	5.00Hz
<u>P03.03</u>	Speed-loop proportional gain 2	0–200.0	20.0
<u>P03.04</u>	Speed-loop integral time 2	0.000–10.000s	0.200s
<u>P03.05</u>	High-point frequency for switching	P03.02-P00.03 (Max. output frequency)	10.00Hz
<u>P03.06</u>	Speed-loop output filter	0–8 (0–2 <sup>8</sup> /10ms)	0
<u>P03.07</u>	Electromotive slip compensation coefficient of vector control	50%–200%	100%
<u>P03.08</u>	Braking slip compensation	50%–200%	100%

Function code	Name	Description	Default
	coefficient of		
	vector control		
<u>P03.09</u>	Current-loop proportional coefficient P	0–65535	1000
<u>P03.10</u>	Current-loop integral coefficient I	0–65535	1000
<u>P03.11</u>	Torque setting method	1: Keypad (P03.12) 2: Al1 3: Al2 4: Al3 5: Pulse frequency HDIA 6: Multi-step torque 7: Modbus/Modbus TCP communication 8: PROFIBUS/CANopen/DeviceNet communication 9: Ethernet communication 10: Pulse frequency HDIB 11: EtherCAT/PROFINET/EtherNet IP communication 12: Programmable card Note: For these settings, 100% corresponds to the motor rated current.	1
<u>P03.12</u>	Torque set through keypad	-300.0%–300.0% (of the motor rated current)	50.0%
<u>P03.13</u>	Torque reference filter time	0.000–10.000s	0.010s
P03.14	Setting source of forward rotation upper-limit frequency in torque control	0: Keypad (P03.16) 1: Al1 2: Al2 3: Al3 4: Pulse frequency HDIA 5: Multi-step setting 6: Modbus/Modbus TCP communication 7: PROFIBUS/CANopen/DeviceNet communication 8: Ethernet communication	0

Function code	Name	Description	Default
		9: Pulse frequency HDIB  10: EtherCAT/PROFINET/EtherNet IP communication	
		11: Programmable card	
		12: Reserved	
		Note: For these settings, 100% corresponds to the	
		max. frequency.	
	Setting source		
	of reverse		
D02.15	rotation	0: Keypad (set by <u>P03.17</u> )	0
<u>P03.15</u>	upper-limit	1–11: Same as those of P03.14	U
	frequency in		
	torque control		
	Forward		
	rotation		
	upper-limit		
P03.16	frequency set		50.00Hz
	through		
	keypad in		
	torque control	Setting range: 0.00 Hz-P00.03 (Max. output	
	Reverse	frequency)	
	rotation		
	upper-limit		
P03.17	frequency set		50.00Hz
	through		
	keypad in		
	torque control		
		0: Keypad (P03.20)	
		1: Al1	
		2: AI2	
	0 - 44	3: Al3	
	Setting source of	4: Pulse frequency HDIA	
D00.40		5: Modbus/Modbus TCP communication	0
<u>P03.18</u>	electromotive	6: PROFIBUS/CANopen/DeviceNet communication	0
	torque upper	7: Ethernet communication	
	limit	8: Pulse frequency HDIB	
		9: EtherCAT/PROFINET/EtherNet IP communication	
		10: Programmable card	
		11: Reserved	

Function code	Name	Description	Default
		Note: For these settings, 100% corresponds to the	
		motor rated current.	
<u>P03.19</u>	Setting source of braking torque upper limit	0: Keypad (set by <u>P03.21</u> ) 1–10: Same as those for <u>P03.18</u>	0
<u>P03.20</u>	Electromotive torque upper limit set through keypad	0.0–300.0% (of the motor rated current)	180.0%
<u>P03.21</u>	Braking torque upper limit set through keypad	0.0-300.0% (of the motor fated current)	180.0%
<u>P03.22</u>	Weakening coefficient in constant power zone	0.1–2.0	0.3
P03.23	Lowest weakening point in constant power zone	10%–100%	20%
<u>P03.24</u>	Max. voltage limit	0.0–120.0%	100.0%
<u>P03.25</u>	Pre-exciting time	0.000-10.000s	0.300s
<u>P03.32</u>	Enabling torque control	0: Disable 1: Enable	0
P03.33	Flux weakening integral gain	0–8000	1200
<u>P03.35</u>	Control optimization setting	0–0x1111 Ones place: Torque command selection 0: Torque reference	0x0000

Function code	Name	Description	Default
Code		1: Torque current reference Tens place: Reserved 0: Reserved 1: Reserved Hundreds place: indicates whether to enable speed-loop integral separation 0: Disable 1: Enable Thousands place: Reserved 0: Reserved 1: Reserved Range: 0x0000-0x1111	
<u>P03.36</u>	Speed-loop differential gain	0.00–10.00s	0.00s
<u>P03.37</u>	High-frequenc y current-loop proportional coefficient	In the closed-loop vector control mode ( <u>P00.00</u> =3), when the frequency is lower than the current-loop high-frequency switching threshold ( <u>P03.39</u> ), the	1000
<u>P03.38</u>	High-frequenc y current-loop integral coefficient	current-loop PI parameters are <u>P03.09</u> and <u>P03.10</u> ; and when the frequency is higher than the current-loop high-frequency switching threshold ( <u>P03.39</u> ), the current-loop PI parameters are <u>P03.37</u> and <u>P03.38</u> . Setting range of P03.37: 0–20000	1000
<u>P03.39</u>	Current-loop high-frequenc y switching threshold	Setting range of <u>P03.38</u> : 0–20000 Setting range of <u>P03.39</u> : 0.0–100.0% (of the maximum frequency)	100.0%
<u>P17.32</u>	Flux linkage	0.0–200.0%	0.0%

#### 5.5.4 Space voltage vector control mode

The VFD also provides the space voltage control function. The space voltage control mode can be used in cases where mediocre control precision is enough and in cases where the VFD needs to drive multiple motors.


The VFD provides multiple V/F curve modes to meet different requirements. You can select V/F curves or set V/F curves as required.

## Suggestions:


• For the load featuring constant moment, such as conveyor belt which runs in straight line, as the

whole running process requires constant moment, it is recommended to adopt the straight line V/F curve

 For the load featuring decreasing moment, such as fan and water pumps, as there is a power (square or cube) relation between its actual torque and speed, it is recommended to adopt the V/F curve corresponding to the power of 1.3, 1.7 or 2.0.



The VFD also provides multi-point V/F curves. You can change the V/F curves output by the VFD by setting the voltage and frequency of the three points in the middle. A whole curve consists of five points starting from (0Hz, 0V) and ending at (motor fundamental frequency, motor rated voltage). During setting, follow the rule:  $0 \le f1 \le f2 \le f3 \le Motor$  fundamental frequency, and,  $0 \le V1 \le V2 \le V3 \le Motor$  rated voltage



The VFD provides dedicated function codes for the space voltage control mode. You can improve the space voltage control performance by means of setting.


The VFD provides dedicated function codes for the space voltage control mode. You can improve the space voltage control performance by means of setting.

#### (1) Torque boost

The torque boost function can effectively compensate for the low-speed torque performance in space voltage control. Automatic torque boost has been set by default, which enables the VFD to adjust the torque boost value based on actual load conditions.

#### Note:

- Torque boost takes effect only at the torque boost cut-off frequency.
- If torque boost is too large, the motor may encounter low-frequency vibration or overcurrent. If such a situation occurs, reduce the torque boost value.



# (2) Energy-saving run

During actual running, the VFD can search for the max. efficiency point to keep running in the most efficient state to save energy.

#### Note:

- This function is generally used in light load or no-load cases.
- This function is no applicable to the cases where sudden load changes often occur.

#### (3) V/F slip compensation gain

Space voltage vector control belongs to an open-loop mode. Sudden motor load changes cause motor speed fluctuation. In cases where strict speed requirements must be met, you can set the slip compensation gain to compensate for the speed change caused by load fluctuation through VFD internal output adjustment.

The setting range of slip compensation gain is 0–200%, in which 100% corresponds to the rated slip frequency.

**Note:** Rated slip frequency = (Rated synchronous rotation speed of motor – Rated rotation speed of motor) x (Number of motor pole pairs)/60

#### (4) Oscillation control

Motor oscillation often occurs in space voltage vector control in large-power driving applications. To solve this problem, the VFD provides two oscillation factor function codes. You can set the function codes based on the oscillation occurrence frequency.


**Note:** A greater value indicates better control effect. However, if the value is too large, the VFD output current may be too large.

#### (5) AM IF control

Generally, the IF control mode is valid for AMs. It can be used for SMs only when the frequency is

extremely low. Therefore, the IF control mode described in this manual is only involved with AMs. IF control is implemented by performing closed-loop control on the total output current of the VFD. The output voltage adapts to the current reference, and open-loop control is separately performed over the frequency of the voltage and current.

Customized V/F curve (V/F separation) function:



When selecting the customized V/F curve function, you can specify the setting channels and acceleration/deceleration time of voltage and frequency respectively, which form a real-time V/F curve in combination manner.

**Note:** This type of V/F curve separation can be applied in various variable-frequency power sources. However, exercise caution when setting parameters as improper settings may cause equipment damage.

Function code	Name	Description	Default
P00.00	Speed control mode	O: Sensorless vector control (SVC) mode 0 1: Sensorless vector control (SVC) mode 1 2: Space voltage vector control mode 3: FVC Note: To select 0, 1, or 3 as the control mode, enable the VFD to perform motor parameter autotuning first.	2
P00.03	Max. output frequency	<u>P00.04</u> –400.00Hz	50.00Hz
<u>P00.04</u>	Upper limit of running frequency	P00.05-P00.03	50.00Hz
P00.05	Lower limit of running frequency	0.00Hz- <u>P00.04</u>	0.00Hz
<u>P00.11</u>	ACC time 1	0.0–3600.0s	Model depended
P00.12	DEC time 1	0.0–3600.0s	Model depended
P02.00	Type of motor 1	0: Asynchronous motor (AM) 1: Synchronous motor (SM)	0
P02.02	Rated frequency of AM 1	0.01Hz-P00.03 (Max. output frequency)	50.00Hz
P02.04	Rated voltage of AM 1	0–1200V	Model depended
P04.00	V/F curve setting of motor 1	0: Straight-line V/F curve 1: Multi-point V/F curve 2: Torque-down V/F curve (power of 1.3) 3: Torque-down V/F curve (power of 1.7) 4: Torque-down V/F curve (power of 2.0) 5: Customized V/F curve (V/F separation)	0
<u>P04.01</u>	Torque boost of motor 1	0.0%: (automatic); 0.1%-10.0%	0.0%

Function code	Name	Description	Default
<u>P04.02</u>	Torque boost cut-off of motor 1	0.0%–50.0% (of the rated frequency of motor 1)	20.0%
<u>P04.03</u>	V/F frequency point 1 of motor 1	0.00Hz- <u>P04.05</u>	0.00Hz
<u>P04.04</u>	V/F voltage point 1 of motor 1	0.0%–110.0%	0.0%
<u>P04.05</u>	V/F frequency point 2 of motor 1	<u>P04.03</u> – <u>P04.07</u>	0.00Hz
<u>P04.06</u>	V/F voltage point 2 of motor 1	0.0%–110.0%	0.0%
<u>P04.07</u>	V/F frequency point 3 of motor 1	P04.05- P02.02 or P04.05- P02.16	0.00Hz
<u>P04.08</u>	V/F voltage point 3 of motor 1	0.0%–110.0%	0.0%
<u>P04.09</u>	V/F slip compensation gain of motor 1	0.0–200.0%	100.0%
<u>P04.10</u>	Low-frequency oscillation control factor of motor 1	0–100	10
<u>P04.11</u>	High-frequency oscillation control factor of motor 1	0–100	10
<u>P04.12</u>	Oscillation control threshold of motor 1	0.00Hz-P00.03 (Max. output frequency)	30.00Hz
P04.13	V/F curve setting of motor 2	0: Straight-line V/F curve 1: Multi-point V/F curve 2: Torque-down V/F curve (power of 1.3) 3: Torque-down V/F curve (power of 1.7) 4: Torque-down V/F curve (power of 2.0) 5: Customized V/F curve (V/F separation)	0
<u>P04.14</u>	Torque boost of motor 2	0.0%: (automatic); 0.1%-10.0%	0.0%
<u>P04.15</u>	Torque boost cut-off of motor 2	0.0%–50.0%(of the rated frequency of motor 1)	20.0%
P04.16	V/F frequency	0.00Hz- <u>P04.18</u>	0.00Hz

Function code	Name	Description	Default
	point 1 of motor 2		
<u>P04.17</u>	V/F voltage point 1 of motor 2	0.0%–110.0%	0.0%
<u>P04.18</u>	V/F frequency point 2 of motor 2	<u>P04.16</u> – <u>P04.20</u>	0.00Hz
<u>P04.19</u>	V/F voltage point 2 of motor 2	0.0%—110.0%	0.0%
<u>P04.20</u>	V/F frequency point 3 of motor 2	<u>P04.18</u> – <u>P02.02</u> or <u>P04.18</u> – <u>P02.16</u>	0.00Hz
<u>P04.21</u>	V/F voltage point 3 of motor 2	0.0%–110.0%	0.0%
<u>P04.22</u>	V/F slip compensation gain of motor 2	0.0–200.0%	100.0%
<u>P04.23</u>	Low-frequency oscillation control factor of motor 2	0–100	10
<u>P04.24</u>	High-frequency oscillation control factor of motor 2	0–100	10
<u>P04.25</u>	Oscillation control threshold of motor 2	0.00Hz-P00.03 (Max. output frequency)	30.00Hz
<u>P04.26</u>	Energy-saving run	Disable     Automatic energy-saving run	0
P04.27	Voltage setting channel	0: Keypad; output voltage is determined by P04.28 1: Al1 2: Al2 3: Al3 4: HDIA 5: Multi-step 6: PID 7: Modbus/Modbus TCP communication 8: PROFIBUS/CANopen/DeviceNet communication 9: Ethernet communication	0


Function code	Name	Description	Default
		10: HDIB 11: EtherCAT/PROFINET/EtherNet IP communication 12: Programmable card 13: Reserved	
P04.28	Voltage set through keypad	0.0%–100.0%(of the motor rated voltage)	100.0%
<u>P04.29</u>	Voltage increase time	0.0-3600.0s	5.0s
<u>P04.30</u>	Voltage decrease time	0.0–3600.0s	5.0s
P04.31	Max. output voltage	P04.32–100.0% (of the motor rated voltage)	100.0%
P04.32	Min. output voltage	0.0%-P04.31 (the motor rated voltage)	0.0%
<u>P04.33</u>	Weakening coefficient in constant power zone	1.00–1.30	1.00
P04.34	Pull-in current 1 in SM V/F control	When the SM V/F control mode is enabled, the function code is used to set the reactive current of the motor when the output frequency is lower than the frequency specified by <u>P04.36</u> . Setting range:-100.0%-100.0% (of the motor rated current)	20.0%
P04.35	Pull-in current 2 in SM V/F control	When the SM V/F control mode is enabled, the function code is used to set the reactive current of the motor when the output frequency is higher than the frequency specified by <u>P04.36</u> . Setting range:-100.0%-100.0% (of the motor rated current)	10.0%
P04.36	Frequency threshold for pull-in current switching in SM V/F control	When the SM V/F control mode is enabled, the function code is used to set the frequency threshold for the switching between pull-in current 1 and pull-in current 2.  Setting range: 0.00Hz-P00.03 (Max. output frequency)	50.00Hz
P04.37	Reactive current	When the SM V/F control mode is enabled, the	50

Function code	Name	Description	Default
	closed-loop	function code is used to set the proportional	
	proportional	coefficient of reactive current closed-loop	
	coefficient in SM	control.	
	V/F control	Setting range: 0-3000	
	Reactive current	When the SM V/F control mode is enabled, the	
		function code is used to set the integral	
P04.38	closed-loop	coefficient of reactive current closed-loop	30
	integral time in SM V/F control	control.	
	V/F CONTION	Setting range: 0–3000	
		When the SM V/F control mode is enabled, the	
		function code is used to set the output limit of	
	Reactive current	the reactive current closed-loop control. A	
D04.20	closed-loop output	greater value indicates a higher reactive	8000
<u>P04.39</u>	limit in SM V/F	closed-loop compensation voltage and higher	6000
	control	output power of the motor. In general, you do	
		not need to modify the function code.	
		Setting range: 0–16000	
P04.40	Enabling IF mode	0: Disable	0
1 04.40	for AM 1	1: Enable	U
		When IF control is adopted for AM 1, the	
	Current setting in	function code is used to set the output current.	
P04.41	IF mode for AM 1	The value is a percentage in relative to the	120.0%
	II IIIOGE IOI AWI I	rated current of the motor.	
		Setting range: 0.0–200.0%	
		When IF control is adopted for AM 1, the	
	Proportional	function code is used to set the proportional	
P04.42	coefficient in IF	coefficient of the output current closed-loop	650
	mode for AM 1	control.	
		Setting range: 0-5000	
		When IF control is adopted for AM 1, the	
	Integral coefficient	function code is used to set the integral	
P04.43	in IF mode for AM	coefficient of the output current closed-loop	350
	1	control.	
		Setting range: 0–5000	
	Starting frequency		
<u>P04.44</u>	point for switching	0.00-P04.50	10.00Hz
	off IF mode for AM		

Function code	Name	Description	Default
	1		
<u>P04.45</u>	Enabling IF mode for AM 2	0: Disable 1: Enable	0
<u>P04.46</u>	Current setting in IF mode for AM 2	When IF control is adopted for AM 2, the function code is used to set the output current. The value is a percentage in relative to the rated current of the motor.  Setting range: 0.0–200.0%	120.0%
<u>P04.47</u>	Proportional coefficient in IF mode for AM 2 proportional coefficient	When IF control is adopted for AM 2, the function code is used to set the proportional coefficient of output current closed-loop control. Setting range: 0–5000	650
<u>P04.48</u>	Integral coefficient in IF mode for AM 2	When IF control is adopted for AM 2, the function code is used to set the integral coefficient of output current closed-loop control. Setting range: 0–5000	350
<u>P04.49</u>	Starting frequency point for switching off IF mode for AM 2	0.00-P04.51	10.00Hz
P04.50	End frequency point for switching off IF mode for AM 1	P04.44–P00.03	25.00Hz
P04.51	End frequency point for switching off IF mode for AM 2	P04.49 – P00.03	25.00Hz

## 5.5.5 Torque control

The VFD supports torque control and speed control. Speed control aims to stabilize the speed to keep the set speed consistent with the actual running speed, meanwhile, the max. load-carrying capacity is restricted by the torque limit. Torque control aims to stabilize the torque to keep the set torque consistent with the actual output torque, meanwhile, the output frequency is restricted by the upper and lower limits.



Function code	Name	Description	Default
P00.00	Speed control mode	O: Sensorless vector control (SVC) mode 0  1: Sensorless vector control (SVC) mode 1  2: Space voltage vector control mode  3: FVC  Note: To select 0, 1, or 3 as the control mode, enable the VFD to perform motor parameter autotuning first.	2
P03.32	Enabling torque control	0: Disable 1: Enable	0
P03.11	Torque setting method	1: Keypad (P03.12) 2: Al1 3: Al2 4: Al3 5: Pulse frequency HDIA 6: Multi-step torque 7: Modbus/Modbus TCP communication 8: PROFIBUS/CANopen/DeviceNet communication 9: Ethernet communication 10: Pulse frequency HDIB 11: EtherCAT/PROFINET/EtherNet IP communication 12: Programmable card Note: For these settings, 100% corresponds to the motor rated current.	0
<u>P03.12</u>	Torque set through keypad	-300.0%–300.0% (of the motor rated current)	50.0%
<u>P03.13</u>	Torque reference filter time	0.000-10.000s	0.010s
Setting source of forward rotation  P03.14  Posting source of forward rotation upper-limit frequency in torque control		0: Keypad (P03.16) 1: Al1 2: Al2 3: Al3 4: Pulse frequency HDIA 5: Multi-step setting 6: Modbus/Modbus TCP communication 7: PROFIBUS/CANopen/DeviceNet communication 8: Ethernet communication 9: Pulse frequency HDIB	0

Function code	Name	Description	Default
		10: EtherCAT/PROFINET/EtherNet IP communication 11: Programmable card 12: Reserved Note: For these settings, 100% corresponds to the max. frequency.	
<u>P03.15</u>	Setting source of reverse rotation upper-limit frequency in torque control	0: Keypad (P03.17) 1: Al1 2: Al2 3: Al3 4: Pulse frequency HDIA 5: Multi-step setting 6: Modbus/Modbus TCP communication 7: PROFIBUS/CANopen/DeviceNet communication 8: Ethernet communication 9: Pulse frequency HDIB 10: EtherCAT/PROFINET/EtherNet IP communication 11: Programmable card 12: Reserved Note: For these settings, 100% corresponds to the max. frequency.	0
<u>P03.16</u>	Forward rotation upper-limit frequency set through keypad in torque control	0.00Hz– <u>P00.03</u> (Max. output frequency)	50.00 Hz
<u>P03.17</u>	Reverse rotation upper-limit frequency set through keypad in torque control	0.00Hz– <u>P00.03</u> (Max. output frequency)	50.00 Hz
P03.18	Setting source of electromotive torque upper limit	0: Keypad (P03.20) 1: Al1 2: Al2 3: Al3 4: Pulse frequency HDIA 5: Modbus/Modbus TCP communication	0

Function code	Name	Description	Default
		6: PROFIBUS/CANopen/DeviceNet communication 7: Ethernet communication 8: Pulse frequency HDIB 9: EtherCAT/PROFINET/EtherNet IP communication 10: Programmable card 11: Reserved Note: For these settings, 100% corresponds to the motor rated current.	
<u>P03.19</u>	Setting source of braking torque upper limit	0: Keypad (P03.21) 1: Al1 2: Al2 3: Al3 4: Pulse frequency HDIA 5: Modbus/Modbus TCP communication 6: PROFIBUS/CANopen/DeviceNet communication 7: Ethernet communication 8: Pulse frequency HDIB 9: EtherCAT/PROFINET/EtherNet IP communication 10: Programmable card 11: Reserved Note: For these settings, 100% corresponds to the motor rated current.	0
<u>P03.20</u>	Electromotive torque upper limit set through keypad	0.0-300.0% (of the motor rated current)	180.0%
<u>P03.21</u>	Braking torque upper limit set through keypad	0.0–300.0% (of the motor rated current)	180.0%
P17.09	Output torque	-250.0–250.0%	0.0%
<u>P17.15</u>	Torque reference value	-300.0–300.0% (of the motor rated current)	0.0%

# 5.5.6 Motor parameters



Check the safety conditions surrounding the motor and load machineries before autotuning as physical injury may occur due to sudden start of motor during


#### autotuning.

Although the motor does not run during static autotuning, the motor is still supplied with power. Do not touch the motor during autotuning; otherwise, electric shock may occur. Do not touch the motor before autotuning is completed.




If the motor has been connected to a load, do not carry out rotary autotuning. Otherwise, the VFD may malfunction or may be damaged. If rotary autotuning is carried out on a motor which has been connected to a load, incorrect motor parameter settings and motor action exceptions may occur. Disconnect from the load to carry out autotuning if necessary.

The VFD can drive both asynchronous motors and synchronous motors, and it supports two sets of motor parameters, which can be switched over by multifunction digital input terminals or communication modes.



The control performance of the VFD is based on accurate motor models. Therefore, you need to carry out motor parameter autotuning before running a motor for the first time (taking motor 1 as an example).



#### Note:

- Motor parameters must be set correctly according to the motor nameplate.
- If rotary autotuning is selected during motor autotuning, disconnect the motor from the load to put
  the motor in static and no-load state. Otherwise, the motor parameter autotuning results may be
  incorrect. In addition, autotune <u>P02.06</u>–<u>P02.10</u> for AMs and autotune <u>P02.20</u>–<u>P02.23</u> for SMs.
- If static autotuning is selected for motor autotuning, there is no need to disconnect the motor from
  the load, but the control performance may be impacted as only a part of the motor parameters
  have been autotuned. In addition, autotune <a href="P02.06">P02.06</a>-P02.10 for AMs and autotune

   P02.20-P02.22 for SMs. P02.23 can be obtained through calculation.
- Motor autotuning can be carried out on the present motor only. If you need to perform autotuning
  on the other motor, switch the motor through selecting the switchover channel of motor 1 and
  motor 2 by setting the ones place of <u>P08.31</u>.

Function code	Name	Description	Default
<u>P00.01</u>	Channel of running commands	0: Keypad 1: Terminal 2: Communication	0
P00.15	Motor parameter autotuning	0: No operation 1: Rotary autotuning 1. Comprehensive motor parameter autotuning. It is recommended to use rotating autotuning when high control accuracy is needed. 2: Static autotuning 1 (comprehensive autotuning); static autotuning 1 is used in cases where the motor cannot be disconnected from load. 3: Static autotuning 2 (partial autotuning); when the present motor is motor 1, only P02.06, P02.07 and P02.08 are autotuned; when the present motor is motor 2, only P12.06, P12.07 and P12.08 are autotuned. 4: Rotary autotuning 2. Similar to rotary autotuning 1, but it is valid only for AMs. 5: Static autotuning 3 (partial autotuning), valid only for AMs.	0
<u>P02.00</u>	Type of motor 1	Asynchronous motor (AM)     Synchronous motor (SM)	0
<u>P02.01</u>	Rated power of AM 1	0.1–3000.0kW	Model depended
P02.02	Rated frequency of AM 1	0.01Hz-P00.03 (Max. output frequency)	50.00Hz
P02.03	Rated speed of AM 1	1–60000rpm	Model depended
P02.04	Rated voltage of AM 1	0–1200V	Model depended
P02.05	Rated current of AM 1	0.8–6000.0A	Model depended
P02.06	Stator resistance of AM 1	0.001–65.535Ω	Model depended
<u>P02.07</u>	Rotor resistance of AM	0.001–65.535Ω	Model

Function code	Name	Description	Default
	1		depended
P02.08	Leakage inductance of AM 1	0.1–6553.5mH	Model depended
P02.09	Mutual inductance of AM 1	0.1–6553.5mH	Model depended
P02.10	No-load current of AM	0.1–6553.5A	Model depended
P02.15	Rated power of SM 1	0.1–3000.0kW	Model depended
P02.16	Rated frequency of SM 1	0.01Hz-P00.03 (Max. output frequency)	50.00Hz
P02.17	Number of pole pairs of SM 1	1–50	2
P02.18	Rated voltage of SM 1	0–1200V	Model depended
P02.19	Rated current of SM 1	0.8–6000.0A	Model depended
P02.20	Stator resistance of SM 1	0.001–65.535Ω	Model depended
P02.21	Direct-axis inductance of SM 1	0.01-655.35mH	Model depended
<u>P02.22</u>	Quadrature-axis inductance of SM 1	0.01-655.35mH	Model depended
P02.23	Counter-emf constant of SM 1	0–10000	300
P05.01-P 05.06	Function selection of multifunction digital input terminals (S1–S4, HDIA, HDIB)	35: Switch from motor 1 to motor 2	
P08.31	Switching between motor 1 and motor 2	0x00–0x14 Ones: Switchover channel 0: Switch over by terminal 1: Switch over by Modbus/Modbus TCP communication 2: Switch over by PROFIBUS/CANopen/DeviceNet	0x00

Function code	Name	Description	Default
		3: Switch over by Ethernet communication	
		4: Switch over by	
		EtherCAT/PROFINET/EtherNet IP	
		communication	
		Tens: Motor switchover during running	
		0: Disable switchover during running	
		1: Enable switchover during running	
D12.00	Type of motor 2	0: Asynchronous motor (AM)	0
<u>P12.00</u>	Type of motor 2	1: Synchronous motor (SM)	U
D40.04	Detect never of AM 2	0.1–3000.0kW	Model
<u>P12.01</u>	Rated power of AM 2	0.1–3000.0KW	depended
P12.02	Rated frequency of	0.01Hz–P00.03 (Max. output frequency)	50.00Hz
<u>F 12.02</u>	AM 2	(wax. output frequency)	30.00112
P12.03	Rated speed of AM 2	1–60000rpm	Model
1 12.00	Nated Speed of AW 2	1-00001piii	depended
P12.04	Rated voltage of AM 2	0–1200V	Model
<u>F 12.04</u>	Nated Voltage of AIVI 2	0–1200V	depended
P12.05	Rated current of AM 2	0.8–6000.0A	Model
112.00	Tratou current or 7 tim 2	0.0 0000.071	depended
P12.06	Stator resistance of	0.001–65.535Ω	Model
112.00	AM 2	0.001 00.00012	depended
P12.07	Rotor resistance of AM	0.001–65.535Ω	Model
112.07	2	0.001 00.00012	depended
P12.08	Leakage inductance of	0.1–6553.5mH	Model
1.2100	AM 2		depended
P12.09	Mutual inductance of	0.1–6553.5mH	Model
1.2100	AM 2		depended
P12.10	No-load current of AM	0.1–6553.5A	Model
	2	6556.671	depended
P12.15	Rated power of SM 2	0.1–3000.0kW	Model
			depended
<u>P12.16</u>	Rated frequency of SM 2	0.01Hz-P00.03 (Max. output frequency)	50.00Hz
<u>P12.17</u>	Number of pole pairs of SM 2	1–50	2
D10.10	Poted voltage of CM 2	0.1200\/	Model
<u>P12.18</u>	Rated voltage of SM 2	M 2 0-1200V	depended

Function code	Name	Description	Default
<u>P12.19</u>	Rated current of SM 2	0.8–6000.0A	Model depended
P12.20	Stator resistance of SM 2	0.001–65.535Ω	Model depended
P12.21	Direct-axis inductance of SM 2	0.01–655.35mH	Model depended
P12.22	Quadrature-axis inductance of SM 2	0.01-655.35mH	Model depended
P12.23	Counter-emf constant of SM 2	0–10000	300

## 5.5.7 Start/stop control


The start/stop control of the VFD involves three states: start after a running command is given at power-on; start after power-off restart is effective; start after automatic fault reset. The three start/stop control states are described in the following.

There are three start modes for the VFD, which are start at starting frequency, start after DC braking, and start after speed tracking. You can select the proper start mode based on actual conditions.


For large-inertia load, especially in cases where reversal may occur, you can choose to start after DC braking or start after speed tracking.

### Note: It is recommended to drive SMs in direct start mode.


(1) Logic diagram for start after a running command is given at power-on



### (2) Logic diagram for start after power-off restart is effective



## (3) Logic diagram for start after automatic fault reset



Function code	Name	Description	Default
<u>P00.01</u>	Channel of running commands	Keypad     Terminal     Communication	0
<u>P00.11</u>	ACC time 1	0.0–3600.0s	Model depended
P00.12	DEC time 1	0.0–3600.0s	Model depended
<u>P01.00</u>	Start mode	Direct start     Start after DC braking     Start after speedtracking	0
P01.01	Starting frequency of direct start	0.00–50.00Hz	0.50Hz

Function code	Name	Description	Default
<u>P01.02</u>	Starting frequency hold time	0.0–50.0s	0.0s
<u>P01.03</u>	Braking current before start	0.0–100.0%	0.0%
<u>P01.04</u>	DC braking time before start	0.00-50.00s	0.00s
<u>P01.05</u>	ACC and DEC mode	0: Linear 1: S curve <b>Note:</b> If mode 1 is selected, set <u>P01.06</u> , <u>P01.07</u> , <u>P01.27</u> , and <u>P01.28</u> accordingly.	0
P01.08	Stop mode	0: Decelerate to stop 1: Coast to stop	0
<u>P01.09</u>	Starting frequency of DC braking for stop	0.00Hz-P00.03 (Max. output frequency)	0.00Hz
<u>P01.10</u>	Wait time before DC braking for stop	0.00-50.00s	0.00s
P01.11	DC braking current for stop	0.0–100.0%	0.0%
P01.12	DC braking time for stop	0.00-50.00s	0.00s
<u>P01.13</u>	FWD/REV running deadzone time	0.0–3600.0s	0.0s
<u>P01.14</u>	FWD/REV running switching mode	O: Switch at zero frequency : Switch at the starting frequency : Switch after the speed reaches the stop speed with a delay	0
P01.15	Stop speed	0.00–100.00Hz	0.50 Hz
<u>P01.16</u>	Stop speed detection mode	O: Detect by the set speed (unique in space voltage vector control mode)  1: Detect by the feedback speed	1
<u>P01.18</u>	Terminal-based running command protection at power-on	O: The terminal running command is invalid at power-on T: The terminal running command is valid at power-on  O: The terminal running command is valid at power-on	0
<u>P01.19</u>	Action selected when running frequency less than frequency lower limit (valid when frequency	Ones place: Action selection 0: Run at the frequency lower limit 1: Stop 2: Sleep	0x00

Function code	Name	Description	Default
	lower limit greater than 0)	Tens place: Stop mode	
		0: Coast to stop	
		1: Decelerate to stop	
P01.20	Wake-up-from-sleep delay	0.0-3600.0s (valid when P01.19=2)	0.0s
D04.04		0: Disable	•
<u>P01.21</u>	Power-off restart selection	1: Enable	0
<u>P01.22</u>	Wait time for power-on restart	0.0–3600.0s (valid when <u>P01.21</u> =1)	1.0s
P01.23	Start delay	0.0-60.0s	0.0s
P01.24	Stop speed delay	0.0-100.0s	0.0s
		0: Output without voltage	
D04.25	Open-loop 0Hz output	1: Output with voltage	0
<u>P01.25</u>	selection	2: Output with the DC braking current for	U
		stop	
<u>P01.26</u>	DEC time for emergency stop	0.0-60.0s	2.0s
<u>P01.27</u>	Time of starting segment of DEC S curve	0.0–50.0s	0.1s
<u>P01.28</u>	Time of ending segment of DEC S curve	0.0-50.0s	0.1s
<u>P01.29</u>	Short-circuit braking current	0.0-150.0% (of the VFD rated current)	0.0%
<u>P01.30</u>	Hold time of short-circuit braking for start	0.00-50.00s	0.00s
<u>P01.31</u>	Hold time of short-circuit braking for stop	0.00-50.00s	0.00s
P01.32	Pre-exciting time of jog	0-10.000s	0.000s
<u>P01.33</u>	Starting frequency of braking for jogging to stop	0-P00.03	0.00Hz
P01.34	Delay to enter sleep	0-3600.0s	0.0s
	, and the second	1: Run forward	
		2: Run reversely	
B05	<b>5</b>	4: Jog forward	
P05.01-P	Digital input function	5: Jog reversely	
<u>05.06</u>	selection	6: Coast to stop	
		7: Reset faults	
		8: Pause running	

Function code	Name	Description	Default
		21: ACC/DEC time selection 1	
		22: ACC/DEC time selection 2	
		30: Disable ACC/DEC	
D00 00	ACC time 2	0.0–3600.0s	Model
P08.00	ACC time 2	0.0–3600.08	depended
D00 01	DEC time 2	0.0.3600.00	Model
P08.01	DEC time 2	0.0–3600.0s	depended
D00 02	ACC time 3	0.0–3600.0s	Model
<u>P08.02</u>	ACC time 3	0.0–3600.05	depended
D00 03	DEC time 3	0.0–3600.0s	Model
P08.03	DEC time 3	0.0–3600.05	depended
D00 04	ACC time 4	0.0.3600.00	Model
<u>P08.04</u>	ACC time 4	0.0–3600.0s	depended
D00 05	DEC time 4	0.0–3600.0s	Model
<u>P08.05</u>	DEC time 4	0.0–3600.05	depended
P08.06	Running frequency of jog	0.00Hz-P00.03 (Max. output frequency)	5.00Hz
D00.07	ACC time for jog	0.0–3600.0s	Model
<u>P08.07</u>	ACC time for jog	0.0–3600.05	depended
P08.08	DEC time for jog	0.0–3600.0s	Model
<u>P00.00</u>	DEC time for jog	0.0–3600.05	depended
		0.00-P00.03(Max. output frequency)	0
P08.19	Switching frequency of	0.00Hz: No switchover	
<u>F00.19</u>	ACC/DEC time	If the running frequency is greater than	
		P08.19, switch to ACC/DEC time 2.	
		0: Max. output frequency	0
<u>P08.21</u>	Potoronoo fraguanay of	1: Set frequency	
	Reference frequency of ACC/DEC time	2: 100Hz	
	ACC/DEC tille	Note: Valid only for straight-line	
		ACC/DEC	
P08.28	Auto fault reset count	0–10	0
P08.29	Auto fault reset interval	0.1–3600.0s	1.0s


## 5.5.8 Frequency setting

The VFD supports multiple frequency setting methods, which can be divided into two types: main reference channel and auxiliary reference channel.

There are two main reference channels, namely frequency reference channel A and frequency reference channel B. These two channels support simple arithmetical operation between each other, and they can be switched dynamically by setting multi-function terminals.

There is one input mode for auxiliary reference channel, namely terminal <a href="UP/DOWN">UP/DOWN</a> switch input. By setting function codes, you can enable the corresponding reference mode and the impact made on the VFD frequency reference by this reference mode.

The actual reference of VFD is comprised of the main reference channel and auxiliary reference channel.




The VFD supports switchover between different reference channels, and the rules for channel switchover are shown in the following.

Present reference channel <u>P00.09</u>	Multifunction terminal function 13 Channel A switched to channel B	Multifunction terminal function 14 Combination setting switched to channel A	Multifunction terminal function 15 Combination setting switched to channel B
Α	В	/	/
В	А	/	/
A+B	/	А	В
A-B	/	А	В
Max(A,B)	/	А	В
Min(A,B)	/	А	В

Note: "/" indicates this multifunction terminal is invalid under present reference channel.

When setting the auxiliary frequency inside the VFD via multi-function terminal UP (10) and DOWN (11), you can increase/decrease the frequency quickly by setting <u>P08.45</u> (UP terminal frequency incremental change rate) and <u>P08.46</u> (DOWN terminal frequency decrement change rate).




Function code	Name	Description	Default
P00.03	Max. output frequency	<u>P00.04</u> –400.00Hz	50.00Hz
<u>P00.04</u>	Upper limit of running frequency	P00.05-P00.03	50.00Hz
<u>P00.05</u>	Lower limit of running frequency	0.00Hz- <u>P00.04</u>	0.00Hz
<u>P00.06</u>	Setting channel of A frequency command	0: Keypad 1: Al1	0
P00.07	Setting channel of B	2: Al2	15

Function code	Name	Description	Default
	frequency command	3: AI3	
		4: High speed pulse HDIA	
		5: Simple PLC program	
		6: Multi-step speed running	
		7: PID control	
		8: Modbus/Modbus TCP communication	
		9: PROFIBUS/CANopen/DeviceNet	
		communication	
		10: Ethernet communication	
		11: High speed pulse HDIB	
		12: Pulse train AB	
		13: EtherCAT/PROFINET/EtherNet IP	
		communication	
		14: Programmable card	
		15: Reserved	
D00.00	Reference object of B	0: Max. output frequency	
P00.08	frequency command	1: A frequency command	0
		0: A	
		1: B	
P00.09	Combination mode of	2: (A+B)	0
<u>F00.09</u>	setting source	3: (A-B)	U
		4: Max(A, B)	
		5: Min. (A, B)	
		10: Increase frequency setting (UP)	
		11: Decrease frequency setting (DOWN)	
		12: Clear the frequency	
	Function selection of	increase/decrease setting	
<u>P05.01</u> – <u>P</u>	multifunction digital input	13: Switch between A setting and B	
<u>05.06</u>	terminals (S1-S4, HDIA,	setting	
	HDIB)	14: Switch between combination setting	
		and A setting	
		15: Switch between combination setting	
		and B setting	
P08.42	Reserved		
P08.43	Reserved		
P08.44	UP/DOWN terminal control	0x000–0x221	0x000
1 00.44	setting	Ones place: Frequency setting selection	0,000

Function code	Name	Description	Default
		0: The setting made through UP/DOWN	
		is valid.	
		1: The setting made through UP/DOWN	
		is invalid.	
		Ones place: Frequency control selection	
		0: Valid only when P00.06=0 or P00.07=0	
		1: Valid for all frequency setting methods	
		2: Invalid for multi-step speed running	
		when multi-step speed running has the	
		priority	
		Hundreds place: Action selection for stop	
		0: Setting is valid.	
		1: Valid during running, cleared after stop	
		2: Valid during running, cleared after a	
		stop command is received	
	Frequency increment		
P08.45	change rate of the UP	0.01–50.00 Hz/s	0.50 Hz/s
	terminal		
	Frequency decrement		
P08.46	change rate of the DOWN	0.01–50.00 Hz/s	0.50 Hz/s
	terminal		
P17.00	Set frequency	0.00Hz-P00.03 (Max. output frequency)	0.00Hz
P17.02	Ramp reference frequency	0.00Hz-P00.03 (Max. output frequency)	0.00Hz
P17.14	Digital adjustment value	0.00Hz- <u>P00.03</u>	0.00Hz

### 5.5.9 Analog input

The VFD provides two analog input terminals, which are Al1 supporting 0–10V/0–20mA, (whether the input is voltage or current can be set by <u>P05.50</u>), and Al2 supporting -10–10V, and two high-speed pulse input terminals. Each input can be filtered separately, and the corresponding reference curve can be set by adjusting the reference corresponds to the max. value and min. value.




Function code	Name	Description	Default
<u>P05.00</u>	HDI input type	0x00–0x11 Ones place: HDIA input type 0: HDIA is high-speed pulse input 1: HDIA is digital input Tens place: HDIB input type 0: HDIB is high-speed pulse input 1: HDIB is digital input	0x00
P05.24	Al1 lower limit	0.00V-P05.26	0.00V
<u>P05.25</u>	Corresponding setting of Al1 lower limit	-300.0%–300.0%	0.0%
P05.26	Al1 upper limit	P05.24-10.00V	10.00V
<u>P05.27</u>	Corresponding setting of Al1 upper limit	-300.0%–300.0%	100.0%
P05.28	Al1 input filter time	0.000s-10.000s	0.100s
P05.29	Al2 lower limit	-10.00V– <u>P05.31</u>	-10.00V

Function code	Name	Description	Default
<u>P05.30</u>	Corresponding setting of Al2 lower limit	-300.0%–300.0%	-100.0%
P05.31	Al2 middle value 1	P05.29-P05.33	0.00V
<u>P05.32</u>	Corresponding setting of Al2 middle value 1	-300.0%–300.0%	0.0%
P05.33	Al2 middle value 2	<u>P05.31</u> – <u>P05.35</u>	0.00V
<u>P05.34</u>	Corresponding setting of Al2 middle value 2	-300.0%–300.0%	0.0%
P05.35	AI2 upper limit	<u>P05.33</u> –10.00V	10.00V
<u>P05.36</u>	Corresponding setting of Al2 upper limit	-300.0%–300.0%	100.0%
P05.37	Al2 input filter time	0.000s-10.000s	0.100s
<u>P05.38</u>	HDIA high-speed pulse input function selection	<ul><li>0: Input set through frequency</li><li>1: Reserved</li><li>2: Input set through encoder, used together with HDIB</li></ul>	0
P05.39	HDIA lower limit frequency	0.000 kHz – <u>P05.41</u>	0.000kHz
P05.40	Corresponding setting of HDIA lower limit frequency	-300.0%–300.0%	0.0%
P05.41	HDIA upper limit frequency	P05.39 –50.000kHz	50.000kHz
P05.42	Corresponding setting of HDIA upper limit frequency	-300.0%–300.0%	100.0%
<u>P05.43</u>	HDIA frequency input filter time	0.000s-10.000s	0.030s
<u>P05.44</u>	HDIB high-speed pulse input function selection	Input set through frequency     Reserved     Input set through encoder, used together with HDIA	0
P05.45	HDIB lower limit frequency	0.000 kHz – <u>P05.47</u>	0.000kHz
<u>P05.46</u>	Corresponding setting of HDIB lower limit frequency	-300.0%–300.0%	0.0%
P05.47	HDIB upper limit frequency	<u>P05.45</u> –50.000kHz	50.000kHz
<u>P05.48</u>	Corresponding setting of HDIB upper limit frequency	-300.0%–300.0%	100.0%
<u>P05.49</u>	HDIB frequency input filter time	0.000s-10.000s	0.030s
P05.50	Al1 input signal type	0–1	0

Function code	Name	Description	Default
		0: Voltage	
		1: Current	

### 5.5.10 Analog output

The VFD provides one analog output terminal (supporting 0–10V/0–20mA) and one high-speed pulse output terminal. Analog output signals can be filtered separately, and the proportional relation can be adjusted by setting the max. value, min. value, and the percentage of their corresponding output. Analog output signals can output the motor speed, output frequency, output current, motor torque and motor power at a certain proportion.



Terminal output is described as follows:

Setting	Function	Description
0	Running frequency	0-Max. output frequency
1	Set frequency	0-Max. output frequency
2	Ramp reference frequency	0-Max. output frequency
3	Running speed	0-Synchronous speed corresponding to
3		max. output frequency
4	Output current (relative to VFD)	0-Twice the VFD rated current
5	Output current (relative to motor)	0-Twice the motor rated current
6	Output voltage	0–1.5 times the VFD rated voltage
7	Output power	0-Twice the rated power
	Set torque value (bipolar)	0-Twice the VFD rated current. A negative
8		value corresponds to 0.0% by default.
9	Output torque (absolute value)	0 - +/-(Twice the motor rated torque)
10	Al1 input	0-10V/0-20mA
11	Al2 input	0V-10V. A negative value corresponds to

Setting	Function	Description
		0.0% by default.
12	Al3 input	0–10V/0–20mA
13	High-speed pulse HDIA input	0.00–50.00kHz
14	Value 1 set through Modbus/Modbus TCP communication	0–1000
15	Value 2 set through Modbus/Modbus TCP communication	0–1000
16	Value 1 set through PROFIBUS/CANopen/DeviceNet communication	0–1000
17	Value 2 set through PROFIBUS/CANopen/DeviceNet communication	0–1000
18	Value 1 set through Ethernet communication	0–1000
19	Value 2 set through Ethernet communication	0–1000
20	High-speed pulse HDIA input	0.00–50.00kHz
21	Value 1 set through EtherCAT/PROFINET/EtherNet IP communication	0–1000. A negative value corresponds to 0.0% by default.
22	Torque current (bipolar)	0–Three times the motor rated current. A negative value corresponds to 0.0% by default.
23	Exciting current	0–Three times the motor rated current. A negative value corresponds to 0.0% by default.
24	Set frequency (bipolar)	0-Max. output frequency. A negative value corresponds to 0.0% by default.
25	Ramp reference frequency (bipolar)	0-Max. output frequency. A negative value corresponds to 0.0% by default.
26	Rotational speed (bipolar)	0–Synchronous speed corresponding to max. output frequency A negative value corresponds to 0.0% by default.
27	Value 2 set through EtherCAT/PROFINET/EtherNet IP communication	0–1000

Setting	Function	Description
28	AO1 from the programmable card	0–1000
29	AO2 from the programmable card	0–1000
30	Rotational speed	0–Twice the motor rated synchronous speed
31	Output torque (bipolar)	0-Twice motor rated torque. A negative value corresponds to 0.0% by default.
32	AI/AO temperature detection output	AO value of AI/AO temperature detection
33–63	Reserved	

Function code	Name	Description	Default
<u>P06.00</u>	HDO output type	O: Open collector high-speed pulse output     Copen collector output	0
P06.14	AO1 output	0: Running frequency	0
P06.15	Reserved	1: Set frequency	0
P06.16	HDO high-speed pulse output	2: Ramp reference frequency 3: Rotational speed (100% corresponds to the speed corresponding to max. output frequency) 4: Output current (100% corresponds to twice the VFD rated current) 5: Output current (100% corresponds to twice the motor rated current) 6: Output voltage (100% corresponds to 1.5 times the VFD rated voltage) 7: Output power (100% corresponds to twice the motor rated power) 8: Set torque (100% corresponds to twice the motor rated torque) 9: Output torque (Absolute value, 100% corresponds to twice the motor rated torque) 10: Al1 input 11: Al2 input 12: Al3 input	0


Function code	Name	Description	Default
		13: HDIA input	
		14: Value 1 set through	
		Modbus/Modbus TCP communication	
		15: Value 2 set through	
		Modbus/Modbus TCP communication	
		16: Value 1 set through	
		PROFIBUS/CANopen/DeviceNet	
		communication	
		17: Value 2 set through	
		PROFIBUS/CANopen/DeviceNet	
		communication	
		18: Value 1 set through Ethernet	
		communication	
		19: Value 2 set through Ethernet	
		communication	
		20: HDIB input	
		21: Value 1 set through	
		EtherCAT/PROFINET/EtherNet IP	
		communication	
		22: Torque current (bipolar, 0-Triple the	
		motor rated current)	
		23: Exciting current (bipolar, 0-Triple	
		the motor rated current)	
		24: Set frequency (bipolar)	
		25: Ramp reference frequency (bipolar)	
		26: Rotational speed (bipolar)	
		27: Value 2 set through	
		EtherCAT/PROFINET/EtherNet IP	
		communication	
		28: AO1 from the programmable card	
		29: AO2 from the programmable card	
		30: Rotational speed (100%	
		corresponds to twice the motor rated	
		synchronous speed)	
		31: Output torque (Actual value, 100%	
		corresponds to twice the motor rated	
		torque)	
		32: AI/AO temperature detection output	

Function code	Name	Description	Default
		33–63: Reserved	
		Note:	
		When the output comes from the	
		programmable card (28-29), if the card	
		is a Codesys programmable card,	
		P27.00 must be set to 1.	
		When AO1 is of the current output type,	
		100% corresponds to 20mA; when AO1	
		is of the voltage output type, 100%	
		corresponds to 10V; 100% of HDO	
		corresponds to the output of P06.30.	
P06.17	AO1 output lower limit	-300.0%– <u>P06.19</u>	0.0%
<u>P06.18</u>	AO1 output corresponding to lower limit	0.00V-10.00V	0.00V
P06.19	AO1 output upper limit	<u>P06.17</u> –300.0%	100.0%
<u>P06.20</u>	AO1 output corresponding to upper limit	0.00V-10.00V	10.00V
P06.21	AO1 output filter time	0.000s-10.000s	0.000s
P06.22- P06.26	Reserved	0–65535	0
P06.23	PTC constant output current setting	0.000–20.000mA	4.000
P06.24	PTC resistance alarm threshold	0–60000Ω	750
P06.25	PTC resistance alarm recovery threshold	0–60000Ω	150
P06.26	Actual PTC resistance	0–60000Ω	0
P06.27	HDO output lower limit	-300.0%– <u>P06.29</u>	0.0%
<u>P06.28</u>	HDO output corresponding to lower limit	0.00-50.00kHz	0.0kHz
P06.29	HDO output upper limit	<u>P06.27</u> –300.0%	100.0%
<u>P06.30</u>	HDO output corresponding to upper limit	0.00–50.00kHz	50.00kHz
P06.31	HDO output filter time	0.000s-10.000s	0.000s

# 5.5.11 Digital input

The VFD provides four programmable digital input terminals and two HDI input terminals. All the digital input terminal functions can be programmed by function codes. HDI input terminal can be set to

act as high-speed pulse input terminal or common digital input terminal; if it is set to act as high-speed pulse input terminal, you can also set HDIA or HDIB high-speed pulse input to serve as the frequency reference and encoder signal input.



Note: Two different multifunction input terminals cannot be set as the same function.

Setting	Function	Description
0	No function	The VFD does not act even if there is signal input; you can set the unused terminals to "no function" to avoid misacts.
1	Forward running (FWD)	Control the forward/reverse running of the VFD by
2	Reverse running (REV)	external terminals.
3	3-wire control/Sin	Set the VFD running mode to 3-wire control mode by this terminal. See P05.13 for details.
4	Forward jogging	Frequency when jogging, see P08.06, P08.07 and
5	Reverse jogging	P08.08 for jogging acceleration/deceleration time.
6	Coast to stop	The VFD blocks output, and the stop process of motor is uncontrolled by the VFD. This mode is applied in cases of large-inertia load and free stop time; its definition is the same with P01.08, and it is mainly used in remote control.
7	Fault reset	External fault reset function, its function is the same with the STOP/RST key on the keypad. This function can be used in remote fault reset.

Setting	Function	Description	
8	Running pause	The VFD decelerates to stop, however, all the running parameters are in memory state, such as PLC parameter, wobbling frequency, and PID parameter. After this signal disappears, the VFD will revert to the state before stop.	
9	External fault input	When external fault signal is transmitted to the VFD, the VFD releases fault alarm and stops.	
10	Frequency increase (UP)	Used to change the frequency-increase/decrease	
11	Frequency decrease (DOWN)	command when the frequency is given by external terminals.	
12	Clear frequency increase/decrease setting	The terminal used to clear frequency-increase/decrease setting can clear the frequency value of auxiliary channel set by UP/DOWN, thus restoring the reference frequency to the frequency given by main reference frequency command channel.	
13	Switching between A setting and B setting	This function is used to switch between the frequency setting channels.	
14	Switching between combination setting and A setting	A frequency reference channel and B frequency reference channel can be switched by no. 13 function; the combination channel set by P00.09 and the A frequency reference channel can be switched by no. 14	
15	Switching between combination setting and B setting	function; the combination channel set by P00.09 and the B frequency reference channel can be switched by no. 15 function.	
16	Multi-step speed terminal 1	16-step speeds can be set by combining digital states of	
17	Multi-step speed terminal 2	these four terminals.	

Setting	Function					Descr	iption		
18	Multi-step speed terminal 3		Note: Multi-step speed 1 is low bit, multi-step speed 4 is high bit.				i-step speed		
19	Multi-step speed terminal 4		Multi-s speed	tep		ulti-step eed 3	Multi-step speed 2		Multi-step speed 1
20	Multi-step speed pause				ep sı	need sele		on t	to keep the set
21	Acceleration/deceleration time selection 1					ninals to s	_	rou	ıps of
	Acceleration/deceleration time selection 2	Т	Terminal	Term 2		deceler	eration or ation time ection	C	orresponding parameter
		c	OFF	OFF		Accelera decelera	tion/ tion time 1	PC	00.11/P00.12
22			NC	OFF		Accelera decelera	tion/ tion time 2	PC	08.00/P08.01
		c	OFF	ON		Accelera decelera	tion/ tion time 3	PC	08.02/P08.03
		c	ON	ON		Accelera decelera	tion/ tion time 4	PC	08.04/P08.05
23	Simple PLC stop reset		testart si	•		process	and clear p	rev	vious PLC
24	Simple PLC pause	The program pauses during PLC execution, and keeps running in current speed step. After this function is cancelled, simple PLC keeps running.							
25	PID control pause	PID is ineffective temporarily, and the VFD maintains current frequency output.							
26	Wobbling frequency pause (stop at current frequency)		The VFD pauses at current output. After this function is canceled, it continues wobbling-frequency operation at						

Setting	Function	Description
		current frequency.
27	Wobbling frequency reset (revert to center frequency)	The set frequency of VFD reverts to center frequency.
28	Counter reset	Zero out the counter state.
29	Switching between speed control and torque control	The VFD switches from torque control mode to speed control mode, or vice versa.
30	Acceleration/deceleration disabled	Ensure the VFD will not be impacted by external signals (except for stop command), and maintains current output frequency.
31	Counter trigger	Enable pulse counting of the counter.
33	Clear frequency increase/decrease setting temporarily	When the terminal is closed, the frequency value set by UP/DOWN can be cleared to restore to the frequency given by frequency command channel; when the terminal is disconnected, it will revert to the frequency value after frequency increase/decrease setting.
34	DC brake	The VFD starts DC braking immediately after the command becomes valid.
35	Switching between motor 1 and motor 2	When this terminal is valid, you can realize switchover control of two motors.
36	Command switches to keypad	When this terminal is valid, the running command channel will switch to keypad compulsorily. If this function becomes invalid, the running command channel will revert to the original state.
37	Command switches to terminal	When this terminal is valid, the running command channel will switch to terminal compulsorily. If this function becomes invalid, the running command channel will revert to the original state.
38	Command switches to communication	When this terminal is valid, the running command channel will switch to communication compulsorily. If this function becomes invalid, the running command channel will revert to the original state.

Basic operation guidelines

Setting	Function	Description
39	Pre-exciting command	When this terminal is valid, motor pre-exciting will be started until this terminal becomes invalid.
40	Zero out power consumption quantity	After this command becomes valid, the power consumption quantity of the VFD will be zeroed out.
41	Maintain power consumption quantity	When this command is valid, current operation of the VFD will not impact the power consumption quantity.
42	Source of upper torque limit switches to keypad	When this command is valid, the upper limit of the torque will be set by keypad.
43	Position reference point input	Valid only for S1, S2, and S3.
44	Disable spindle orientation	Spindle orientation is invalid.
45	Spindle zeroing/local position zeroing	Spindle positioning is triggered.
46	Spindle zero position selection 1	Spindle zero position selection 1.
47	Spindle zero position selection 2	Spindle zero position selection 2.
48	Spindle scale division selection 1	Spindle scale division selection 1.
49	Spindle scale division selection 2	Spindle scale division selection 2.
50	Spindle scale division selection 3	Spindle scale division selection 3.
51	Position/speed control switchover terminal	Terminal for switching between position control and speed control.
52	Disable pulse input	Pulse input is invalid when the terminal is valid.
53	Clear position deviation	Used to clear the input deviation of position loop.
54	Switch position proportional gains	Used to switch position proportional gains.

Setting	Function	Description
55	Enable cyclic digital positioning	Cyclic positioning can be enabled when digital positioning is valid.
56	Emergency stop	When this command is valid, the motor decelerate to emergency stop as per the time set by P01.26.
57	Motor overtemperature fault input	Motor stops at motor over-temperature fault input.
59	Switch from FVC to SVPWM control	When this terminal is valid in stop state, switch to SVPWM control.
60	Switch to FVC control	When this terminal is valid in stop state, switch to FVC (closed-loop vector) control.
61	PID polarity switchover	Switching the output polarity of PID, this terminal should be used in conjunction with P09.03
62	Reserved	
63	Enable servo	When the thousands place of P21.00 is set to enable the servo, the servo enabling terminal is valid, which controls the VFD to enter zero servo control. At this situation, no startup command is needed.
64	FWD max. limit	Max frequency limit on forward rotation
65	REV max limit	Max frequency limit on reverse rotation
66	Zero out the counter	Zero out the position counting value
67	Pulse increase	When the terminal function is valid, the pulse input is increased according to the P21.27 pulse speed.
68	Enable pulse superimposition	When the pulse superimposition is enabled, pulse increase and pulse decrease are effective.
69	Pulse decrease	When the terminal function is valid, the pulse input is decreased according to the P21.27 pulse speed.
70	Electronic gear selection	If the terminal is valid, the proportional numerator is switched to the P21.30 numerator of the 2 <sup>nd</sup> command ratio.

Setting	Function	Description
71	Switch to mater	In stopped state, if the terminal is valid, the master is used.
72	Switch to slave	In stopped state, if the terminal is valid, the slave is used.
73	Reset roll diameter	Used to reset the roll diameter when the tension control function is enabled.
74	Switch winding/unwinding	Used to switch winding/unwinding modes when the tension control function is enabled.
75	Tension control pre-drive	If the terminal is valid when the tension control function is enabled, tension control pre-drive is performed.
76	Disable roll diameter calculation	If the terminal is valid when the tension control function is enabled, roll diameter calculation is disabled.
77	Clear alarm display	Used to clear the alarm display when the tension control function is enabled.
78	Manual braking of tension control	If the terminal is valid when the tension control function is enabled, manual braking is activated.
79	Trigger forced feeding interrupt	If the terminal is valid when the tension control function is enabled, a feeding interrupt signal is triggered forcibly.
80	Initial roll diameter 1	Used to select different initial roll diameters by combining with the initial roll diameter 2 when the tension control function is enabled.
81	Initial roll diameter 2	Used to select different initial roll diameters by combining with the initial roll diameter 1 when the tension control function is enabled.
82	Trigger fire mode control	In fire mode, if the terminal is valid, the fire mode control signal is triggered.
83	Switch tension PID parameters	Used to switch two PID parameter groups when the tension control function is enabled. The first group is used by default. If the terminal is valid, the second group is used.

Setting	Function	Description
84–95	Reserved	/

Function code	Name	Description	Default
P05.00	HDI input type	0x00–0x11 Ones: HDIA input type 0: HDIA is high-speed pulse input 1: HDIA is digital input Tens: HDIB input type 0: HDIB is high-speed pulse input 1: HDIB is digital input	0x00
P05.01	Function of S1 terminal	0: No function	1
<u>P05.02</u>	Function of S2 terminal	Forward running     Reverse running	4
P05.03	Function of S3 terminal	3: 3-wire control/Sin	7
<u>P05.04</u>	Function of S4 terminal	4: Forward jogging 5: Reverse jogging	0
<u>P05.05</u>	Function of HDIA terminal	6: Coast to stop 7: Fault reset 8: Running pause	0
P05.06	Function of HDIB terminal	9: External fault input 10: Frequency increase (UP) 11: Frequency decrease (DOWN) 12: Clear frequency increase/decrease setting 13: Switchover between setup A and setup B 14: Switchover between combination setting and A setting 15: Switchover between combination setting and setup B 16: Multi-step speed terminal 1 17: Multi-step speed terminal 2 18: Multi-step speed terminal 3 19: Multi-step speed terminal 4 20: Multi-step speed pause 21: Acceleration/deceleration time selection	0


Function	Mana	December 1	Defect
code	Name	Description	Default
		1	
		22: Acceleration/deceleration time selection	
		2	
		23: Simple PLC stop reset	
		24: Simple PLC pause	
		25: PID control pause	
		26: Wobbling frequency pause	
		27: Wobbling frequency reset	
		28: Counter reset	
		29: Switching between speed control and	
		torque control	
		30: Acceleration/deceleration disabled	
		31: Counter trigger	
		32: Reserved	
		33: Clear frequency increase/decrease	
		setting temporarily	
		34: DC brake	
		35: Switching between motor 1 and motor 2	
		36: Command switches to keypad	
		37: Command switches to terminal	
		38: Command switches to communication	
		39: Pre-exciting command	
		40: Zero out power consumption quantity	
		41: Maintain power consumption quantity	
		42: Source of upper torque limit switches to	
		keypad	
		43: Position reference point input (only valid	
		for S1, S2 and S3)	
		44: Disable spindle orientation	
		45: Spindle zeroing/local positioning zeroing	
		46: Spindle zero position selection 1	
		47: Spindle zero position selection 2	
		48: Spindle scale division selection 1	
		49: Spindle scale division selection 2	
		50: Spindle scale division selection 3	
		51: Position/speed control switchover	
		terminal	
		52: Disable pulse input	

Function code	Name	Description	Default
		53: Clear position deviation	
		54: Switch position proportional gains	
		55: Enable cyclic digital positioning	
		56: Emergency stop	
		57: Motor overtemperature fault input	
		59: Switch to V/F control	
		60: Switch to FVC control	
		61: PID polarity switchover	
		62: Reserved	
		63: Enable servo	
		64: FWD max. limit	
		65: REV max limit	
		66: Zero out the counter	
		67: Pulse increase	
		68: Enable pulse superimposition	
		69: Pulse decrease	
		70: Electronic gear selection	
		71: Switch to master	
		72: Switch to slave	
		73: Reset the roll diameter	
		74: Switch winding/unwinding	
		75: Pre-drive	
		76: Disable roll diameter calculation	
		77: Clear alarm display	
		78: Manual braking	
		79: Trigger forced feeding interrupt	
		80: Initial roll diameter 1	
		81: Initial roll diameter 2	
		82: Trigger fire mode control	
		83: Switch tension PID parameters	
		84–95: Reserved	
<u>P05.07</u>	Reserved		
P05.08	Polarity of input terminal	0x00-0x3F	0x00
P05.09	Digital filter time	0.000-1.000s	0.010s
		0x00-0x3F (0: Disable; 1: Enable)	
P05.10	Virtual terminal setting	BIT0: S1 virtual terminal	0x00
		BIT1: S2 virtual terminal	

Function code	Name	Description	Default
		BIT2: S3 virtual terminal	
		BIT3: S4 virtual terminal	
		BIT4: HDIA virtual terminal	
		BIT8: HDIB virtual terminal	
		0: 2-wire control 1	
P05.11	2/3-wire control mode	1: 2-wire control 2	0
1 00.11	2/0 wire control mode	2: 3-wire control 1	· ·
		3: 3-wire control 2	
<u>P05.12</u>	S1 terminal switch-on delay	0.000-50.000s	0.000s
<u>P05.13</u>	S1 terminal switch-off delay	0.000-50.000s	0.000s
<u>P05.14</u>	S2 terminal switch-on delay	0.000-50.000s	0.000s
<u>P05.15</u>	S2 terminal switch-off delay	0.000–50.000s	0.000s
<u>P05.16</u>	S3 terminal switch-on delay	0.000–50.000s	0.000s
P05.17	S3 terminal switch-off delay	0.000–50.000s	0.000s
P05.18	S4 terminal switch-on delay	0.000-50.000s	0.000s
<u>P05.19</u>	S4 terminal switch-off delay	0.000-50.000s	0.000s
<u>P05.20</u>	HDIA terminal switch-on delay	0.000-50.000s	0.000s
<u>P05.21</u>	HDIA terminal switch-off delay	0.000-50.000s	0.000s
P05.22	HDIB terminal switch-on delay	0.000–50.000s	0.000s
P05.23	HDIB terminal switch-off delay	0.000-50.000s	0.000s
<u>P07.39</u>	Input terminal state of present fault	0x0000-0xFFFF	0x0000
<u>P17.12</u>	Digital input terminal state	0x00-0x3F	0x00

# 5.5.12 Digital output

The VFD provides two groups of relay output terminals, one open collector Y output terminal and one high-speed pulse output (HDO) terminal. All the digital output terminal functions can be programmed by function codes, of which the high-speed pulse output terminal HDO can also be set to high-speed pulse output or digital output by function code.



The following table lists the function code options. A same output terminal function can be repeatedly selected.

Set value	Function	Description
0	Invalid	Output terminal has no function
1	In running	Output ON signal when there is frequency output during running
2	In forward running	Output ON signal when there is frequency output during forward running
3	In reverse running	Output ON signal when there is frequency output during reverse running
4	In jogging	Output ON signal when there is frequency output during jogging
5	VFD fault	Output ON signal when VFD fault occurred
6	Frequency level detection FDT1	Refer to P08.32 and P08.33
7	Frequency level detection FDT2	Refer to P08.34 and P08.35
8	Frequency reached	Refer to P08.36

Basic operation guidelines

Set value	Function	Description
9	Running in zero speed	Output ON signal when the VFD output frequency and reference frequency are both zero.
10	Reach upper limit frequency	Output ON signal when the running frequency reaches upper limit frequency
11	Reach lower limit frequency	Output ON signal when the running frequency reached lower limit frequency
12	Ready to run	Main circuit and control circuit powers are established, the protection functions do not act; when the VFD is ready to run, output ON signal.
13	In pre-exciting	Output ON signal during pre-exciting of the VFD
14	Overload pre-alarm	Output ON signal after the pre-alarm time elapsed based on the pre-alarm threshold; see P11.08–P11.10 for details.
15	Underload pre-alarm	Output ON signal after the pre-alarm time elapsed based on the pre-alarm threshold; see P11.11–P11.12 for details.
16	Simple PLC state completed	Output signal when current stage of simple PLC is completed
17	Simple PLC cycle completed	Output signal when a single cycle of simple PLC operation is completed
23	Virtual terminal output of Modbus/Modbus TCP communication	Output corresponding signal based on the set value of Modbus/Modbus TCP; output ON signal when it is set to 1, output OFF signal when it is set to 0
24	Virtual terminal output of POROFIBUS/CANopen/DeviceNet communication	Output corresponding signal based on the set value of POROFIBUS/CANopen/DeviceNet; output ON signal when it is set to 1, output OFF signal when it is set to 0
25	Virtual terminal output of Ethernet	Output corresponding signal based on the set value of Ethernet; output ON signal when it is set

Set value	Function	Description
	communication	to 1, output OFF signal when it is set to 0.
26	DC bus voltage established	Output is valid when the bus voltage is above the undervoltage threshold of the inverter
27	Z pulse output	Output is valid when the encoder Z pulse is arrived, and is invalid after 10 ms.
28	During pulse superposition	Output is valid when the pulse superposition terminal input function is valid
29	STO action	Output when STO fault occurred
30	Positioning completed	Output is valid when position control positioning is completed
31	Spindle zeroing completed	Output is valid when spindle zeroing is completed
32	Spindle scale-division completed	Output is valid when spindle scale-division is completed
33	In speed limit	Output is valid when the frequency is limited
34	Virtual terminal output of EtherCAT/PROFINET/ EtherNet IP communication	The corresponding signal is output according to the set value of PROFINET communication. When it is set to 1, the ON signal is output, and when it is set to 0, the OFF signal is output.
35	Reserved	
36	Speed/position control switchover completed	Output is valid when the mode switchover is completed
37	Any frequency reached	The frequency reached signal is output when the present ramp reference frequency is greater than the detection value for frequency being reached.
38–40	Reserved	
41	Y1	Y1 from the programmable card
42	Y2	Y2 from the programmable card

Set value	Function	Description
43	HDO	HDO from the programmable card
44	RO1	RO1 from the programmable card
45	RO2	RO2 from the programmable card
46	RO3	RO3 from the programmable card
47	RO4	RO4 from the programmable card
48	EC PT100 detected OH pre-alarm	Pre-alarm of overheating (OH) detected by the expansion card (EC) with PT100.
49	EC PT1000 detected OH pre-alarm	Pre-alarm of OH detected by the EC with PT1000.
50	AI/AO detected OH pre-alarm	Pre-alarm of OH detected by AI/AO.
51	Stopped or running at zero speed	The VFD is in stopped state or running at zero speed.
52	Disconnection detected in tension control	Disconnection is detected when the disconnection detection is enabled in tension control.
53	Roll diameter setting reached	The set roll diameter is reached during running in tension control.
54	Max. roll diameter reached	The max. roll diameter is reached during running in tension control.
55	Min. roll diameter reached	The min. roll diameter is reached during running in tension control.
56	Fire control mode enabled	The fire mode is turned on.
57–63	Reserved	

# Related parameter list:

Function code	Name	Description	Default
<u>P06.00</u>	HDO output type	O: Open collector high-speed pulse output     Spen collector output	0

Basic operation guidelines

Function code	Name	Description	Default
P06.01	Y1 output selection	0: Invalid	0
P06.02	HDO output selection	1: In running	0
P06.03	RO1 output selection	2: In forward running	1
		3: In reverse running	
		4: In jogging	
		5: VFD fault	
		6: Frequency level detection FDT1	
		7: Frequency level detection FDT2	
		8: Frequency reached	
		9: Running in zero speed	
		10: Reach upper limit frequency	
		11: Reach lower limit frequency	
		12: Ready to run	
		13: In pre-exciting	
		14: Overload pre-alarm	
		15: Underload pre-alarm	
		16: Simple PLC stage completed	
		17: Simple PLC cycle completed	
		18: Reach set counting value	
		19: Reach designated counting value	
P06.04	RO2 output selection	20: External fault is valid	5
		21: Reserved	
		22: Reach running time	
		23: Virtual terminal output of	
		Modbus/Modbus TCP communication	
		24: Virtual terminal output of	
		POROFIBUS/CANopen/DeviceNet	
		communication	
		25: Virtual terminal output of Ethernet	
		communication	
		26: DC bus voltage established	
		27: Z pulse output	
		28: During pulse superposition	
		29: STO action	
		30: Positioning completed	
		31: Spindle zeroing completed	
		32: Spindle scale-division completed	
		33: Speed limit reached in torque control	

Function code	Name	Description	Default
		34: Virtual terminal output of	
		EtherCAT/PROFINET/EtherNet IP	
		communication	
		35: Reserved	
		36: Speed/position control switchover	
		completed	
		37: Any frequency reached	
		38–40: Reserved	
		41: Y1 from the programmable card	
		42: Y2 from the programmable card	
		43: HDO from the programmable card	
		44: RO1 from the programmable card	
		45: RO2 from the programmable card	
		46: RO3 from the programmable card	
		47: RO4 from the programmable card	
		48: EC PT100 detected OH pre-alarm	
		49: EC PT1000 detected OH pre-alarm	
		50: Al/AO detected OH pre-alarm	
		51: Stopped or running at zero speed	
		52: Disconnection detected in tension	
		control	
		53: Roll diameter setting reached	
		54: Max. roll diameter reached	
		55: Min. roll diameter reached	
		56: Fire control mode enabled	
		57–63: Reserved	
P06.05	Output terminal polarity	0x00-0x0F	0x00
<u>F00.03</u>	selection	0x00-0x0F	0,000
P06.06	Y1 switch-on delay	0.000-50.000s	0.000s
P06.07	Y1 switch-off delay	0.000-50.000s	0.000s
P06.08	HDO switch-on delay	0.000–50.000s (valid only when <u>P06.00</u> =1)	0.000s
P06.09	HDO switch-off delay	0.000-50.000s (valid only when P06.00=1)	0.000s
P06.10	RO1 switch-on delay	0.000–50.000s	0.000s
P06.11	RO1 switch-off delay	0.000-50.000s	0.000s
P06.12	RO2 switch-on delay	0.000-50.000s	0.000s
P06.13	RO2 switch-off delay	0.000-50.000s	0.000s
P07.40	Output terminal status at		0


Function code	Name	Description	Default
	present fault		
P17.13	Digital output terminal		0
	status		0

# 5.5.13 Simple PLC

Simple PLC is a multi-step speed generator, and the VFD can change the running frequency and direction automatically based on the running time to fulfill process requirements. Previously, such function was realized with external PLC, while now, the VFD itself can achieve this function.

The VFD can realize 16-step speeds control, and provide four groups of acceleration/deceleration time for you to choose.

After the set PLC completes one cycle (or one segment), one ON signal can be output by the multifunction relay.



# Related parameter list:


Function code	Name	Description	Default
<u>P05.01</u> – <u>P</u> <u>05.06</u>	Digital input function selection	23: Simple PLC stop reset 24: Pause simple PLC 25: Pause PID control	
<u>P06.01</u> – <u>P</u> <u>06.04</u>	Digital output function selection	16: Simple PLC stage reached 17: Simple PLC cycle reached	
P10.00 Simple PLC mode		Stop after running once     Keep running in the final value after running once	0

Function code	Name	Description	Default
		2: Cyclic running	
D40.04	Simple PLC memory	0: No memory after power off	0
<u>P10.01</u>	selection	1: Memory after power off	0
P10.02	Multi-step speed 0	-300.0–300.0%	0.0%
P10.03	Running time of step 0	0.0-6553.5s (min)	0.0s
P10.04	Multi-step speed 1	-300.0–300.0%	0.0%
P10.05	Running time of step 1	0.0–6553.5s (min)	0.0s
P10.06	Multi-step speed 2	-300.0–300.0%	0.0%
P10.07	Running time of step 2	0.0-6553.5s (min)	0.0s
P10.08	Multi-step speed 3	-300.0–300.0%	0.0%
P10.09	Running time of step 3	0.0-6553.5s (min)	0.0s
P10.10	Multi-step speed 4	-300.0–300.0%	0.0%
P10.11	Running time of step 4	0.0-6553.5s (min)	0.0s
P10.12	Multi-step speed 5	-300.0–300.0%	0.0%
P10.13	Running time of step 5	0.0-6553.5s (min)	0.0s
P10.14	Multi-step speed 6	-300.0–300.0%	0.0%
P10.15	Running time of step 6	0.0–6553.5s (min)	0.0s
P10.16	Multi-step speed 7	-300.0–300.0%	0.0%
P10.17	Running time of step 7	0.0–6553.5s (min)	0.0s
P10.18	Multi-step speed 8	-300.0–300.0%	0.0%
P10.19	Running time of step 8	0.0-6553.5s (min)	0.0s
P10.20	Multi-step speed 9	-300.0–300.0%	0.0%
P10.21	Running time of step 9	0.0–6553.5s (min)	0.0s
P10.22	Multi-step speed 10	-300.0–300.0%	0.0%
P10.23	Running time of step 10	0.0–6553.5s (min)	0.0s
P10.24	Multi-step speed 11	-300.0–300.0%	0.0%
P10.25	Running time of step 11	0.0–6553.5s (min)	0.0s
P10.26	Multi-step speed 12	-300.0–300.0%	0.0%
P10.27	Running time of step 12	0.0-6553.5s (min)	0.0s
P10.28	Multi-step speed 13	-300.0–300.0%	0.0%
P10.29	Running time of step 13	0.0-6553.5s (min)	0.0s
P10.30	Multi-step speed 14	-100.0–100.0%	0.0%
P10.31	Running time of step 14	0.0–6553.5s (min)	0.0s
P10.32	Multi-step speed 15	-300.0–300.0%	0.0%
P10.33	Running time of step 15	0.0–6553.5s (min)	0.0s
P10.34	ACC/DEC time of steps 0–7	0x0000–0xFFFF	0x0000

Function code	Name	Description	Default
	of simple PLC		
<u>P10.35</u>	ACC/DEC time of steps 8–15 of simple PLC	0x0000-0xFFFF	0x0000
P10.36	PLC restart mode	Restart from step 1     Resume from the paused step	0
P17.00	Set frequency	0.00Hz-P00.03 (Max. output frequency)	0.00Hz
<u>P17.27</u>	Simple PLC and present stage number of multi-step speed	Displays the present stage of the simple PLC function.	0

# 5.5.14 Multi-step speed running

The VFD can set 16-step speeds, which are selectable by multi-step speed terminals 1-4, corresponding to multi-step speed 0 to multi-step speed 15.




# Related parameter list:

Function code	Name	Description	Default
		16: Multi-step speed terminal 1 17: Multi-step speed terminal 2	
P05.01–P05.06	Digital input function	18: Multi-step speed terminal 3	
<u> </u>	selection	19: Multi-step speed terminal 4	
		20: Pause multi-step speed	
P10.02	Multi stan an and O	running	0.0%
P10.02	Multi-step speed 0	-300.0–300.0%	0.0% 0.0s
	Running time of step 0	0.0–6553.5s (min)	
P10.04	Multi-step speed 1	-300.0–300.0%	0.0%
<u>P10.05</u>	Running time of step 1	0.0–6553.5s (min)	0.0s
<u>P10.06</u>	Multi-step speed 2	-300.0–300.0%	0.0%
P10.07	Running time of step 2	0.0-6553.5s (min)	0.0s
P10.08	Multi-step speed 3	-300.0–300.0%	0.0%
<u>P10.09</u>	Running time of step 3	0.0-6553.5s (min)	0.0s
<u>P10.10</u>	Multi-step speed 4	-300.0–300.0%	0.0%
<u>P10.11</u>	Running time of step 4	0.0–6553.5s (min)	0.0s
<u>P10.12</u>	Multi-step speed 5	-300.0–300.0%	0.0%
P10.13	Running time of step 5	0.0-6553.5s (min)	0.0s
<u>P10.14</u>	Multi-step speed 6	-300.0–300.0%	0.0%
<u>P10.15</u>	Running time of step 6	0.0-6553.5s (min)	0.0s
<u>P10.16</u>	Multi-step speed 7	-300.0–300.0%	0.0%
<u>P10.17</u>	Running time of step 7	0.0-6553.5s (min)	0.0s
<u>P10.18</u>	Multi-step speed 8	-300.0–300.0%	0.0%
<u>P10.19</u>	Running time of step 8	0.0-6553.5s (min)	0.0s
<u>P10.20</u>	Multi-step speed 9	-300.0–300.0%	0.0%
<u>P10.21</u>	Running time of step 9	0.0-6553.5s (min)	0.0s
<u>P10.22</u>	Multi-step speed 10	-300.0–300.0%	0.0%
P10.23	Running time of step 10	0.0-6553.5s (min)	0.0s
<u>P10.24</u>	Multi-step speed 11	-300.0–300.0%	0.0%
P10.25	Running time of step 11	0.0-6553.5s (min)	0.0s
P10.26	Multi-step speed 12	-300.0–300.0%	0.0%
P10.27	Running time of step 12	0.0-6553.5s (min)	0.0s

Function code	Name	Description	Default
P10.28	Multi-step speed 13	-300.0–300.0%	0.0%
P10.29	Running time of step 13	0.0-6553.5s (min)	0.0s
P10.30	Multi-step speed 14	-300.0–300.0%	0.0%
P10.31	Running time of step 14	0.0-6553.5s (min)	0.0s
<u>P10.32</u>	Multi-step speed 15	-300.0–300.0%	0.0%
P10.33	Running time of step 15	0.0-6553.5s (min)	0.0s
<u>P10.34</u>	ACC/DEC time of steps 0–7 of simple PLC	0x0000-0xFFFF	0x0000
ACC/DEC time of steps 8–15 of simple PLC		0x0000-0xFFFF	0x0000
<u>P17.27</u>	Simple PLC and present stage number of multi-step speed	Displays the present stage of the simple PLC function.	0

### 5.5.15 PID control

PID control, a common mode for process control, is mainly used to adjust the VFD output frequency or output voltage through performing scale-division, integral and differential operations on the difference between feedback signal of controlled variables and signal of the target, thus forming a negative feedback system to keep the controlled variables above the target. It is suitable for flow control, pressure control, temperature control, etc. Diagram of basic principles for output frequency regulation is shown in the figure below.



Introduction to the working principles and control methods for PID control

Proportional control (Kp): When the feedback is different from the reference, the output will be

proportional to the difference. If such a difference is constant, the regulating variable will also be constant. Proportional control can respond to feedback changes rapidly, however, it cannot eliminate the difference by itself. A larger proportional gain indicates a faster regulating speed, but a too large gain will result in oscillation. To solve this problem, set the integral time to a large value and the differential time to 0, run the system only with proportional control, and then change the reference to observe the difference (that is, static difference) between the feedback signal and reference. If the static difference occurs in the direction of reference change (such as reference increase, where the feedback is always less than the reference after system stabilizes), continue increasing the proportional gain; otherwise, decrease the proportional gain. Repeat this process until the static difference becomes small.

Integral time (Ti): When feedback deviates from reference, the output regulating variable accumulates continuously, if the deviation persists, the regulating variable will increase continuously until deviation disappears. Integral regulator can be used to eliminate static difference; however, too large regulation may lead to repetitive overshoot, which will cause system instability and oscillation. The feature of oscillation caused by strong integral effect is that the feedback signal fluctuates up and down based on the reference variable, and fluctuation range increases gradually until oscillation occurred. Integral time parameter is generally regulated gradually from large to small until the stabilized system speed fulfills the requirement.

Derivative time (Td): When the deviation between feedback and reference changes, output the regulating variable which is proportional to the deviation variation rate, and this regulating variable is only related to the direction and magnitude of the deviation variation rather than the direction and magnitude of the deviation itself. Differential control is used to control the feedback signal variation based on the variation trend. Differential regulator should be used with caution as it may easily enlarge the system interferences, especially those with high variation frequency.

When the frequency command selection ( $\underline{P00.06}$ ,  $\underline{P00.07}$ ) is 7 or the voltage setting channel selection ( $\underline{P04.27}$ ) is 6, the VFD is process PID controlled.

### 5.5.15.1 General procedures for PID parameter settings

### a. Determining proportional gain P

When determining proportional gain P, first, remove the integral term and derivative term of PID by making Ti=0 and Td=0 (see PID parameter setup for details), thus turning PID into pure proportional control. Set the input to 60%–70% of the max. allowable value, and increase proportional gain P gradually from 0 until system oscillation occurred, and then in turn, decrease proportional gain P gradually from current value until system oscillation disappears, record the proportional gain P at this point and set the proportional gain P of PID to 60%–70% of current value. This is whole commissioning process of proportional gain P.

#### b. Determine integral time Ti

After proportional gain P is determined, set the initial value of a larger integral time Ti, and decrease Ti gradually until system oscillation occurred, and then in turn, increase Ti until system oscillation

disappears, record the Ti at this point, and set the integral time constant Ti of PID to 150%–180% of current value. This is the commissioning process of integral time constant Ti.

### c. Determining derivative time Td

The derivative time Td is generally set to 0.


If you need to set Td to another value, set in the same way with P and Ti, namely set Td to 30% of the value when there is no oscillation.

 d. Empty system load, perform load-carrying joint debugging, and then fine-tune PID parameter until fulfilling the requirement.


### 5.5.15.2 PID adjusting methods

After setting the parameters controlled by PID, you can adjust these parameters by the following means.


Control overshoot: When overshoot occurred, shorten the derivative time (Td) and prolong integral time (Ti).




**Stabilize the feedback value as fast as possible:** when overshoot occurred, shorten integral time (Ti) and prolong derivative time (Td) to stabilize control as fast as possible.



**Control long-term vibration:** If the cycle of periodic vibration is longer than the set value of integral time (Ti), it indicates the integral action is too strong, prolong the integral time (Ti) to control vibration.



**Control short-term vibration**: If the vibration cycle is short is almost the same with the set value of derivative time (Td), it indicates derivative action is too strong, shorten the derivative time (Td) to control vibration. When derivative time (Td) is set to 0.00 (namely no derivative control), and there is no way to control vibration, decrease the proportional gain.



### Related parameter list:

Function code	Name	Description	Default
<u>P09.00</u>	PID reference source	0: Set by P09.01 1: Al1 2: Al2 3: Al3 4: High-speed pulse HDIA 5: Multi-step running 6: Modbus/Modbus TCP communication 7: PROFIBUS/CANopen/DevicneNET communication 8: Ethernet communication 9: High-speed pulse HDIB communication 10: EtherCAT/PROFINET/EtherNet IP communication 11: Programmable card	0


Function code	Name	Description	Default
		12: Reserved	
P09.01	PID digital setting	-100.0%–100.0%	0.0%
P09.02	PID feedback source	0: Al1 1: Al2 2: Al3 3: High-speed pulse HDIA 4: Modbus/Modbus TCP communication 5: PROFIBUS/CANopen/DevicneNET communication 6: Ethernet communication 7: High-speed pulse HDIB 8: EtherCAT/PROFINET/EtherNet IP communication 9: Programmable card 10: Reserved	0
<u>P09.03</u>	PID output characteristics selection	PID output is positive characteristic     PID output is negative characteristic	0
<u>P09.04</u>	Proportional gain (Kp)	0.00–100.00	1.80
P09.05	Integral time (Ti)	0.01-10.00s	0.90s
P09.06	Differential time (Td)	0.00-10.00s	0.00s
P09.07	Sampling period (T)	0.000-10.000s	0.100s
P09.08	PID control deviation limit	0.0–100.0%	0.0%
P09.09	PID output upper limit	P09.10-100.0% (max. frequency or voltage)	100.0%
<u>P09.10</u>	PID output lower	-100.0%– <u>P09.09</u> (max. frequency or voltage)	0.0%
P09.11	Feedback offline detection value	0.0–100.0%	0.0%
P09.12	Feedback offline detection time	0.0–3600.0s	1.0s
<u>P09.13</u>	PID control selection	0x0000–0x1111 Ones place: 0: Continue integral control after the frequency	0x0001

Function code	Name	Description	Default
		reaches upper/lower limit	
		1: Stop integral control after the frequency	
		reaches upper/lower limit	
		Tens place:	
		0: The same with the main reference direction	
		1: Contrary to the main reference direction	
		Hundreds place:	
		0: Limit as per the max. frequency	
		1: Limit as per A frequency	
		Thousands place:	
		0: A+B frequency, acceleration /deceleration of	
		main reference A frequency source buffering is	
		invalid	
		1: A+B frequency, acceleration/ deceleration of	
		main reference A frequency source buffering is	
		valid, acceleration/deceleration is determined by	
		P08.04 (acceleration time 4).	
	Low frequency		
P09.14	proportional gain	0.00-100.00	1.00
	(Kp)		
P09.15	ACC/DEC time of	0.0–1000.0s	0.0s
1 00.10	PID command		0.08
P09.16	PID output filter time	0.000–10.000s	0.000s
P09.17	Reserved		
D00.40	Low frequency	0.00.40.00-	0.00-
P09.18	integral time (Ti)	0.00–10.00s	0.90s
D00.40	Low frequency	0.00, 40.005	0.00=
P09.19	differential time (Td)	0.00–10.00s	0.00s
	Low frequency point		
P09.20	for PID parameter	0.00-P09.21	5.00Hz
	switching		
	High frequency		
P09.21	point for PID	P09.20–P00.04	10.00Hz
	parameter switching		
<u>P17.00</u>	Set frequency	0.00Hz-P00.03 (Max. output frequency)	0.00Hz
P17.23	PID reference value	-100.0–100.0%	0.0%

Function code	Name	Description	Default
P17.24	PID feedback value	-100.0–100.0%	0.0%

# 5.5.16 Running at wobbling frequency

Wobbling frequency is mainly applied in cases where transverse movement and winding functions are needed like textile and chemical fiber industries. The typical working process is shown as below.



Function code	Name	Description	Default
P00.03	Max. output frequency	<u>P00.03</u> –400.00Hz	50.00Hz
P00.06	Setting channel of A frequency command	0: Keypad 1: Al1 2: Al2 3: Al3 4: High-speed pulse HDIA 5: Simple PLC program 6: Multi-step speed running 7: PID control 8: Modbus/Modbus TCP communication 9: PROFIBUS/CANopen/DeviceNet communication 10: Ethernet communication 11: High-speed pulse HDIB 12: Pulse train AB 13: EtherCAT/PROFINET/EtherNet IP communication 14: Programmable card	0

Function code	Name	Description	Default
<u>P00.11</u>	ACC time 1	0.0–3600.0s	Model depended
<u>P00.12</u>	DEC time 1	0.0–3600.0s	Model depended
<u>P05.01</u> – <u>P</u> <u>05.06</u>	Digital input function selection	26: Wobbling frequency pause (stop at current frequency) 27: Wobbling frequency reset (revert to center frequency)	
<u>P08.15</u>	Amplitude of wobbling frequency	0.0-100.0% (relative to set frequency)	0.0%
<u>P08.16</u>	Amplitude of jump frequency	0.0–50.0% (relative to amplitude of wobbling frequency)	0.0%
<u>P08.17</u>	Wobbling frequency rise time	0.1–3600.0s	5.0s
P08.18	Wobbling frequency fall time	0.1–3600.0s	5.0s

# 5.5.17 Local encoder input

The VFD supports pulse count function by inputting the count pulse from HDI high-speed pulse port. When the actual count value is no less than the set value, digital output terminal will output count-value-reached pulse signal, and the corresponding count value will be zeroed out.

Function code	Name	Description	Default
<u>P05.00</u>	HDI input type	0x00–0x11 Ones: HDIA input type 0: HDIA is high-speed pulse input 1: HDIA is digital input Tens: HDIB input type 0: HDIB is high-speed pulse input	0x00
<u>P05.38</u>	HDIA high-speed pulse input function	1: HDIB is digital input  0: Set input via frequency  1: Reserved  2: Input via encoder, used in combination with HDIB	0
<u>P05.44</u>	HDIB high-speed pulse input function selection	Set input via frequency     Reserved     Input via encoder, used in combination with HDIA	0

Function code	Name	Description	Default
P18.00	Actual frequency of encoder	-999.9–3276.7Hz	0.0Hz
<u>P20.15</u>	Speed measurement mode	0: PG card 1: Local; realized by HDIA and HDIB; supports incremental 24V encoder only	0

5.5.18 Commissioning procedures for closed-loop control, position control and spindle positioning

### 1. Commissioning procedures for closed-loop vector control of asynchronous motor

Step 1: Restore to default value via keypad

Step 2: Set P00.03, P00.04 and P02 group motor nameplate parameters

Step 3: Motor parameter autotuning

Carry out rotary parameter autotuning or static parameter autotuning via keypad, if the motor can be disconnected from load, then it is users can carry out rotary parameter autotuning; otherwise, carry out static parameter autotuning, the parameter obtained from autotuning will be saved in P02 motor parameter group automatically.

Step 4: Verify whether the encoder is installed and set properly

a) Confirm the encoder direction and parameter setup

Set <u>P20.01</u> (encoder pulse-per-revolution), set <u>P00.00</u>=2 and <u>P00.10</u>=20.00Hz, and run the VFD, at this point, the motor rotates at 20.00Hz, observe whether the speed measurement value of <u>P18.00</u> is correct, if the value is negative, it indicates the encoder direction is reversed, under such situation, set <u>P20.02</u> to 1; if the speed measurement value deviates greatly, it indicates <u>P20.01</u> is set improperly. Observe whether <u>P18.02</u> (encoder Z pulse count value) fluctuates, if yes, it indicates the encoder suffers interference or <u>P20.01</u> is set improperly, requiring users to check the wiring and the shielding layer.

### b) Determine Z pulse direction

Set  $\underline{P00.10}$ =20.00Hz, and set  $\underline{P00.13}$  (running direction) to forward and reverse direction respectively to observe whether the difference value of  $\underline{P18.02}$  is less than 5, if the difference value remains to be larger than 5 after setting Z pulse reversal function of  $\underline{P20.02}$ , power off and exchange phase A and phase B of the encoder, and then observe the difference between the value of  $\underline{P18.02}$  during forward and reverse rotation. Z pulse direction only affects the forward/reverse positioning precision of the spindle positioning carried out with Z pulse.

Step 5: Closed-loop vector pilot-run

Set P00.00=3, and carry out closed-loop vector control, adjust P00.10 and speed loop and current

loop PI parameter in P03 group to make it run stably in the whole range.

Step 6: Flux-weakening control

Set flux-weakening regulator gain P03.26=0-8000, and observe the flux-weakening control effect. P03.22-P03.24 can be adjusted as needed.

### 2. Commissioning procedures for closed-loop vector control of synchronous motor

Step 1: Set P00.18=1, restore to default value

Step 2: Set P00.00=3 (FVC), set P00.03, P00.04, and motor nameplate parameters in P02 group.

Step 3: Set P20.01 encoder parameter.

When the encoder is resolver-type encoder, set the encoder pulse count value to (resolver pole pair number x 1024), e.g., if pole pair number is 4, set P20.01 to 4096.

Step 4: Ensure the encoder is installed and set correctly

When motor stops, observe whether <u>P18.21</u> (resolver angle) fluctuates, if it fluctuates sharply, check the wiring and grounding. Rotates the motor slowly, observe whether <u>P18.21</u> changes accordingly. If yes, it indicates motor is connected correctly; if the value of <u>P18.02</u> keeps constant at a non-zero value after rotating for multiple circles, it indicates encoder Z signal is correct.

Step 5: Autotuning of initial position of magnetic pole

Set P20.11=2 or 3 (3: rotary autotuning; 2: static autotuning), press RUN key to run the VFD.

a) Rotary autotuning ( $\underline{P20.11} = 3$ )

Detect the position of current magnetic pole when autotuning starts, and then accelerates to 10Hz, autotuning corresponding magnetic pole position of encoder Z pulse, and decelerate to stop.

During running, if ENC1o or ENC1d fault occurred, set P20.02=1 and carry out autotuning again.

After autotuning is done, the angle obtained from autotuning will be saved in <u>P20.09</u> and <u>P20.10</u> automatically.

# b) Static autotuning

In cases where the load can be disconnected, it is recommended to adopt rotary autotuning (P20.11=3) as it has high angle precision. If the load cannot be disconnected, users can adopt static autotuning (P20.11=2). The magnetic pole position obtained from autotuning will be saved in P20.09 and P20.10.

Step 6: Closed-loop vector pilot-run

Adjust <u>P00.10</u> and speed loop and current loop PI parameter in P03 group to make it run stably in the whole range. If oscillation occurred, reduce the value of <u>P03.00</u>, <u>P03.03</u>, <u>P03.09</u> and <u>P03.10</u>. If current oscillation noise occurred during low speed, adjust P20.05.

Note: It is necessary to re-determine P20.02 (encoder direction) and carry out magnetic pole position

autotuning again if the wiring of motor or encoder is changed.

### 3. Commissioning procedures for pulse train control

Pulse input is operated based on closed-loop vector control; speed detection is needed in the subsequent spindle positioning, zeroing operation and division operation.

- Step 1: Restore to default value by keypad
- Step 2: Set P00.03, P00.04 and motor nameplate parameters in P02 group
- Step 3: Motor parameter autotuning: rotary parameter autotuning or static parameter autotuning
- Step 4: Verity the installation and settings of encoder. Set <u>P00.00</u>=3 and <u>P00.10</u>=20.00Hz to run the system, and check the control effect and performance of the system.
- Step 5: Set <u>P21.00</u>=0001 to set positioning mode to position control, namely pulse-string control. There are four kinds of pulse command modes, which can be set by <u>P21.01</u> (pulse command mode).

Under position control mode, you can check high-order bit and low-order bit of position reference and feedback, <u>P18.02</u> (count value of Z pulse), <u>P18.00</u> (actual frequency of encoder), <u>P18.17</u> (pulse command frequency) and <u>P18.19</u> (position regulator output) via P18, through which users can figure out the relation between <u>P18.08</u> (position of position reference point) and P18.02, pulse command frequency <u>P18.17</u>, feedforward <u>P18.18</u> and position regulator output <u>P18.19</u>.

Step 6: The position regulator has two gains, namely <u>P21.02</u> and <u>P21.03</u>, and they can be switched by speed command, torque command and terminals.


Step 7: When P21.08 (output limit of position controller) is set to 0, the position control will be invalid, and at this point, the pulse train acts as frequency source, P21.13 (position feedforward gain) should be set to 100%, and the speed acceleration/deceleration time is determined by the acceleration /deceleration time of pulse train, the pulse train acceleration/deceleration time of the system can be adjusted. If the pulse train acts as the frequency source in speed control, users can also set P21.00 to 0000, and set the frequency source reference P00.06 or P00.07 to 12 (set by pulse train AB), at this point, the acceleration/deceleration time is determined by the acceleration/deceleration time of the VFD, meanwhile, the parameters of pulse train AB is still set by P21 group. In speed mode, the filter time of pulse train AB is determined by P21.29.

Step 8: The input frequency of pulse train is the same with the feedback frequency of encoder pulse, the relation between them can be changed by altering <u>P21.11</u> (numerator of position command ratio) and <u>P21.12</u> (denominator of position command ratio)

Step 9: When running command or servo enabling is valid (by setting <u>P21.00</u> or terminal function 63), it will enter pulse train servo running mode.

### 4. Commissioning procedures for spindle positioning

Spindle orientation is to realize orientation functions like zeroing and division based on closed-loop vector control



Step 1–4: These four steps are the same with the first four steps of the commissioning procedures for closed-loop vector control, which aim to fulfill the control requirements of closed-loop vector control, thus realizing spindle positioning function in either position control or speed control mode.

Step 5: Set <u>P22.00</u>.bit0=1 to enable spindle positioning, set <u>P22.00</u>.bit1 to select spindle zero input. If the system adopts encoder for speed measurement, set <u>P22.00</u>.bit1 to 0 to select Z pulse input; if the system adopts photoelectric switch for speed measurement, set <u>P22.00</u>.bit1 to 1 to select photoelectric switch as zero input; set <u>P22.00</u>.bit2 to select zero search mode, set <u>P22.00</u>.bit3 to enable or disable zero calibration, and select zero calibration mode by setting P22.00.bit7.

### Step 6: Spindle zeroing operation

- a) Select the positioning direction by setting P22.00.bit4.
- b) There are four zero positions in P22 group, users can choose one out of four zeroing positions by setting zeroing input terminal selection (46, 47) in P05 group. When executing zeroing function, the motor will stop accurately at corresponding zeroing position according to the set positioning direction, which can be viewed via <u>P18.10</u>.
- c) The positioning length of spindle zeroing is determined by the deceleration time of accurate-stop and the speed of accurate-stop.

#### Step 7: Spindle division operation

There are seven scale-division positions in P22 group, users can choose one out of seven scale-division positions by setting scale-division input terminal selection (48, 49, 50) in P05 group.

Enable corresponding scale-division terminal after the motor stops accurately, and the motor will check the scale-division position state and switch to corresponding position incrementally, at this point, users can check P18.09.

Step 8: Priority level of speed control, position control and zeroing

The priority level of speed running is higher than that of the scale division, when the system runs in scale-division mode, if spindle orientation is prohibited, the motor will turn to speed mode or position mode.

The priority level of zeroing is higher than that of the scale division.

Scale-division command is valid when the scale-division terminal is from 000 state to non-000 state, e.g., in 000–011, the spindle executes scale division 3. The transition time during terminal switchover needs to be less than 10ms; otherwise, wrong scale division command may be executed.

Step 9: Hold positioning

The position loop gain during positioning is <u>P21.03</u>; while the position loop gain in positioning-completion-hold state is <u>P21.02</u>. In order to keep sufficient position-hold force and ensure no system oscillation occurred, adjust <u>P03.00</u>, <u>P03.01</u>, <u>P20.05</u>, and <u>P21.02</u>.

Step 10: Positioning command selection (bit6 of P22.00)

Electric level signal: Positioning command (zeroing and scale division) can be executed only when there is running command or the servo is enabled.

Step 11: Spindle reference point selection (bit0 of P22.00)

Encoder Z pulse positioning supports the following spindle positioning modes:

- a) The encoder is installed on the motor shaft, the motor shaft and spindle is 1:1 rigid connection:
- b) The encoder is installed on the motor shaft, the motor shaft and spindle is 1:1 belt connection;

At this point, the belt may slip during high-speed running and cause inaccurate positioning, it is recommended to install proximity switch on the spindle.

c) The encoder is installed on the spindle, and the motor shaft is connected to the spindle with belt, the drive ratio is not necessarily 1:1.

At this point, set <u>P20.06</u> (speed ratio of the mounting shaft between motor and encoder), and set <u>P22.14</u> (spindle drive ratio) to 1. As the encoder is not installed on the motor, the control performance of closed-loop vector will be affected.


Proximity switch positioning supports the following spindle positioning modes:

a) The encoder is installed on the motor shaft, the drive ratio between motor shaft and spindle is not necessarily 1:1;

At this point, it is required to set P22.14 (spindle drive ratio).

# 5. Commissioning procedures for digital positioning

The diagram for digital positioning is shown below.



P21.25 Hold time of positioning completion signal

Step 1–4: These four steps are the same with the first four steps of the commissioning procedures for closed-loop vector control, which aim to fulfill the control requirements of closed-loop vector control.

Step 5: Set <u>P21.00</u>=0011 to enable digital positioning. Set <u>P21.17</u>, <u>P21.11</u> and <u>P21.12</u> (set positioning displacement) according to actual needs; set <u>P21.18</u> and <u>P21.19</u> (set positioning speed); set <u>P21.20</u> and <u>P21.21</u> (set acceleration/deceleration time of positioning).

Step 6: Single positioning operation


Set <u>P21.16</u>.bit1=0, and the motor will carry out single positioning action and stay in the positioning position according to the setup in step 5.

Step 7: Cyclic positioning operation

Set <u>P21.16</u>.bit1=1 to enable cyclic positioning. The cyclic positioning is divided into continuous mode and repetitive mode; users can also carry out cyclic positioning through terminal function (no. 55, enable digital positioning cycle)

### 6. Commissioning procedures for positioning of photoelectric switch

Photoelectric switch positioning is to realize positioning function based on closed-loop vector control.



Step 1—4: These four steps are the same with the first four steps of the commissioning procedures for closed-loop vector control, which aim to fulfill the control requirements of closed-loop vector control.

Step 5: Set <u>P21.00</u>=0021 to enable photoelectric switch positioning, the photoelectric switch signal can be connected to S8 terminal only, and set <u>P05.08</u>=43, meanwhile, set <u>P21.17</u>, <u>P21.11</u> and <u>P21.12</u> (set positioning displacement) based on actual needs; set <u>P21.21</u> (deceleration time of positioning), however, when present running speed is too fast or the set positioning displacement is too small, the deceleration time of positioning will be invalid, and it will enter direct deceleration positioning mode.

#### Step 6: Cyclic positioning


After positioning is done, the motor will stay in current position. Users can set cyclic positioning through input terminal function selection (55: enable cyclic digital positioning) in P05 group; when the terminal receives cyclic positioning enable signal (pulse signal), the motor will continue running in the set speed as per the speed mode and re-enter positioning state after encountering photoelectric switch.

### (7) Hold positioning

The position loop gain during positioning is <u>P21.03</u>; while the position loop gain in positioning-completion-hold state is <u>P21.02</u>. In order to keep sufficient position-hold force and ensure no system oscillation occurred, adjust P03.00, P03.01, P20.05, and P21.02.

### 5.5.19 Fault handling

The following provides fault handling information.



# Related parameter list:

Function code	Name	Description	Default
P07.27	Present fault type	0: No fault	0
P07.28	Last fault type	1: Inverter unit U phase protection (OUt1)	0
P07.29	2nd-last fault type	2: Inverter unit V phase protection (OUt2)	0
P07.30	3rd-last fault type	3: Inverter unit W phase protection (OUt3)	0
P07.31	4th-last fault type	4: Overcurrent during acceleration (OC1)	0
		5: Overcurrent during deceleration (OC2)	
		6: Overcurrent during constant speed (OC3)	
		7: Overvoltage during acceleration (OV1)	
		8: Overvoltage during deceleration (OV2)	
		9: Overvoltage during constant speed (OV3)	
	5th-last fault type	10: Bus undervoltage fault (UV)	
D07.00		11: Motor overload (OL1)	0
P07.32		12: VFD overload (OL2)	0
		13: Phase loss on input side (SPI)	
		14: Phase loss on output side (SPO)	
		15: Rectifier module overheat (OH1)	
		16: Inverter module overheat (OH2)	
		17: External fault (EF)	
		18: Modbus/Modbus TCP communication	

Function code	Name	Description	Default
		fault (CE)	
		19: Current detection fault (ItE)	
		20: Motor autotuning fault (tE)	
		21: EEPROM operation fault (EEP)	
		22: PID feedback offline fault (PIDE)	
		23: Braking unit fault (bCE)	
		24: Running time reached (END)	
		25: Electronic overload (OL3)	
		26: Keypad communication error (PCE)	
		27: Parameter upload error (UPE)	
		28: Parameter download error (DNE)	
		29: PROFIBUS communication fault (E-DP)	
		30: Ethernet communication fault (E-NET)	
		31: CANopen communication fault (E-CAN)	
		32: To-ground short-circuit fault 1 (ETH1)	
		33: To-ground short-circuit fault 2 (ETH2)	
		34: Speed deviation fault (dEu)	
		35: Maladjustment fault (STo)	
		36: Underload fault (LL)	
		37: Encoder offline fault (ENC1o)	
		38: Encoder reversal fault (ENC1d)	
		39: Encoder Z pulse offline fault (ENC1Z)	
		40: Safe torque off (STO)	
		41: Channel H1 safety circuit exception	
		(STL1)	
		42: Channel H2 safety circuit exception	
		(STL2)	
		43: Channel H1 and H2 exception (STL3)	
		44: Safety code FLASH CRC fault (CrCE)	
		45: Programmable card customized fault 1	
		(P-E1)	
		46: Programmable card customized fault 2	
		(P-E2)	
		47: Programmable card customized fault 3	
		(P-E3)	
		48: Programmable card customized fault 4	
		(P-E4)	
		49: Programmable card customized fault 5	

Function code	Name	Description	Default
		(P-E5)	
		50: Programmable card customized fault 6	
		(P-E6)	
		51: Programmable card customized fault 7	
		(P-E7)	
		52: Programmable card customized fault 8	
		(P-E8)	
		53: Programmable card customized fault 9	
		(P-E9)	
		54: Programmable card customized fault 10	
		(P-E10)	
		55: Duplicate card type(E-Err)	
		56: Encoder UVW loss fault (ENCUV)	
		57: PROFIBUS communication fault (E-PN)	
		58: CANopen communication fault (SECAN)	
		59: Motor over-temperature fault (OT)	
		60: Failure to identify the card at slot 1	
		(F1-Er)	
		61: Failure to identify the card at slot 2	
		(F2-Er)	
		62: Failure to identify the card at slot 3	
		(F3-Er)	
		63: Communication timeout of the card at	
		slot 1 (C1-Er)	
		64: Communication timeout of the card at	
		slot 2 (C2-Er)	
		65: Communication timeout of the card at	
		slot 3 (C3-Er)	
		66: EtherCAT communication fault (E-CAT)	
		67: Bacnet communication fault (E-BAC)	
		68: DeviceNet communication fault (E-DEV)	
		69: CAN slave fault in master/slave	
		synchronization (S-Err)	
		70: EC PT100 detected overheating (OtE1)	
		71: EC PT1000 detected overheating (OtE2)	
		72: EtherNet/IP communication timeout	
		(E-EIP)	
		73: No upgrade bootload (E-PAO)	

Function code	Name	Description	Default
		74: Al1 disconnected (E-Al1) 75: Al2 disconnected (E-Al2) 76: Al3 disconnected (E-Al3)	
<u>P07.33</u>	Running frequency at present fault	0.00Hz-P00.03	0.00Hz
<u>P07.34</u>	Ramp reference frequency at present fault	0.00Hz-P00.03	0.00Hz
<u>P07.35</u>	Output current at present fault	0–1200V	0V
<u>P07.36</u>	Output current at present fault	0.0-6300.0A	0.0A
<u>P07.37</u>	Bus voltage at present fault	0.0–2000.0V	0.0V
<u>P07.38</u>	Max. temperature at present fault	-20.0–120.0°C	0.0°C
<u>P07.39</u>	Input terminal status at present fault	0x0000-0xFFFF	0
<u>P07.40</u>	Output terminal status at present fault	0x0000-0xFFFF	0
P07.41	Running frequency at last fault	0.00Hz-P00.03	0.00Hz
<u>P07.42</u>	Ramp reference frequency at last fault	0.00Hz-P00.03	0.00Hz
<u>P07.43</u>	Output voltage at last fault	0–1200V	0V
<u>P07.44</u>	Output current at last fault	0.0-6300.0A	0.0A
<u>P07.45</u>	Bus voltage at last fault	0.0–2000.0V	0.0V
<u>P07.46</u>	Max. temperature at last fault	-20.0–120.0°C	0.0°C
<u>P07.47</u>	Input terminal status at last fault	0x0000-0xFFFF	0
<u>P07.48</u>	Output terminal status at last fault	0x0000-0xFFFF	0
P07.49	Running frequency at	0.00Hz-P00.03	0.00Hz


Function code	Name	Description	Default
	2nd-last fault		
	Ramp reference		0.00Hz
<u>P07.50</u>	frequency at 2nd-last	0.00Hz-P00.03	
	fault		
<u>P07.51</u>	Output voltage at	0–1200V	0V
	2nd-last fault	0-12007	
<u>P07.52</u>	Output current at	0.0-6300.0A	0.0A
	2nd-last fault	0.0-0000.07	
<u>P07.53</u>	Bus voltage at 2nd-last	0.0–2000.0V	0.0V
	fault	0.0 2000.00	
<u>P07.54</u>	Max temperature at	-20.0–120.0°C	0.0°C
	2nd-last fault	20.0 120.0 0	
<u>P07.55</u>	Input terminal status at	0x0000-0xFFFF	0x0000
	2nd-last fault	0.0000-0.1111	
<u>P07.56</u>	Output terminal status at	0x0000_0xFFFF	0x0000
	2nd-last fault	0x0000-0x1111	


### 5.5.20 Tension control solutions

In many fields of industrial production, precise tension control is needed to maintain a constant output tension of the drive equipment, in order to improve the quality of the products. In the winding and unwinding of some industries such as paper processing, printing and dyeing, packing, wire and cable manufacturing, textile, fiber, optic cable, leather, metal foil material processing and so on, tension needs to keep constant.


The VFD controls the tension by regulating the motor output torque or speed. There are three modes to control the tension: speed mode, open-loop torque mode and closed-loop torque mode.

# 5.5.20.1 Typical tension control applications for winding/unwinding






In some special situations, if the roll diameter can be counted through thickness, the following applications can be implemented:



### 5.5.20.2 Speed control

The detection feedback signal is needed in the closed-loop adjustment. PID calculation is carried out according to the feedback signal for the motor speed regulation, linear speed and stable tension control. If the tension rocker or floating roller is used for feedback, changing the set value (PID reference) may change the actual tension, and at the same time, changing the mechanical configuration such as the tension rocker or floating roller weight can also change the tension.

The control principle is as follows.



### Related modules:


- (1) Linear speed input module: It is important for the calculation of the basic setting frequency according to the linear speed and the calculation of roll diameter according to the linear speed.
- (2) Real-time roll diameter calculation module: The calculation accuracy of roll diameter determines the control performance. The roll diameter can be calculated according to the VFD output frequency and the linear speed. In addition, it can also be calculated through the thickness or sensor. The linear speed is widely used for the calculation. If the set linear speed is used for the calculation, you you choose whether to enable the function of roll diameter change limiting.
- (3) PID regulation module: There are two groups of PID parameters in P09. The linear speed synchronization and stable tension can be kept through PID regulation. PID parameters can be modified based on site commissioning. The two groups of PID parameters can be switched for PID

regulation improvement.

- (4) Material feeding interrupt detection and processing module: The function is valid when material feeding interrupt detection has been enabled.
- (5) Pre-drive: This function is applied to automatic reel change. After the VFD is started if the pre-drive function terminal is valid, the roller runs at the set linear speed. If the terminal is invalid, the VFD will automatically switch to the corresponding control mode after a period of time.

# 5.5.20.3 Open-loop torque mode

Open loop means there is no tension feedback signal. In this mode, stable tension can be achieved by means of motor torque control. The rotation speed automatically changes with the linear speed of material. The control basis is as follows: For a reel control system, the relationship between the tension F of the roller with materials, present roll diameter D and output torque of the shaft is:  $T = F \times D/2$ . If the output torque can be adjusted according to the variation of roll diameter, the tension can be controlled. In order to ensure the constant tension in the process of acceleration and deceleration, the internal friction compensation module and inertia compensation module have been built in the VFD to calculate the real time rotation inertia, and compensate the torque according to the actual speed change rate. The control principle is shown in the following figure.



### Relevant modes:


- (1) Linear speed input module: It has two functions: calculating the synchronous frequency in torque control according to the linear speed, and calculating the roll diameter according to the linear speed.
- (2) Tension setting module: Used to set the tension adapting to the control system. It needs to be adjusted according to the actual situation. After confirmation, the value remains the same. In some scenarios where the forming effect after winding needs to be improved, the tension taper function can be used so that the tension decreases as the roll diamter increases.
- (3) Real-time roll diameter calculation module: The calculation accuracy of roll diameter determines the control performance. The roll diameter can be calculated according to the VFD output frequency and the linear speed. In addition, it can also be calculated through the thickness or sensor. The linear speed is widely used for the calculation. If the set linear speed is used for the calculation, you you choose whether to enable the function of roll diameter change limiting.
- (4) Torque compensation module: Torque compensation includes friction torque compensation and

inertia torque compensation. Friction torque compensation is used to eliminate the impact of friction on tension, and it needs to be adjusted according to actual requirements. rRotation inertia includes inertial of mechanical systems and that of materials. In order to keep the tension stable in ACC/DEC, compensation torque is required. In some cases without strict tension control requirements, disabling rotation inertia torque compensation can also achieve the control.

- (5) Material feeding interrupt detection and processing module: The function is valid when material feeding interrupt detection has been enabled.
- (6) This function is applied to automatic reel change. After the VFD is started if the pre-drive function terminal is valid, the roller runs at the set linear speed. If the terminal is invalid, the VFD will automatically switch to the corresponding control mode after a period of time.

### 5.5.20.4 Closed-loop torque mode

Similar to the open-loop torque mode, the closed-loop torque mode has only the difference that tension detection sensors are installed on the winding/unwinding side. In addition to all the function modules supported in open-loop torque mode, this mode supports an additional tension feedback PID closed-loop regulation module. The control principle is shown in the following figure.



# 6 Function parameter list

# 6.1 What this chapter contains

This chapter lists all the function codes and corresponding description of each function code.

# 6.2 Function parameter list

The function parameters of the VFD are divided into groups by function. Among the function parameter groups, the P98 group is the analog input and output calibration group, while the P99 group contains the factory function parameters, which are user inaccessible. Each group includes several function codes (each function code identifies a function parameter). A three-level menu style is applied to function codes. For example, "P08.08" indicates the 8th function code in the P08 group.

The function group numbers correspond to the level-1 menus, the function codes correspond to the level-2 menus, and the function parameters correspond to the level-3 menus.

1. The content of the function code table is as follows:

Column 1 "Function code ": Code of the function group and parameter

Column 2 "Name": Full name of the function parameter

Column 3 "Description": Detailed description of the function parameter

Column 4 "Default": Initial value set in factory

Column 5 "Modify": Whether the function parameter can be modified, and conditions for the modification

"O" indicates that the value of the parameter can be modified when the VFD is in stopped or running state.

"©" indicates that the value of the parameter cannot be modified when the VFD is in running state.

"O" indicates that the value of the parameter is detected and recorded, and cannot be modified.

(The VFD automatically checks and constrains the modification of parameters, which helps prevent incorrect modifications.)

- 2. The parameters adopt the decimal system (DEC). If the hexadecimal system is adopted, all bits are mutually independent on data during parameter editing, and the setting ranges at some bits can be hexadecimal (0–F).
- 3. "Default" indicates the factory setting of the function parameter. If the value of the parameter is detected or recorded, the value cannot be restored to the factory setting.
- 4. To better protect parameters, the VFD provides the password protection function. After a password is set (that is, <u>P07.00</u> is set to a non-zero value), "[].[].[].[].[].[].[].[] is displayed when you press the <u>PRG/ESC</u> key to enter the function code editing interface. You need to enter the correct user password to enter the interface. For the factory parameters, you need to enter the correct factory

password to enter the interface. (You are not advised to modify the factory parameters. Incorrect parameter setting may cause operation exceptions or even damage to the VFD.) If password protection is not in locked state, you can change the password any time. You can set <u>P07.00</u> to 0 to cancel the user password. When <u>P07.00</u> is set to a non-zero value during power-on, parameters are prevented from being modified by using the user password function. When you modify function parameters through serial communication, the user password protection function is also applicable and compliant with the same rule.

### P00—Basic functions

Function code	Name	Description	Default	Modify
P00.00	Speed control mode	0: Sensorless vector control (SVC) mode 0 1: Sensorless vector control (SVC) mode 1 2: Space voltage vector control mode 3: FVC  Note: To select 0, 1, or 3 as the control mode, enable the VFD to perform motor parameter autotuning first.	2	0
P00.01	Channel of running commands	0: Keypad 1: Terminal 2: Communication	0	0
P00.02	Communication mode of running commands	O: Modbus/Modbus TCP  1: PROFIBUS/CANopen/DeviceNet  2: Ethernet  3: EtherCAT/PROFINET/EtherNet IP  4: Programmable card  5: Wireless communication card  Note: The options 1, 2, 3, 4, and 5 are add-on functions and are available only when corresponding expansion cards are configured.	0	0
P00.03	Max. output frequency	Used to set the max. output frequency of the VFD. Pay attention to the function code because it is the foundation of the frequency setting and the speed of acceleration (ACC) and deceleration (DEC) Setting range: Max (P00.04, 10.00)–400.00Hz	50.00Hz	0
P00.04	Upper limit of running frequency	The upper limit of the running frequency is the upper limit of the output frequency of the	50.00Hz	0

Function code	Name	Description	Default	Modify
		VFD, which is lower than or equal to the max. output frequency.  When the set frequency is higher than the upper limit of the running frequency, the upper limit of the running frequency is used for running.  Setting range: P00.05-P00.03 (Max. output frequency)		
P00.05	Lower limit of running frequency	The lower limit of the running frequency is the lower limit of the output frequency of the VFD, When the set frequency is lower than the lower limit of the running frequency, the lower limit of the running frequency is used for running.  Note: Max. output frequency ≥ Upper limit of frequency ≥ Lower limit of frequency Setting range: 0.00Hz–P00.04 (Upper limit of running frequency)	0.00Hz	0
P00.06	Setting channel of A frequency command	0: Keypad 1: Al1	0	0
P00.07	Setting channel of B frequency command	2: AI2 3: AI3 4: High speed pulse HDIA 5: Simple PLC program 6: Multi-step speed running 7: PID control 8: Modbus/Modbus TCP communication 9: PROFIBUS/CANopen/DeviceNet communication 10: Ethernet communication 11: High speed pulse HDIB 12: Pulse train AB 13: EtherCAT/PROFINET/EtherNet IP	15	0

Function code	Name	Description	Default	Modify
		communication		
		14: Programmable card		
		15: Reserved		
P00.08	Reference object of B frequency command	0: Max. output frequency 1: A frequency command	0	0
P00.09	Combination mode of setting source	0: A 1: B 2: (A+B) 3: (A- B) 4: Max(A, B) 5: Min. (A, B)	0	0
P00.10	Frequency set through keypad	When A and B frequency commands select the keypad for setting, the value of the function code is the original setting one of the frequency data of the VFD.  Setting range: 0.00 Hz–P00.03 (Max. output frequency)	50.00Hz	0
P00.11	ACC time 1	ACC time means the time needed if the VFD speeds up from 0Hz to the max. output	Model depended	0
P00.12	DEC time 1	frequency (P00.03).  DEC time means the time needed if the VFD speeds down from the max. output frequency (P00.03) to 0Hz.  The VFD has four groups of ACC/DEC time, which can be selected by P05. The factory default ACC/DEC time of the VFD is the first group.  Setting range of P00.11 and P00.12:  0.0–3600.0s	Model depended	0
P00.13	Running direction	O: Run at the default direction. I: Run at the opposite direction. I: Disable reverse running	0	0

Function code	Name		De	scri	ption		Default	Modify
P00.14	Carrier frequency	Mode  G type  P type  Advanta current v wave an Disadval increasir tempera capacity. carrier fr leakage will incree low frequence low frequence low frequence in the far general, When th carrier fr	1.5–11kV 15–55kW Higher th 75kW 2.2–15kV Higher th 18.5kW ge of high covaveform, li d motor nointage of high ge the switch ture and the The VFD requency. Ar and electric tase. ontrary, an ey may caus ture, decrease. scillation. ier frequency tory before you do not ge frequency, the	wee ellows  V  I an  V  I an  V  I an  Extra see un  Extra	h Low  N High  In models  S:  Default freque  8kHz  4kHz  2kHz  2kHz  2kHz  arrier frequer current has to dera same tin hagnetic interpretable on the torque of the torque	ncy: ideal armonic uency: sing VFD e output te on high ne, the interference va carrier peration at ue, or even properly set lelivered. In	,	0

Function code	Name	Description	Default	Modify
P00.15	Motor parameter autotuning	O: No operation  1: Rotary autotuning 1.  Comprehensive motor parameter autotuning. It is recommended to use rotating autotuning when high control accuracy is needed.  2: Static autotuning 1 (comprehensive autotuning); static autotuning 1 is used in cases where the motor cannot be disconnected from load.  3: Static autotuning 2 (partial autotuning); when the present motor is motor 1, only P02.06, P02.07 and P02.08 are autotuned; when the present motor is motor 2, only P12.06, P12.07 and P12.08 are autotuned.  4: Rotary autotuning 2. Similar to rotary autotuning 1, but it is valid only for AMs.  5: Static autotuning 3 (partial autotuning), valid only for AMs.	0	©
P00.16	AVR function selection	O: Invalid 1: Valid during the whole procedure The auto-adjusting function of the VFD can eliminate the impact on the output voltage of the VFD because of the bus voltage fluctuation.	1	0
P00.17	VFD type	0: G type 1: P type	0	0
P00.18	Function parameter restore	O: No operation 1: Restore default values (excluding motor parameters) 2: Clear fault records 3: Reserved	0	0

Function code	Name	Description	Default	Modify
		Restoring the default values may delete the		
		user password. Exercise caution when using		
		this function. The option 5 can be used only		
		for factory testing.		

# P01—Start and stop control

Function code	Name	Description	Default	Modify
P01.00	Start mode	Direct start     Start after DC braking     Start after speedtracking	0	0
P01.01	Starting frequency of direct start	The parameter indicates the initial frequency during VFD start. See P01.02 (Starting frequency hold time) for detailed information. Setting range: 0.00–50.00Hz	0.50Hz	0
P01.02	Starting frequency hold time	Output frequency  fmax   f1 set by P01.01  t1 set by P01.02  t setting a proper starting frequency can increase the torque during VFD start. During the hold time of the starting frequency, the output frequency of the VFD is the starting frequency. And then, the VFD runs from the starting frequency to the set frequency. If the set frequency is lower than the starting frequency, the VFD stops running and keeps in the standby state. The starting frequency is not limited in the lower limit frequency.  Setting range: 0.0–50.0s	0.0s	0
P01.03	Braking current before start	The VFD performs DC braking with the braking current before start and it speeds up	0.0%	0
P01.04	Braking time before start	after the DC braking time. If the set DC braking time is 0, DC braking is invalid.  Stronger braking current indicates larger	0.00s	0

Function code	Name	Description	Default	Modify
P01.05	ACC and DEC mode	braking power. The DC braking current before start is a percentage of the VFD rated current. Setting range of P01.03: 0.0–100.0% Setting range of P01.04: 0.00–50.00s  The parameter indicates the changing mode of the frequency during start and running.  0: Linear type. The output frequency increases or decreases linearly.  1: S curve. The output frequency increases or decreases according to the S curve.  The S curve is generally applied to elevators, conveyors, and other application scenarios where smoother start or stop is required.  Output frequency f  fmax  Output frequency f  fmax  Note: If mode 1 is selected, set P01.06,	0	©
P01.06	Time of starting segment of ACC S curve	P01.07, P01.27, and P01.28 accordingly.  The curvature of S curve is determined by the ACC range and ACC/DEC time.  Output frequency f	0.1s	©
P01.07	Time of ending segment of ACC S curve	11=P01.06 12=P01.07 13=P01.27 14=P01.28 Setting range: 0.0–50.0s	0.1s	0
P01.08	Stop mode	0: Decelerate to stop. After a stop command	0	0

Function	Name	Description	Default	Modify
code		takes effect, the VFD lowers output frequency		,
		based on the DEC mode and the defined		
		DEC time; after the frequency drops to the		
		stop speed ( <u>P01.15</u> ), the VFD stops.		
		1: Coast to stop. After a stop command takes		
		effect, the VFD stops output immediately; and		
		the load coasts to stop according to		
		mechanical inertia.		
	Starting frequency	Starting frequency of DC braking for stop:		
P01.09	of DC braking for	During the deceleration to stop, the VFD	0.00Hz	0
	stop	starts DC braking for stop when running		
	5	frequency reaches the starting frequency		
P01.10	Demagnetization time	determined by P01.09.	0.00s	0
		Wait time before DC braking: The VFD blocks		
	DC braking current for stop	the output before starting DC braking. After		
P01.11		this wait time, DC braking is started so as to	0.0%	0
	101 3100	prevent overcurrent caused by DC braking at		
		high speed.		
		DC braking current for stop: The value of		
		P01.11 is the percentage of rated current of		
		VFD. Stronger current indicates greater DC		
		braking effect.		
		DC braking time for stop: It indicates the hold		
		time of DC braking. If the time is 0, DC		
		braking is invalid, and the VFD decelerates to		
	DO hardin a time of the	stop within the specified time.		
P01.12	DC braking time for stop	P01.09 Time t P01.09 P01.09  Time t P01.23 P01.30 P01.04 DEC P01.10 P01.12 In running	0.00s	0
		Setting range of <u>P01.09</u> : 0.00Hz– <u>P00.03</u>		
		(Max. output frequency)		
		Setting range of <u>P01.10</u> : 0.00–30.00s		
		Setting range of <u>P01.11</u> : 0.0–100.0%		
		Setting range of <u>P01.12</u> : 0.0–50.0s		
P01.13	FWD/REV running	This function code indicates the transition	0.0s	0

Function code	Name	Description	Default	Modify
	deadzone time	time specified in P01.14 during FWD/REV rotation switching. See the figure.  Output frequency forward switch over after starting frequency Starting frequency Time to the figure switch over after starting frequency Starting frequency Time to the figure switch over after switch o		
P01.14	FWD/REV running switching mode	Switch at zero frequency     Switch at the starting frequency     Switch after the speed reaches the stop speed with a delay	0	0
P01.15	Stop speed	0.00–100.00Hz	0.50Hz	0
P01.16	Stop speed detection mode	Detect by the set speed (unique in space voltage vector control mode)     Detect by the feedback speed	0	0
P01.17	Stop speed detection time	0.00–100.00s	0.50s	0
P01.18	Terminal-based running command protection at power-on	When the channel of running commands is terminal control, the system detects the state of the running terminal during power-on.  O: The terminal running command is invalid at power-on. Even the running command is considered as valid during power-on, the VFD does not run and it keeps the protection state until the running command is canceled and enabled again.  1: The terminal running command is valid at power-on. If the running command is considered as valid during power-on, the VFD is started automatically after the initialization.  Note: Exercise caution before using this function. Otherwise, serious result may follow.	0	0
P01.19	Action selected when running frequency less than	This parameter specifies the running status of VFD when the set frequency is below the	0x00	0

Function code	Name	Description	Default	Modify
	frequency lower limit (valid when frequency lower limit greater than 0)	lower limit. Ones place: Action selection 0: Run in lower limit of the frequency 1: Stop 2: Sleep Tens place: Stop mode 0: Coast to stop 1: Decelerate to stop The VFD stops as set in the tens place if the action selection is stop or sleep when the set frequency is below the lower limit. The VFD resumes the running state automatically when the set frequency is above the lower limit again and this situation lasts for the time set		
P01.20	Wake-up-from-slee p delay	by P01.20.  The parameter determines the wake-up-from-sleep delay time. When the running frequency of the VFD is lower than the lower limit, the VFD becomes standby.  When the set frequency exceeds the lower limit one again and it lasts for the time set by P01.20, the VFD runs automatically.  Set frequency curve: Running frequency curve: Running frequency curve:  Trequency 1  11 < P01.20, the inverter runs  10 = P01.34, sleep delay  Setting range: 0.0—3600.0s (valid when P01.19=2)	0.0s	0
P01.21	Power-off restart selection	The parameter indicates whether the VFD automatically runs after re-power on.	0	0

Function code	Name	Description	Default	Modify
		O: Disable  1: Enable. If the restart condition is met, the VFD will run automatically after waiting the time defined by P01.22.		
P01.22	Wait time for restart after power-off	The parameter indicates the wait time before the automatic running of the VFD that is re-powered on.  Output frequency  11=P01.22 12=P01.23 14-Running Power on  Setting range: 0.0–3600.0s (valid when P01.21=1)	1.0s	0
P01.23	Start delay	After a VFD running command is given, the VFD is in standby state and restarts with the delay defined by P01.23 to implement brake release.  Setting range: 0.0–600.0s	0.0s	0
P01.24	Stop speed delay	0.0–600.0s	0.0s	0
P01.25	Open-loop 0Hz output selection	O: Output without voltage     Output with voltage     Output with the DC braking current for stop	0	0
P01.26	DEC time for emergency stop	0.0–60.0s	2.0s	0
P01.27	Time of ending segment of DEC S curve Time of starting segment of DEC S curve	0.0–50.0s	0.1s	0
P01.28	Time of ending segment of DEC S curve	0.0–50.0s	0.1s	0
P01.29	Short-circuit braking current	When the VFD starts in direct start mode (P01.00=0), set P01.30 to a non-zero value to	0.0%	0
P01.30	Hold time of	enter short-circuit braking.	0.00s	0

Function code	Name	Description	Default	Modify
	short-circuit braking	During stop, if the running frequency of VFD		
	for start	is lower than the starting frequency P01.09 of		
		brake for stop, set P01.31 to a non-zero value		
		to enter short-circuit braking for stop, and		
	l lalakiasa ak	then carry out DC braking in the time set by		
D04.04	Hold time of short-circuit braking for stop	P01.12. (Refer to the descriptions for	0.00s	0
P01.31		<u>P01.09</u> – <u>P01.12</u> .)		
		Setting range of <u>P01.29</u> : 0.0–100.0% (VFD)		
		Setting range of <u>P01.30</u> : 0.0–50.00s		
		Setting range of <u>P01.31</u> : 0.0–50.00s		
D04.00	Pre-exciting time of	0.40.000-	0.000-	0
P01.32	jog	0–10.000s	0.000s	0
	Starting frequency			
P01.33	of braking for	0.00Hz-P00.03	0.00Hz	0
	jogging to stop			
P01.34	Delay to enter sleep	0–3600.0s	0.0s	0

## P02—Parameters of motor 1

Function code	Name	Description	Default	Modify
P02.00	Type of motor 1	Asynchronous motor (AM)     Synchronous motor (SM)	0	0
P02.01	Rated power of AM 1	0.1–3000.0kW	Model depended	0
P02.02	Rated frequency of AM 1	0.01Hz– <u>P00.03</u> (Max. output frequency)	50.00Hz	0
P02.03	Rated speed of AM 1	1–60000rpm	Model depended	0
P02.04	Rated voltage of AM 1	0–1200V	Model depended	0
P02.05	Rated current of AM 1	0.8–6000.0A	Model depended	0
P02.06	Stator resistance of AM 1	0.001–65.535Ω	Model depended	0
P02.07	Rotor resistance of AM 1	0.001–65.535Ω	Model depended	0
P02.08	Leakage inductance of AM 1	0.1–6553.5mH	Model depended	0

Function code	Name	Description	Default	Modify
P02.09	Mutual inductance of AM 1	0.1–6553.5mH	Model depended	0
P02.10	No-load current of AM 1	0.1–6553.5A	Model depended	0
P02.11	Magnetic saturation coefficient 1 of iron core of AM 1	0.0–100.0%	80.0%	0
P02.12	Magnetic saturation coefficient 2 of iron core of AM 1	0.0–100.0%	68.0%	0
P02.13	Magnetic saturation coefficient 3 of iron core of AM 1	0.0–100.0%	57.0%	0
P02.14	Magnetic saturation coefficient 4 of iron core of AM 1	0.0–100.0%	40.0%	0
P02.15	Rated power of SM 1	0.1–3000.0kW	Model depended	0
P02.16	Rated frequency of SM 1	0.01Hz– <u>P00.03</u> (Max. output frequency)	50.00Hz	0
P02.17	Number of pole pairs of SM 1	1–128	2	0
P02.18	Rated voltage of SM 1	0–1200V	Model depended	0
P02.19	Rated current of SM 1	0.8–6000.0A	Model depended	0
P02.20	Stator resistance of SM 1	0.001–65.535Ω	Model depended	0
P02.21	Direct-axis inductance of SM 1	0.01–655.35mH	Model depended	0
P02.22	Quadrature-axis inductance of SM 1	0.01–655.35mH	Model depended	0
P02.23	Counter-emf of SM 1	0–10000	300	0
P02.24	Reserved			
P02.25	Reserved			
P02.26	Overload protection	0: No protection	2	0

Function code	Name	Description	Default	Modify
	selection of motor 1	1: Common motor protection (with low-speed compensation). As the cooling effect of a common motor is degraded at low speed running, the corresponding electronic thermal protection value needs to be adjusted properly, the low compensation indicates lowering the overload protection threshold of the motor whose running frequency is lower than 30Hz.  2: Variable-frequency motor protection (without low speed compensation). Because the heat dissipation function for a variable-frequency motor is not impacted by the rotation speed, it is not necessary to adjust the protection value at low speed running.		
P02.27	Overload protection coefficient of motor 1	Motor overload multiples M=lout/(In*K) In is rated motor current, lout is VFD output current, and K is motor overload protection coefficient.  A smaller value of K indicates a bigger value of M.  When M=116%, protection is performed after motor overload lasts for 1 hour; when M=180%, protection is performed after motor overload lasts for 5 minutes; when M=200%, protection is performed after motor overload lasts for 60 seconds; and when M≥400%, protection is performed immediately.	100.0%	0

Function code	Name	Description	Default	Modify
		Time (min)  12  Current overload multiple 116% 150% 180% 200%  Setting range: 20.0% —120.0%		
P02.28	Power display calibration coefficient of motor	The function code can be used to adjust the power display value of motor 1. However, it does not affect the control performance of the VFD.  Setting range: 0.00–3.00	1.00	0
P02.29	Parameter display selection of motor 1	O: Display by motor type. In this mode, only parameters related to the present motor type are displayed.  1: Display all. In this mode, all the motor parameters are displayed.	0	0
P02.30	System inertia of motor 1	0–30.000kgm²	0 kgm²	0
P02.31- P02.32	Reserved			

# P03—Vector control of motor 1

Function code	Name	Description	Default	Modify
P03.00	Speed-loop proportional gain 1	The parameters P03.00-P03.05 are applicable only to vector control mode. Below	20.0	0
P03.01	Speed-loop integral time 1	the switching frequency 1 ( <u>P03.02</u> ), the speed-loop PI parameters are: <u>P03.00</u> and P03.01. Above the switching frequency 2	0.200s	0
P03.02	Low-point frequency for switching	(P03.05), the speed-loop PI parameters are: P03.03 and P03.04. PI parameters are obtained according to the linear change of	5.00Hz	0

Function code	Name	Description	Default	Modify
P03.03	Speed-loop proportional gain 2	two groups of parameters. See the following figure:  • PI parameter	20.0	0
P03.04	Speed-loop integral time 2	P03.00, P03.01	0.200s	0
P03.05	High-point frequency for switching	P03.03, P03.04	10.00Hz	0
P03.06	Speed-loop output filter	0-8 (corresponding to 0-2^8/10ms)	0	0
P03.07	Electromotive slip compensation coefficient of vector control	Slip compensation coefficient is used to adjust the slip frequency of the vector control and improve the speed control accuracy of the system. Adjusting the parameter properly	100%	0
P03.08	Power-generation	can control the speed steady-state error.	100%	0

Function code	Name	Description	Default	Modify
	slip compensation coefficient of vector control	Setting range: 50–200%		
P03.09	Current-loop proportional coefficient P	Note:  The two parameters are used to adjust PI parameters of current loop; it affects	1000	0
P03.10	Current-loop integral coefficient I	dynamic response speed and control precision of the system directly. The default value needs no adjustment under common conditions.  • Applicable to SVC mode 0 (P00.00=0), SVC mode 1 (P00.00=1), and FVC mode (P00.00=3).  Setting range: 0–65535	1000	0
P03.11	Torque setting method	0–1: Keypad (P03.12) 2: Al1 3: Al2 4: Al3 5: Pulse frequency HDIA 6: Multi-step torque 7: Modbus/Modbus TCP communication 8: PROFIBUS/CANopen/DeviceNet communication 9: Ethernet communication 10: Pulse frequency HDIB 11: EtherCAT/PROFINET/EtherNet IP communication 12: Programmable card Note: For these settings, 100% corresponds to the motor rated current.	0	0
P03.12	Torque set through keypad	-300.0%–300.0% (of the motor rated current)	20.0%	0
P03.13	Torque reference filter time	0.000–10.000s	0.010s	0
P03.14	Setting source of forward rotation upper-limit frequency in torque	0: Keypad (P03.16) 1: Al1 2: Al2 3: Al3	0	0

Function code	Name	Description	Default	Modify
	control	4: Pulse frequency HDIA		
		5: Multi-step setting		
		6: Modbus/Modbus TCP communication		
		7: PROFIBUS/CANopen/DeviceNet		
		communication		
		8: Ethernet communication		
		9: Pulse frequency HDIB		
		10: EtherCAT/PROFINET/EtherNet IP		
		communication		
		11: Programmable card		
		12: Reserved		
		Note: For these settings, 100% corresponds		
		to the max. frequency.		
		0: Keypad (P03.17)		
		1: AI1		
		2: Al2		
		3: Al3		
		4: Pulse frequency HDIA		
		5: Multi-step setting		
	Setting source of	6: Modbus/Modbus TCP communication		
	reverse rotation	7: PROFIBUS/CANopen/DeviceNet		
P03.15	upper-limit	communication	0	0
	frequency in torque	8: Ethernet communication		
	control	9: Pulse frequency HDIB		
		10: EtherCAT/PROFINET/EtherNet IP		
		communication		
		11: Programmable card		
		12: Reserved		
		Note: For these settings, 100% corresponds		
		to the max. frequency.		
	Forward rotation			
	upper-limit	Used to set the frequency upper limits. 100%		
P03.16	frequency set	corresponds to the max. frequency. P03.16	50.00Hz	0
	through keypad in	sets the value when P03.14=1; P03.17 sets		
	torque control	the value when <u>P03.15</u> =1.		
	Reverse rotation	Setting range: 0.00Hz-P00.03 (Max. output		
P03.17	upper-limit	frequency)	50.00Hz	0
	frequency set			

Function code	Name	Description	Default	Modify
	through keypad in			
	torque control			
		0: Keypad (P03.20)		
		1: Al1		
		2: AI2		
		3: AI3		
		4: Pulse frequency HDIA		
		5: Modbus/Modbus TCP communication		
	Setting source of	6: PROFIBUS/CANopen/DeviceNet		
P03.18	electromotive	communication	0	0
FU3.10		7: Ethernet communication	U	
	torque upper limit	8: Pulse frequency HDIB		
		9: EtherCAT/PROFINET/EtherNet IP		
		communication		
		10: Programmable card		
		11: Reserved		
		Note: For these settings, 100% corresponds		
		to the motor rated current.		
		0: Keypad (P03.21)		
		1: Al1		
		2: Al2		
		3: Al3		
		4: Pulse frequency HDIA		
		5: Modbus/Modbus TCP communication		
	Setting source of	6: PROFIBUS/CANopen/DeviceNet		
P03.19	braking torque	communication	0	0
1 03.19	upper limit	7: Ethernet communication	U	
	иррег шти	8: Pulse frequency HDIB		
		9: EtherCAT/PROFINET/EtherNet IP		
		communication		
		10: Programmable card		
		11: Reserved		
		Note: For these settings, 100% corresponds		
		to the motor rated current.		
	Electromotive	Used to set torque limits.		
P03.20	torque upper limit	Setting range: 0.0–300.0% (of the motor rated	180.0%	0
	set through keypad	current)		
P03.21	Braking torque	,	180.0%	0

Function code	Name	Description	Default	Modify
	upper limit set through keypad			
P03.22	Weakening coefficient in constant power zone	Used when the AM is in flux-weakening control.  T	0.3	0
P03.23	Lowest weakening point in constant power zone	Flux-weakening coefficient of motor  O.1  1.0  2.0  f  Min. flux-weakening limit of motor  The function codes P03.22 and P03.23 are valid at constant power. The motor enters the flux-weakening state when the motor runs above the rated speed. Change the flux-weakening curvature by modifying the flux-weakening control coefficient. The larger the coefficient, the steeper the curve, the smaller the coefficient, the smoother the curve.  Setting range of P03.22: 0.1–2.0  Setting range of P03.23: 10%—100%	20%	0
P03.24	Max. voltage limit	P03.24 sets the max. output voltage of the VFD, which is the percentage of motor rated voltage. Set the value according to onsite conditions.  Setting range: 0.0–120.0%	100.0%	0
P03.25	Pre-exciting time	Pre-exciting is performed for the motor when the VFD starts up. A magnetic field is built up inside the motor to improve the torque performance during the start process. Setting range: 0.000–10.000s	0.300s	0
P03.26	Flux-weakening proportional gain	0–8000	1000	0
P03.27	Speed display selection in vector control	Display the actual value     Display the set value	0	0

Function code	Name	Description	Default	Modify
P03.28	Static friction compensation coefficient	0.0–100.0%	0.0%	0
P03.29	Corresponding frequency point of static friction	0.50Hz- <u>P03.31</u>	1.00Hz	0
P03.30	High speed friction compensation coefficient	0.0–100.0%	0.0%	0
P03.31	Corresponding frequency of high speed friction torque	<u>P03.29</u> –400.00Hz	50.00Hz	0
P03.32	Enabling torque control	0: Disable 1: Enable	0	0
P03.33	Flux-weakening integral gain	0–8000	1200	0
P03.34	Flux-weakening control mode	0x000–0x112 Ones place: Control mode 0: Mode 0 1: Mode 1 2: Mode 2 Tens place: Compensation of inductance saturation coefficient 0: Enable 1: Disable Hundreds place: Reserved 0: Reserved 1: Reserved	0x000	•
P03.35	Control optimization setting	0–0x1111 Ones place: Torque command selection 0: Torque reference 1: Torque current reference Tens place: Reserved 0: Reserved 1: Reserved Hundreds place: indicates whether to enable	0x0000	0

Function code	Name	Description	Default	Modify
		speed-loop integral separation		
		0: Disable		
		1: Enable		
		Thousands place: Reserved		
		0: Reserved		
		1: Reserved		
		Range: 0x0000-0x1111		
P03.36	Speed-loop differential gain	0.00–10.00s	0.00s	0
	High-frequency	Under the FVC mode (P00.00=3), when the		
	current-loop	frequency is lower than the current-loop		
P03.37	proportional	high-frequency switching threshold (P03.39),	1000	0
	coefficient	the current-loop PI parameters are P03.09		
	High-frequency	and P03.10; and when the frequency is higher		
P03.38	current-loop	than the current-loop high-frequency	1000	0
	integral coefficient	switching threshold (P03.39), the current-loop		
	<u> </u>	PI parameters are P03.37 and P03.38.		
	Current-loop	Setting range of <u>P03.37</u> : 0–20000		
P03.39	high-frequency	Setting range of <u>P03.38</u> : 0–20000	100.0%	0
	switching threshold	Setting range of <u>P03.39</u> : 0.0–100.0% (of the		
	Ü	maximum frequency)		
D00.40	Enabling inertia	0: Disable		
P03.40	compensation	1: Enable	0	0
		The max. inertia compensation torque is		
	Upper limit of inertia	limited to prevent inertia compensation torque		
P03.41	compensation	from being too large.	10.0%	0
	torque	Setting range: 0.0–150.0% (of the motor rated		
		torque)		
	Inertia	Filter times of inertia compensation torque,		
P03.42	compensation filter	used to smooth inertia compensation torque.	7	0
	times	Setting range: 0–10		
		Due to friction force, it is required to set		
	Inertia identification	certain identification torque for the inertia		
P03.43		identification to be performed properly.	10.0%	0
	torque value	Setting range: 0.0-100.0% (of the motor rated		
		torque)		
P03.44	Enabling inertia	0: No operation	0	0

Function code	Name	Description	Default	Modify
	identification	1: Enable		
		Automatic update will be performed after		
		motor parameter autotuning. In the		
P03.45	Current loop	closed-loop vector control mode for		
	proportional	synchronous motors, you can set the value of	0	
	coefficient after	this function code to P03.09.	U	_
	autotuning	Range: 0-65535		
		Note: Set the value to 0 if motor parameter		
		autotuning is not performed.		
		Automatic update will be performed after		
		motor parameter autotuning. In the		
	Current integral	closed-loop vector control mode for		
P03.46	proportional	synchronous motors, you can set the value of	0	
P03.46	coefficient after	this function code to P03.10.	U	•
	autotuning	Range: 0–65535		
		Note: Set the value to 0 if motor parameter		
		autotuning is not performed.		

## P04—V/F control

Function code	Name	Description	Default	Modify
P04.00	V/F curve setting of motor 1	This group of function code defines the V/F curve of motor 1 to meet the needs of different loads.  0: Straight-line V/F curve, applicable to constant torque loads  1: Multi-point V/F curve  2: Torque-down V/F curve (power of 1.3)  3: Torque-down V/F curve (power of 1.7)  4: Torque-down V/F curve (power of 2.0)  Curves 2 – 4 are applicable to the torque loads such as fans and water pumps. You can adjust according to the characteristics of the loads to achieve best performance.  5: Customized V/F (V/F separation); in this mode, V can be separated from F and F can be adjusted through the frequency setting channel set by P00.06 or the voltage setting	0	©

Function code	Name	Description	Default	Modify
		channel set by P04.27 to change the characteristics of the curve.  Note: In the following figure, V <sub>b</sub> is the motor rated voltage and f <sub>b</sub> is the motor rated frequency.  Output voltage  Torque step-down V/F curve (power of 1.3)  Torque step-down V/F curve (power of 1.7)  Torque step-down V/F curve (power of 2.0)  Quput frequency		
P04.01	Torque boost of motor 1	In order to compensate for low-frequency torque characteristics, you can make some	0.0%	0
P04.02	Torque boost cut-off of motor 1	boost compensation for the output voltage. P04.01 is relative to the maximum output voltage V <sub>b</sub> .  P04.02 defines the percentage of cut-off frequency of manual torque boost to the rated motor frequency f <sub>b</sub> . Torque boost can improve the low-frequency torque characteristics of V/F.  You need to select torque boost based on the load. For example, larger load requires larger torque boost, however, if the torque boost is too large, the motor will run at over-excitation, which may cause increased output current and motor overheating, thus decreasing the efficiency.  When torque boost is set to 0.0%, the VFD uses automatic torque boost.  Torque boost cut-off threshold: Below this frequency threshold, torque boost is valid; exceeding this threshold will invalidate torque boost.	20.0%	0

Function code	Name	Description	Default	Modify
		Output voltage  V <sub>boost</sub> Output frequency f <sub>Cut-off</sub> Setting range of P04.01: 0.0%: (automatic); 0.1%-10.0%  Setting range of P04.02: 0.0%-50.0%		
P04.03	V/F frequency point 1 of motor 1	When P04.00=1 (multi-dot V/F curve), you can set the V/F curve through	0.00Hz	0
P04.04	V/F voltage point 1 of motor 1	P04.03–P04.08.  The V/F curve is generally set according to the load characteristics of the motor.	0.0%	0
P04.05	V/F frequency point 2 of motor 1	<b>Note:</b> $V1 < V2 < V3$ , $f1 < f2 < f3$ . Too high voltage for low frequency will cause motor	0.00Hz	0
P04.06	V/F voltage point 2 of motor 1	overheat or damage and cause VFD overcurrent stall or overcurrent protection.	0.0%	0
P04.07	V/F frequency point 3 of motor 1	Output voltage  100.0% V <sub>b</sub> V3	0.00Hz	0
P04.08	V/F voltage point 3 of motor 1	Setting range of P04.03: 0.00Hz–P04.05 Setting range of P04.04: 0.0%–110.0% (of the rated voltage of motor 1) Setting range of P04.05: P04.03–P04.07 Setting range of P04.06: 0.0%–110.0% (of the rated voltage of motor 1) Setting range of P04.07: P04.05–P02.02 (rated frequency of AM 1) or P04.05–P02.16 (rated frequency of SM 1) Setting range of P04.08: 0.0%–110.0% (of the motor rated voltage of motor 1)	0.0%	0

Function	Name	Description	Default	Modify
code	1140	2000.,р.:о.:	20.000	
P04.09	V/F slip compensation gain of motor 1	Used to compensate for the motor rotating speed change caused by load change in the space voltage vector mode, and thus improve the rigidity of the mechanical characteristics of the motor. You need to calculate the rated slip frequency of the motor as follows: $ \Delta  f{=}fb{-}n^*p/60 $ Of which, $f_b$ is the rated frequency of motor 1, corresponding to function code $\underline{P02.02}$ . n is the rated rotating speed of motor 1, corresponding to function code $\underline{P02.03}$ . p is the number of pole pairs of the motor. 100.0% corresponds to the rated slip frequency $\Delta  f$ of motor 1.	100.0%	0
		Setting range: 0.0–200.0%		
P04.10	Low-frequency oscillation control factor of motor 1	In space voltage vector control mode, the motor, especially the large-power motor, may experience current oscillation at certain	10	0
P04.11	High-frequency oscillation control factor of motor 1	frequencies, which may cause unstable motor running, or even VFD overcurrent. You can adjust the two function codes properly to eliminate such phenomenon.	10	0
P04.12	Oscillation control threshold of motor 1	Setting range of P04.10: 0–100 Setting range of P04.11: 0–100 Setting range of P04.12: 0.00Hz–P00.03 (Max. output frequency)	30.00Hz	0
P04.13	V/F curve setting of motor 2	This group of function code defines the V/F curve of motor 2 to meet the needs of different loads.  0: Straight-line V/F curve 1: Multi-point V/F curve 2: Torque-down V/F curve (power of 1.3) 3: Torque-down V/F curve (power of 1.7) 4: Torque-down V/F curve (power of 2.0) 5: Customized V/F curve (V/F separation) Note: Refer to the description for P04.00.	0	0
P04.14	Torque boost of motor 2	Note: Refer to the descriptions for <u>P04.01</u> and <u>P04.02</u> .	0.0%	0

Function code	Name	Description	Default	Modify
P04.15	Torque boost cut-off of motor 2	Setting range of P04.14: 0.0%: (automatic); 0.1%–10.0% Setting range of P04.15: 0.0%–50.0% (of the rated frequency of motor 2)	20.0%	0
P04.16	V/F frequency point 1 of motor 2	Note: Refer to the descriptions for P04.03–P04.08.	0.00Hz	0
P04.17	V/F voltage point 1 of motor 2	Setting range of <u>P04.16</u> : 0.00Hz– <u>P04.18</u> Setting range of <u>P04.17</u> : 0.0%–110.0% (of the	0.0%	0
P04.18	V/F frequency point 2 of motor 2	rated voltage of motor 2) Setting range of P04.18: P04.16- P04.20	0.00Hz	0
P04.19	V/F voltage point 2 of motor 2	Setting range of P04.19: 0.0%-110.0% (of the rated voltage of motor 2)	00.0%	0
P04.20	V/F frequency point 3 of motor 2	Setting range of <u>P04.20</u> : <u>P04.18</u> – <u>P12.02</u> (rated frequency of AM 2) or <u>P04.18</u> – <u>P12.16</u>	0.00Hz	0
P04.21	V/F voltage point 3 of motor 2	(rated frequency of SM 2) Setting range of P04.21: 0.0%–110.0% (of the rated voltage of motor 2)	0.0%	0
P04.22	V/F slip compensation gain of motor 2	Used to compensate for the motor rotating speed change caused by load change in the space voltage vector mode, and thus improve the rigidity of the mechanical characteristics of the motor. You need to calculate the rated slip frequency of the motor as follows: $\Delta f = f_b - n^* p/60$ Of which, $f_b$ is the rated frequency of the motor, corresponding to function code P12.02. n is the rated rotating speed of the motor, corresponding to function code P12.03. p is the number of pole pairs of the motor. 100.0% corresponds to the rated slip frequency $\Delta f$ of motor 2. Setting range: 0.0–200.0%	0.0%	0
P04.23	Low-frequency oscillation control factor of motor 2	In space voltage vector control mode, the motor, especially the large-power motor, may experience current oscillation at certain	10	0
P04.24	High-frequency oscillation control factor of motor 2	frequencies, which may cause unstable motor running, or even VFD overcurrent. You can adjust the two function codes properly to	10	0

Function code	Name	Description	Default	Modify
P04.25	Oscillation control threshold of motor 2	eliminate such phenomenon.  Setting range of P04.23: 0–100  Setting range of P04.24: 0–100  Setting range of P04.25: 0.00Hz–P00.03  (Max. output frequency)	30.00Hz	0
P04.26	Energy-saving run	O: Disable  1: Automatic energy-saving run  In light-load state, the motor can adjust the output voltage automatically to achieve energy saving.	0	0
P04.27	Voltage setting channel	0: Keypad (The output voltage is determined by P04.28) 1: Al1 2: Al2 3: Al3 4: HDIA 5: Multi-step speed running (The setting is determined by group P10.) 6: PID 7: Modbus/Modbus TCP communication 8: PROFIBUS/CANopen/DeviceNet communication 9: Ethernet communication 10: HDIB 11: EtherCAT/PROFINET/EthernetIP communication 12: Programmable card 13: Reserved	0	0
P04.28	Voltage set through keypad	The function code is the voltage digital setting when "keypad" is selected as the voltage setting channel.  Setting range: 0.0% –100.0%	100.0%	0
P04.29	Voltage increase time	Voltage increase time means the time needed for the VFD to accelerate from min. output	5.0s	0
P04.30	Voltage decrease time	voltage to the max. output frequency. Voltage decrease time means the time needed for the VFD to decelerate from the max. output frequency to min. output voltage.	5.0s	0

Function code	Name	Description	Default	Modify
		Setting range: 0.0-3600.0s		
P04.31	Max. output voltage	Used to set the upper and lower limits of	100.0%	0
P04.32	Min. output voltage	output voltage.  Vmax  V set  Vmin  t1=P04.29  Vset  t2=P04.30  Setting range of P04.31: P04.32-100.0% (of the motor rated voltage)  Setting range of P04.32: 0.0%—P04.31	0.0%	0
P04.33	Weakening coefficient in constant power zone	1.00–1.30	1.00	0
P04.34	Pull-in current 1 in SM V/F control	When the SM V/F control mode is enabled, the function code is used to set the reactive current of the motor when the output frequency is lower than the frequency specified by <u>P04.36</u> .  Setting range: -100.0%-100.0% (of the motor rated current)	20.0%	0
P04.35	Pull-in current 2 in SM V/F control	When the SM V/F control mode is enabled, the function code is used to set the reactive current of the motor when the output frequency is higher than the frequency specified by P04.36  Setting range: -100.0%–100.0% (of the motor rated current)	10.0%	0
P04.36	Frequency threshold for pull-in current switching in SM V/F control	Setting range: 0%–200.0% (of the motor rated frequency)	20.0%	0
P04.37	Reactive current	When the SM V/F control mode is enabled,	50	0

Function	.,	2	5 ( )	
code	Name	Description	Default	Modify
	closed-loop	the function code is used to set the		
	proportional	proportional coefficient of reactive current		
	coefficient in SM	closed-loop control.		
	V/F control	Setting range: 0–3000		
		When the SM V/F control mode is enabled,		
	Reactive current	the function code is used to set the integral		
P04.38	closed-loop integral	coefficient of reactive current closed-loop	30	0
	time in SM V/F	control.		
	control	Setting range: 0–3000		
		When the SM V/F control mode is enabled,		
		the function code is used to set the output		
		limit of the reactive current closed-loop		
	Reactive current	control. A greater value indicates a higher		
P04.39	closed-loop output	reactive closed-loop compensation voltage	8000	0
	limit in SM V/F	and higher output power of the motor. In		
	control	general, you do not need to modify the		
		function code.		
		Setting range: 0–16000		
504.40	Enabling IF mode	0: Disable		
P04.40	for AM 1	1: Enable	0	0
		When IF control is adopted for AM 1, the		
	0	function code is used to set the output		
P04.41	Current setting in IF	current. The value is a percentage in relative	120.0%	0
	mode for AM 1	to the rated current of the motor.		
		Setting range: 0.0–200.0%		
		When IF control is adopted for AM 1, the		
	Proportional	function code is used to set the proportional		
P04.42	coefficient in IF	coefficient of the output current closed-loop	650	0
	mode for AM 1	control.		
		Setting range: 0-5000		
		When IF control is adopted for AM 1, the		
	Internal s #!-!-	function code is used to set the integral		
P04.43	Integral coefficient	coefficient of the output current closed-loop	350	0
	in IF mode for AM 1	control.		
		Setting range: 0-5000		
P04.44	Frequency	0.00Hz D04.50	10.004-	
PU4.44	threshold for	0.00Hz–P04.50	10.00Hz	0

Function code	Name	Description	Default	Modify
	switching off IF			
	mode for AM 1			
P04.45	Enabling IF mode	0: Disable	0	(O)
P04.45	for AM 2	1: Enable	U	0
		When IF control is adopted for AM 2, the		
	Current setting in IF	function code is used to set the output		
P04.46	mode for AM 2	current. The value is a percentage in relative	120.0%	0
	mode for AW 2	to the rated current of the motor.		
		Setting range: 0.0–200.0%		
		When IF control is adopted for AM 2, the		
	Proportional	function code is used to set the proportional		
P04.47	coefficient in IF	coefficient of output current closed-loop	650	0
	mode for AM 2	control.		
		Setting range: 0-5000		
		When IF control is adopted for AM 2, the		
	Integral coefficient	function code is used to set the integral		
P04.48	in IF mode for AM 2	coefficient of output current closed-loop control.	350	0
		Setting range: 0–5000		
P04.49	Frequency threshold for switching off IF mode for AM 2	0.00Hz–P04.51	10.00Hz	0
	End frequency point			
P04.50	for switching off IF	P04.44–P00.03	25.00Hz	0
	mode for AM 1			
	End frequency point			
P04.51	for switching off IF	P04.49–P00.03	25.00Hz	0
	mode for AM 2			

# P05—Input terminals

Function code	Name	Description	Default	Modify
P05.00	HDI input type	0x00-0x11 Ones place: HDIA input type 0: HDIA is high-speed pulse input 1: HDIA is digital input	0x00	©

Name	Description	Default	Modify
	Tens place: HDIB input type		
	0: HDIB is high-speed pulse input		
	1: HDIB is digital input		
Function of S1	0: No function	1	0
terminal	1: Forward running		
Function of S2	2: Reverse running	1	0
terminal	3: 3-wire control/Sin	4	
Function of S3	4: Forward jogging	7	0
terminal	5: Reverse jogging	7	0
Function of S4	6: Coast to stop	0	
terminal	7: Fault reset	U	0
Function of HDIA	8: Running pause	•	
terminal	9: External fault input	U	0
Function of HDIB terminal	11: Frequency increase (DF) 11: Frequency decrease (DOWN) 12: Clear frequency increase/decrease setting 13: Switchover between setup A and setup B 14: Switchover between combination setup and setup A 15: Switchover between combination setup and setup B 16: Multi-step speed terminal 1 17: Multi-step speed terminal 2 18: Multi-step speed terminal 3 19: Multi-step speed terminal 4 20: Multi-step speed pause 21: Acceleration/deceleration time selection 1 22: Acceleration/deceleration time selection 2 23: Simple PLC stop reset 24: Simple PLC pause 25: PID control pause 26: Wobbling frequency pause 27: Wobbling frequency reset 28: Counter reset 29: Switchover between speed control and	0	©
	Function of S1 terminal Function of S2 terminal Function of S3 terminal Function of S4 terminal Function of HDIA terminal	Tens place: HDIB input type  0: HDIB is high-speed pulse input  1: HDIB is digital input  Function of S1 terminal  Function of S2 terminal  Function of S3 terminal  Function of S4 terminal  Function of HDIA terminal  Function of HDIB Terequency increase (UP)  11: Frequency increase (UP) 11: Frequency increase (DOWN) 12: Clear frequency increase/decrease setting 13: Switchover between setup A and setup B 14: Switchover between combination setup and setup A 15: Switchover between combination setup and setup B 16: Multi-step speed terminal 1 17: Multi-step speed terminal 2 18: Multi-step speed terminal 3 19: Multi-step speed terminal 4 20: Multi-step speed terminal	Tens place: HDIB input type  0: HDIB is high-speed pulse input  1: HDIB is digital input  0: No function 1: Forward running  Function of S2 terminal 3: 3-wire control/Sin  4: Forward jogging 5: Reverse jogging  Function of S4 terminal 7: Fault reset  Function of HDIA terminal  7: Fault reset  8: Running pause 9: External fault input 10: Frequency increase (UP) 11: Frequency decrease (DOWN) 12: Clear frequency increase/decrease setting 13: Switchover between setup A and setup B 14: Switchover between combination setup and setup A 15: Switchover between combination setup and setup B 16: Multi-step speed terminal 1 17: Multi-step speed terminal 2 18: Multi-step speed terminal 3 19: Multi-step speed terminal 4 20: Multi-step speed terminal 5 19: Multi-step speed terminal 6 21: Acceleration/deceleration time selection 1 22: Acceleration/deceleration time selection 2 23: Simple PLC stop reset 24: Simple PLC pause 25: PID control pause 26: Wobbling frequency pause 27: Wobbling frequency reset

Function	Name	Description	Default	Modify
code	Nume	Description	Delduit	Modify
		30: Acceleration/deceleration disabled		
		31: Counter trigger		
		32: Reserved		
		33: Clear frequency increase/decrease		
		setting temporarily		
		34: DC brake		
		35: Switch from motor 1 to motor 2		
		36: Command switches to keypad		
		37: Command switches to terminal		
		38: Command switches to communication		
		39: Pre-exciting command		
		40: Zero out power consumption quantity		
		41: Maintain power consumption quantity		
		42: Switching the upper torque limit setting		
		mode to keypad		
		43: Position reference point input (valid only		
		for S1, S2 and S3 are valid)		
		44: Spindle orientation disabled		
		45: Spindle zeroing/local positioning zeroing		
		46: Spindle zero position selection 1		
		47: Spindle zero position selection 2		
		48: Spindle scale division selection 1		
		49: Spindle scale division selection 2		
		50: Spindle scale division selection 3		
		51: Terminal for switching between position		
		control and speed control		
		52: Pulse input disabled		
		53: Clear position deviation cleared		
		54: Switch over position proportional gain		
		55: Enable cyclic positioning of digital position		
		positioning		
		56: Emergency stop		
		57: Motor over-temperature fault input		
		58: Enable rigid tapping		
		59: Switch to V/F control		
		60: Switch to FVC control		
		61: PID polarity switchover		
		62: Reserved		

Function code	Name	Description	Default	Modify
		63: Enable servo		
		64: Limit of forward run		
		65: Limit of reverse run		
		66: Zero out encoder counting		
		67: Pulse increase		
		68: Enable pulse superimposition		
		69: Pulse decrease		
		70: Electronic gear selection		
		71: Switch to master		
		72: Switch to slave		
		73: Reset the roll diameter		
		74: Switch winding/unwinding		
		75: Pre-drive		
		76: Disable roll diameter calculation		
	77: Clear alarm display			
		78: Manual braking		
		79: Trigger forced feeding interrupt		
		80: Initial roll diameter 1		
		81: Initial roll diameter 2		
		82: Trigger fire mode control		
		83: Switch tension PID parameters		
		84–95: Reserved		
P05.07	Reserved			
	Input terminal polarity	Used to set the polarity of input terminals.		
DOE 00		When a bit is 0, the input terminal is positive;	000	0
P05.08		when a bit is 1, the input terminal is negative.	0x00	
		0x000-0x3F		
	Digital input filter time	Used to set the filter time for S1–S4, HDIA,		
DOE 00		and HDIB. In strong interference cases,	0.040	0
P05.09		increase the value to avoid maloperation.	0.010s	
		0.000-1.000s		
P05.10	Virtual terminal setting	0x00-0x3F (0: disable, 1: enable)		
		BIT0: S1 virtual terminal		
		BIT1: S2 virtual terminal		0
		BIT2: S3 virtual terminal	0x00	
		BIT3: S4 virtual terminal		
		BIT4: HDIA virtual terminal		
		BIT5: HDIB virtual terminal		

Function code	Name	Description	Default	Modify
P05.11	Terminal control mode	Used to set the mode of terminal control.  0: Two-wire control 1, the enabling consistent with the direction. This mode is widely used. The defined FWD/REV terminal command determines the motor rotation direction.    FWD   REV   Running   Reverse   Running   OFF   ON   Stop   ON   OFF   Forward   OFF   OFF   Stop   ON   OFF   Forward   OFF   OFF   Stop   ON   OFF   Forward   OFF   OFF   Stop   ON   OFF   Forward   OFF   ON   Stop   ON   ON   Reverse   Running   OFF   ON   ON   ON   Reverse   Running   OFF   ON   ON   ON   ON   ON   ON   O	0	

Function code	Name			Default	Modify		
		SB1 SB2 K The dire		ontrol is as fol	lows during		
		Sin	REV	Previous direction	Present direction		
		ON	OFF → ON	Run forward Run reversely	Run reversely Run forward		
		ON	ON→ OFF	Run reversely	Run forward		
		ON→ OFF		Run forward Decelerate to	Run reversely stop		
		Sin: Thi					
		3: Three Sin as t comma the dire	he enat nd is ge ction is				
		REV. Do to be cla generate running needs to	osed, ar es a ris and dir				
		termina		.pp 30 0) 01000	9		

Function code	Name	Description				Default	Modify
		SB1	FWD SIn REV COM				
		Sin	FWD	REV	Running direction		
		ON OFF	OFF→O	ON	Run forward		
			N	OFF	Run forward		
		ON	ON	OFF→ON	Run reversely		
			OFF		Run reversely		
		ON→ OFF			Decelerate to stop		
			e-wire con REV: Reve				
		when the	r two-wire of FWD/REV os due to a				
		another s	source, the stop comm				
		make the	ol terminal VFD run, V again, fo				
		single-cy	cle stop, fix	ked-length	stop, and valid al control. (See		

Function code	Name	Description	Default	Modify
P05.12	S1 switch-on delay		0.000s	0
P05.13	S1 switch-off delay		0.000s	0
P05.14	S2 switch-on delay		0.000s	0
P05.15	S2 switch-off delay	Used to specify the delay time corresponding	0.000s	0
P05.16	S3 switch-on delay	to the electrical level changes when the programmable input terminals switch on or	0.000s	0
P05.17	S3 switch-off delay	switch off.	0.000s	0
P05.18	S4 switch-on delay	Si Electrical level Si Valid Invalid Invalid Invalid Invalid	0.000s	0
P05.19	S4 switch-off delay	Switch-on delay switch-off delay	0.000s	0
P05.20	HDIA switch-on delay	Setting range: 0.000–50.000s  Note: After a virtual terminal is enabled, the state of the terminal can be changed only in	0.000s	0
P05.21	HDIA switch-off delay	communication mode. The communication address is 0x200A.	0.000s	0
P05.22	HDIB switch-on delay		0.000s	0
P05.23	HDIB switch-off delay		0.000s	0
P05.24	Al1 lower limit	Used to define the relationship between the	0.00V	0
P05.25	Corresponding setting of AI1 lower limit	analog input voltage and its corresponding setting. When the analog input voltage exceeds the range from the upper limit to the	0.0%	0
P05.26	Al1 upper limit	lower limit, the upper limit or lower limit is used.	10.00V	0
P05.27	Corresponding setting of AI1 upper limit	When the analog input is current input, 0mA–20mA current corresponds to 0V–10V voltage.	100.0%	0
P05.28	Al1 input filter time	In different applications, 100.0% of the analog setting corresponds to different nominal	0.030s	0
P05.29	Al2 lower limit	values. See the descriptions of each	-10.00V	0

Function code	Name	Description	Default	Modify
P05.30	Corresponding setting of AI2 lower limit	application section for details.  The following figure illustrates the cases of several settings:	-100.0%	0
P05.31	Al2 middle value 1	Corresponding setting	0.00V	0
P05.32	Corresponding setting of AI2 middle value 1	10V 0 AI 10V 20mA	0.0%	0
P05.33	Al2 middle value 2	Al2 Al1	0.00V	0
P05.34	Corresponding setting of AI2 middle value 2	analog input. Increasing the value properly	0.0%	0
P05.35	Al2 upper limit	can enhance analog input anti-interference but may reduce the sensitivity of analog input.	10.00V	0
P05.36	Corresponding setting of AI2 upper limit	Note: Al1 supports the 0–10V/0–20mA input. When Al1 selects the 0–20mA input, the corresponding voltage of 20mA is 10V. Al2 supports the -10—+10V input.	100.0%	0
P05.37	AI2 input filter time	Setting range of P05.24: 0.00V–P05.26  Setting range of P05.25: -300.0%–300.0%  Setting range of P05.26: P05.24–10.00V  Setting range of P05.27: -300.0%–300.0%  Setting range of P05.28: 0.000s–10.000s  Setting range of P05.29: -10.00V–P05.31  Setting range of P05.30: -300.0%–300.0%  Setting range of P05.31: P05.29–P05.33  Setting range of P05.32: -300.0%–300.0%  Setting range of P05.33: P05.31–P05.35  Setting range of P05.34: -300.0%–300.0%  Setting range of P05.35: P05.33–10.00V  Setting range of P05.36: -300.0%–300.0%  Setting range of P05.36: -300.0%–300.0%  Setting range of P05.37: 0.000s–10.000s	0.030s	0
P05.38	HDIA high-speed pulse input function selection	0: Input set through frequency 1: Reserved 2: Input set through encoder, used together with HDIB	0	0

Function code	Name	Description	Default	Modify
P05.39	HDIA lower limit frequency	0.000 kHz – <u>P05.41</u>	0.000 kHz	0
P05.40	Corresponding setting of HDIA lower limit frequency	-300.0%–300.0%	0.0%	0
P05.41	HDIA upper limit frequency	<u>P05.39</u> –50.000kHz	50.000 kHz	0
P05.42	Corresponding setting of HDIA upper limit frequency	-300.0%–300.0%	100.0%	0
P05.43	HDIA frequency input filter time	0.000s-10.000s	0.030s	0
P05.44	HDIB high-speed pulse input function selection	O: Input set through frequency I: Reserved I: Input set through encoder, used together with HDIA  O: Input set through encoder, used together with HDIA	0	0
P05.45	HDIB lower limit frequency	0.000 kHz – <u>P05.47</u>	0.000 kHz	0
P05.46	Corresponding setting of HDIB lower limit frequency	-100.0%–100.0%	0.0%	0
P05.47	HDIB upper limit frequency	P05.45 –50.000kHz	50.000 kHz	0
P05.48	Corresponding setting of HDIB upper limit frequency	-300.0%–300.0%	100.0%	0
P05.49	HDIB frequency input filter time	0.000s-10.000s	0.030s	0
P05.50	Al1 input signal type	O: Voltage 1: Current  Note: You can set the Al1 input signal type through the corresponding function code.	0	0

Function code	Name	Description	Default	Modify
P05.51-	Reserved			
P05.52	Reserved			

### P06—Output terminals

Function code	Name	Description	Default	Modify
P06.00	HDO output type	O: Open collector high-speed pulse output. The max. frequency of pulse is 50.00kHz. For details about the related functions, see P06.27-P06.31.  Open collector output. For details about the related functions, see P06.02.	0	0
P06.01	Y1 output	0: Invalid	0	0
P06.02	HDO output	1: In running	0	0
P06.03	RO1 output	2: In forward running	1	0
		3: In reverse running 4: In jogging		
P06.04	RO2 output	5: VFD fault 6: Frequency level detection FDT1 7: Frequency level detection FDT2 8: Frequency reached 9: Running in zero speed 10: Reach upper limit frequency 11: Reach lower limit frequency 12: Ready to run 13: In pre-exciting 14: Overload pre-alarm 15: Underload pre-alarm 16: Simple PLC stage completed 17: Simple PLC cycle completed 18: Reach set counting value 19: Reach designated counting value 20: External fault is valid 21: Reserved 22: Reach running time 23: Virtual terminal output of Modbus/Modbus TCP communication 24: Virtual terminal output of	5	0

Function code	Name	Description	Default	Modify
553.5		POROFIBUS/CANopen/DeviceNet		
		communication		
		25: Virtual terminal output of Ethernet		
		communication		
		26: DC bus voltage established		
		27: Z pulse output		
		28: During pulse superposition		
		29: STO action		
		30: Positioning completed		
		31: Spindle zeroing completed		
		32: Spindle scale-division completed		
		33: In speed limit		
		34: Virtual terminal output of		
		EtherCAT/PROFINET/EtherNet IP		
		communication		
		35: Reserved		
		36: Speed/position control switchover		
		completed		
		37: Any frequency reached		
		38-40: Reserved		
		41: Y1 from the programmable card		
		42: Y2 from the programmable card		
		43: HDO from the programmable card		
		44: RO1 from the programmable card		
		45: RO2 from the programmable card		
		46: RO3 from the programmable card		
		47: RO4 from the programmable card		
		48: EC PT100 detected OH pre-alarm		
		49: EC PT1000 detected OH pre-alarm		
		50: Al/AO detected OH pre-alarm		
		51: Stopped or running at zero speed		
		52: Disconnection detected in tension control		
		53: Roll diameter setting reached		
		54: Max. roll diameter reached		
		55: Min. roll diameter reached		
		56: Fire control mode enabled		
		57–63: Reserved		

Function code	Name	Description	Default	Modify
P06.05	Output terminal polarity selection	Used to set the polarity of output terminals.  When a bit is 0, the input terminal is positive;  When a bit is 1, the input terminal is negative.  BIT3 BIT2 BIT1 BIT0 RO2 RO1 HDO Y1  Setting range: 0x00–0x0F	0x00	0
P06.06	Y1 switch-on delay		0.000s	0
P06.07	Y1 switch-off delay		0.000s	0
P06.08	HDO switch-on delay	Used to specify the delay time corresponding to the electrical level changes when the programmable output terminals switch on or	0.000s	0
P06.09	HDO switch-off delay	switch off.  Y electric level	0.000s	0
P06.10	RO1 switch-on delay	Y valid invalid inval	0.000s	0
P06.11	RO1 switch-off delay	Setting range: 0.000–50.000s  Note: P06.08 and P06.09 are valid only when	0.000s	0
P06.12	RO2 switch-on delay	P06.00=1.	0.000s	0
P06.13	RO2 switch-off delay		0.000s	0
P06.14	AO1 output	0: Running frequency	0	0
P06.15	Reserved	Set frequency     Ramp reference frequency		
P06.16	HDO high-speed pulse output	3: Rotational speed (100% corresponds to the speed corresponding to max. output frequency) 4: Output current (100% corresponds to twice the VFD rated current) 5: Output current (100% corresponds to twice the motor rated current) 6: Output voltage (100% corresponds to 1.5 times the VFD rated voltage) 7: Output power (100% corresponds to twice the motor rated power) 8: Set torque (100% corresponds to twice the	0	0

Function code	Name	Description	Default	Modify
		motor rated torque)		
		9: Output torque (Absolute value, 100%		
		corresponds to twice the motor rated torque)		
		10: Al1 input		
		11: Al2 input		
		12: Al3 input		
		13: HDIA input		
		14: Value 1 set through Modbus/Modbus TCP		
		communication		
		15: Value 2 set through Modbus/Modbus TCP		
		communication		
		16: Value 1 set through		
		PROFIBUS/CANopen/DeviceNet		
		communication		
		17: Value 2 set through		
		PROFIBUS/CANopen/DeviceNet		
		communication		
		18: Value 1 set through Ethernet		
		communication		
		19: Value 2 set through Ethernet		
		communication		
		20: HDIB input		
		21: Value 1 set through		
		EtherCAT/PROFINET/EtherNet IP		
		communication		
		22: Torque current (bipolar, 0-Triple the motor		
		rated current)		
		23: Exciting current (bipolar, 0-Triple the		
		motor rated current)		
		24: Set frequency (bipolar)		
		25: Ramp reference frequency (bipolar)		
		26: Rotational speed (bipolar)		
		27: Value 2 set through		
		EtherCAT/PROFINET/EtherNet IP		
		communication		
		28: AO1 from the programmable card		
		29: AO2 from the programmable card		
		30: Rotational speed (100% corresponds to		

Function code	Name	Description	Default	Modify
		twice the motor rated synchronous speed) 31: Output torque (Actual value, 100% corresponds to twice the motor rated torque) 32: Al/AO temperature detection output 33–63: Reserved  Note: When the output comes from the programmable card (28–29), if the card is a Codesys programmable card, P27.00 must be set to 1. When AO1 is of the current output type, 100% corresponds to 20mA; when AO1 is of the voltage output type, 100% corresponds to 10V; 100% of HDO corresponds to the output of P06.30.		
P06.17	AO1 output lower limit	Used to define the relationship between the output value and analog output. When the	0.0%	0
P06.18	AO1 output corresponding to lower limit	output value exceeds the allowed range, the output uses the lower limit or upper limit.  When the analog output is current output,  1mA equals 0.5V.	0.00V	0
P06.19	AO1 output upper limit	In different cases, the corresponding analog output of 100% of the output value is different.	100.0%	0
P06.20	AO1 output corresponding to upper limit	See each application for detailed information.	10.00V	0
P06.21	AO1 output filter time	Setting range of P06.17: -300.0%—P06.19 Setting range of P06.18: 0.00V—10.00V Setting range of P06.19: P06.17—300.0% Setting range of P06.20: 0.00V—10.00V Setting range of P06.21: 0.000s—10.000s	0.000s	0
P06.22	Reserved	5 5 ===================================		
P06.23	PTC constant	0.000–20.000mA	4.000	0

Function code	Name	Description	Default	Modify
	output current setting			
P06.24	PTC resistance alarm threshold	0–60000Ω	750	0
P06.25	PTC resistance alarm recovery threshold	0–60000Ω	150	0
P06.26	Actual PTC resistance	0–60000Ω	0	•
P06.27	HDO output lower limit	-300.0%– <u>P06.29</u>	0.0%	0
P06.28	HDO output corresponding to lower limit	0.00–50.00kHz	0.00kHz	0
P06.29	HDO output upper limit	<u>P06.27</u> –300.0%	100.0%	0
P06.30	HDO output corresponding to upper limit	0.00–50.00kHz	50.00 kHz	0
P06.31	HDO output filter time	0.000s-10.000s	0.000s	0
P06.32	Reserved			
P06.33	Frequency reach detection value	0-P00.03	1.00Hz	0
P06.34	Frequency reach detection time	0–3600.0s	0.5s	0

# P07—HMI

Function code	Name	Description	Default	Modify
P07.00	User password	0–65535 When you set the function code to a non-zero number, password protection is enabled. If you set the function code to 00000, the previous user password is cleared and password protection is disabled. After the user password is set and takes effect, you cannot enter the parameter menu	0	0

Function code	Name	Description	Default	Modify
		if you enter an incorrect password. Please remember your password and save it in a secure place.  After you exit the function code editing interface, the password protection function is enabled within 1 minute. If password protection is enabled, "①.①.①.①.①." is displayed when you press the PRG/ESC key again to enter the function code editing interface. You need to enter the correct user password to enter the interface.  Note: Restoring the default values may delete the user password. Exercise caution		
		when using this function.		
P07.01	Reserved			
P07.02	Key function selection	Range: 0x00–0x27 Ones place: Function of QUICK/JOG 0: No function 1: Jog 2: Reserved 3: Switch between forward and reverse rotating 4: Clear the UP/DOWN setting 5: Coast to stop 6: Switch command channels in sequence 7: Reserved Tens place: Reserved	0x01	©
P07.03	Sequence of switching running-command channels by pressing QUICK	When P07.02=6, set the sequence of switching running-command channels by pressing this key.  0: Keypad→Terminal→Communication  1: Keypad←→Terminal  2: Keypad←→Communication  3: Terminal←→Communication	0	0
P07.04	Stop function validity of	The function code specifies the stop function validity of STOP/RST. For fault reset,	0	0

Function	Name	Description	Default	Modify
<b>code</b> P07.05—	STOP/RST  Reserved	STOP/RST is valid in any conditions.  0: Valid only for keypad control  1: Valid both for keypad and terminal control  2: Valid both for keypad and communication control  3: Valid for all control modes		
P07.07	Frequency display coefficient	0.01–10.00 Display frequency = Running frequency * P07.08	1.00	0
P07.09	Rotational speed display coefficient	0.1–999.9%  Mechanical rotation speed = 120 * (Displayed running frequency) *xP07.09/(Number of motor pole pairs)	100.0%	0
P07.10	Linear speed display coefficient	0.1–999.9% Linear speed = (Mechanical rotation speed) × P07.10	1.0%	0
P07.11	Rectifier bridge temperature	-20.0–120.0°C	0.0°C	•
P07.12	Inverter temperature	-20.0–120.0°C	0.0°C	•
P07.13	Control board software version	1.00–655.35	Depends on version	•
P07.14	Local accumulative running time	0–65535h	0h	•
P07.15	VFD electricity consumption high-order bits	Used to display the electricity consumption of the VFD.  VFD electricity consumption =  P07.15*1000+P07.16	0kWh	•
P07.16	VFD electricity consumption low-order bits	Setting range of <u>P07.15</u> : 0–65535 kWh (*1000) Setting range of <u>P07.16</u> : 0.0–999.9 kWh	0.0kWh	•
P07.17	VFD type	0x0000–0xFFFF Bit0–Bit3: G type or P type 0: G type	0x1000	•

Function code	Name	Description	Default	Modify
		1: P type		
		Bit4–Bit11: Chip type and manufacturer		
		0: DSP (TI)		
		21: MCU (ST)		
		Bit12-Bit15: Product series		
		0: GD350		
		1: GD350A		
		2: GD350-UL		
		3: GD350 IP55		
P07.18	VED roted newer	0.4.2000.0144/	Model	
P07.16	VFD rated power	0.4–3000.0kW	depended	
P07.19	VED roted voltage	50–1200V	Model	
F07.19	VFD rated voltage	30-1200 V	depended	
P07.20	VFD rated current	0.1–6000.0A	Model	
F 07.20	VI D lated cullent	0.1-0000.0A	depended	
P07.21	Factory bar code 1	0x0000-0xFFFF	Model	
1 07.21	Tactory bar code 1	OXCOCC CXITT	depended	
P07.22	Factory bar code 2	0x0000_0xFFFF	Model	
1 07.22	T dotory but dodd 2	CACCOC CALLE	depended	
P07.23	Factory bar code 3	0x0000_0xFFFF	Model	•
			depended	
P07.24	Factory bar code 4	0x0000_0xFFFF	Model	•
			depended	
P07.25	Factory bar code 3	0x0000_0xFFFF	Model	•
			depended	
P07.26	Factory bar code 4	0x0000-0xFFFF	Model	•
	•		depended	
P07.27	Present fault type	0: No fault	0	•
P07.28	Last fault type	1: Inverter unit U phase protection (OUt1)	0	•
P07.29	2nd-last fault type	2: Inverter unit V phase protection (OUt2)	0	•
P07.30	3rd-last fault type	3: Inverter unit W phase protection (OUt3)	0	•
P07.31	4th-last fault type	4: Overcurrent during acceleration (OC1)	0	•
		5: Overcurrent during deceleration (OC2)		
		6: Overcurrent during constant speed (OC3)		
P07.32	5th-last fault type	7: Overvoltage during acceleration (OV1)	0	•
		8: Overvoltage during deceleration (OV2)		
		9: Overvoltage during constant speed (OV3)		

Function	Name	Description	Default	Modify
code	- Tumo	2000 i piloti	Dordan	ouy
		10: Bus undervoltage fault (UV)		
		11: Motor overload (OL1)		
		12: VFD overload (OL2)		
		13: Phase loss on input side (SPI)		
		14: Phase loss on output side (SPO)		
		15: Rectifier module overheat (OH1)		
		16: Inverter module overheat (OH2)		
		17: External fault (EF)		
		18: Modbus/Modbus TCP communication		
		fault (CE)		
		19: Current detection fault (ItE)		
		20: Motor autotuning fault (tE)		
		21: EEPROM operation fault (EEP)		
		22: PID feedback offline fault (PIDE)		
		23: Braking unit fault (bCE)		
		24: Running time reached (END)		
		25: Electronic overload (OL3)		
		26: Keypad communication error (PCE)		
		27: Parameter upload error (UPE)		
		28: Parameter download error (DNE)		
		29: PROFIBUS communication fault (E-DP)		
		30: Ethernet communication fault (E-NET)		
		31: CANopen communication fault (E-CAN)		
		32: To-ground short-circuit fault 1 (ETH1)		
		33: To-ground short-circuit fault 2 (ETH2)		
		34: Speed deviation fault (dEu)		
		35: Maladjustment fault (STo)		
		36: Underload fault (LL)		
		37: Encoder offline fault (ENC1o)		
		38: Encoder reversal fault (ENC1d)		
		39: Encoder Z pulse offline fault (ENC1Z)		
		40: Safe torque off (STO)		
		41: Channel H1 safety circuit exception		
		(STL1)		
		42: Channel H2 safety circuit exception		
		(STL2)		
		43: Channel H1 and H2 exception (STL3)		
		44: Safety code FLASH CRC fault (CrCE)		

Function code	Name	Description	Default	Modify
		45: Programmable card customized fault 1		
		(P-E1)		
		46: Programmable card customized fault 2		
		(P-E2)		
		47: Programmable card customized fault 3		
		(P-E3)		
		48: Programmable card customized fault 4		
		(P-E4)		
		49: Programmable card customized fault 5		
		(P-E5)		
		50: Programmable card customized fault 6		
		(P-E6)		
		51: Programmable card customized fault 7		
		(P-E7)		
		52: Programmable card customized fault 8		
		(P-E8)		
		53: Programmable card customized fault 9		
		(P-E9)		
		54: Programmable card customized fault 10		
		(P-E10)		
		55: Duplicate card type (E-Err)		
		56: Encoder UVW loss fault (ENCUV)		
		57: PROFIBUS communication fault (E-PN)		
		58: CANopen communication fault (SECAN)		
		59: Motor over-temperature fault (OT)		
		60: Failure to identify the card at slot 1 (F1-Er)		
		61: Failure to identify the card at slot 2 (F2-Er)		
		62: Failure to identify the card at slot 3 (F3-Er)		
		63: Communication timeout of the card at slot		
		1 (C1-Er)		
		64: Communication timeout of the card at slot		
		2 (C2-Er)		
		65: Communication timeout of the card at slot		
		3 (C3-Er)		
		66: EtherCAT communication fault (E-CAT)		
		67: Bacnet communication fault (E-BAC)		
		68: DeviceNet communication fault (E-DEV)		
		69: CAN slave fault in master/slave		

Function code	Name	Description	Default	Modify
		synchronization (S-Err) 70: EC PT100 detected overheating (OtE1) 71: EC PT1000 detected overheating (OtE2) 72: EtherNet/IP communication timeout (E-EIP)		
		73: No upgrade bootload (E-PAO) 74: Al1 disconnected (E-Al1) 75: Al2 disconnected (E-Al2) 76: Al3 disconnected (E-Al3)		
P07.33	Running frequency at present fault	0.00Hz-P00.03	0.00Hz	•
P07.34	Ramp reference frequency at present fault	0.00Hz–P00.03	0.00Hz	•
P07.35	Output voltage at present fault	0–1200V	0V	•
P07.36	Output current at present fault	0.0–6300.0A	0.0A	•
P07.37	Bus voltage at present fault	0.0–2000.0V	0.0V	•
P07.38	Max. temperature at present fault	-20.0–120.0°C	0.0°C	•
P07.39	Input terminal status at present fault	0x0000-0xFFFF	0	•
P07.40	Output current status at present fault	0x0000–0xFFFF	0	•
P07.41	Running frequency at last fault	0.00Hz–P00.03	0.00Hz	•
P07.42	Ramp reference frequency at last fault	0.00Hz-P00.03	0.00Hz	•
P07.43	Output voltage at last fault	0–1200V	0V	•
P07.44	Output current at last fault	0.0–6300.0A	0.0A	•
P07.45	Bus voltage at last	0.0–2000.0V	0.0V	•

Function code	Name	Description	Default	Modify
	fault			
P07.46	Max. temperature at last fault	-20.0–120.0°C	0.0°C	•
P07.47	Input terminal status at last fault	0x0000–0xFFFF	0	•
P07.48	Output terminal status at last fault	0x0000–0xFFFF	0	•
P07.49	Running frequency at 2nd-last fault	0.00Hz–P00.03	0.00Hz	•
P07.50	Ramp reference frequency at 2nd-last fault	0.00Hz-P00.03	0.00Hz	•
P07.51	Output voltage at 2nd-last fault	0–1200V	0V	•
P07.52	Output current at 2nd-last fault	0.0–6300.0A	0.0A	•
P07.53	Bus voltage at 2nd-last fault	0.0–2000.0V	0.0V	•
P07.54	Max. temperature at 2nd-last fault	-20.0–120.0°C	0.0°C	•
P07.55	Input terminal status at 2nd-last fault	0x0000–0xFFFF	0x0000	•
P07.56	Output terminal status at 2nd-last fault	0x0000-0xFFFF	0x0000	•

## P08—Enhanced functions

Function code	Name	Description	Default	Modify
P08.00	ACC time 2		Model depended	0
P08.01	DEC time 2	For details, see P00.11 and P00.12. The VFD has four groups of ACC/DEC time,	Model depended	0
P08.02	ACC time 3	which can be selected by P05. The factory default ACC/DEC time of the VFD is the first	Model depended	0
P08.03	DEC time 3	group. Setting range: 0.0–3600.0s	Model depended	0
P08.04	ACC time 4		Model	0

Function code	Name	Description	Default	Modify
			depended	
P08.05	DEC time 4		Model	0
F00.05	DEC time 4		depended	0
P08.06	Running frequency of jog	Used to define the reference frequency during jogging. Setting range: 0.00Hz-P00.03 (Max. output frequency)	5.00Hz	0
P08.07	ACC time for jog	ACC time for jogging means the time needed	Model	0
P08.08	DEC time for jog	for the VFD to accelerate from 0Hz to the max. output frequency ( <u>P00.03</u> ).  DEC time for jogging means the time needed for the VFD to decelerate from the max. output frequency ( <u>P00.03</u> ) to 0Hz.  Setting range: 0.0–3600.0s	Model depended	0
P08.09	Jump frequency 1	When the set frequency is within the range of jump frequency, the VFD runs at the	0.00Hz	0
P08.10	Jump frequency amplitude 1	boundary of jump frequency. The VFD can avoid mechanical resonance	0.00Hz	0
P08.11	Jump frequency 2	points by setting jump frequencies. The VFD supports the setting of three jump	0.00Hz	0
P08.12	Jump frequency amplitude 2	frequencies. If the jump frequency points are set to 0, this function is invalid.	0.00Hz	0
P08.13	Jump frequency 3	Jump frequency 3 1/2* jump amplitude 3	0.00Hz	0
P08.14	Jump frequency amplitude 3	Jump frequency 2 1,22° jump amplitude 2 1,12° jump amplitude 2 1,12° jump amplitude 2 1,12° jump amplitude 1 1,12° jump amplitude 1 1,12° jump amplitude 1 Time t  Setting range: 0.00Hz–P00.03 (Max. output frequency)	0.00Hz	0
P08.15	Amplitude of wobbling frequency	0.0-100.0% (of the set frequency)	0.0%	0
P08.16	Amplitude of sudden jump frequency	0.0–50.0% (of the amplitude of wobbling frequency)	0.0%	0
P08.17	Rise time of wobbling frequency	0.1–3600.0s	5.0s	0

Function code	Name	Description	Default	Modify
P08.18	Fall time of wobbling frequency	0.1–3600.0s	5.0s	0
P08.19	Switching frequency of ACC/DEC time	0.00– <u>P00.03</u> (Max. output frequency) 0.00Hz: No switchover If the running frequency is greater than <u>P08.19</u> , switch to ACC/DEC time 2.	0.00Hz	0
P08.20	Frequency threshold of the start of droop control	0.00–50.00Hz	2.00Hz	0
P08.21	Reference frequency of ACC/DEC time	O: Max. output frequency 1: Set frequency 2: 100Hz  Note: Valid only for straight-line ACC/DEC	0	0
P08.22	Output torque calculation method	Based on torque current     Based on output power	0	0
P08.23	Number of decimal points of frequency	' '	0	0
P08.24	Number of decimal places of linear speed	0: No decimal place 1: One 2: Two 3: Three	0	0
P08.25	Set counting value	P08.26-65535	0	0
P08.26	Designated counting value	0– <u>P08.25</u>	0	0
P08.27	Set running time	0-65535min	0min	0
P08.28	Auto fault reset count	Auto fault reset count: When the VFD uses automatic fault reset, it is used to set the	0	0
P08.29	Auto fault reset interval	number of automatic fault reset times. When the number of continuous reset times exceeds the value, the VFD reports a fault and stops.  Auto fault reset interval: Time interval from when a fault occurred to when automatic fault reset takes effect.  After VFD starts, If no fault occurred within 600s after the VFD starts, the number of	1.0s	0

Function code	Name	Description	Default	Modify
		automatic fault reset times is cleared. Setting range of P08.28: 0–10 Setting range of P08.29: 0.1–3600.0s		
P08.30	Frequency decrease ratio in drop control	The output frequency of the VFD changes as the load changes. The function code is mainly used to balance the power when several motors drive a same load.  Setting range: 0.00–50.00Hz	0.00Hz	0
P08.31	Channel for switching between motor 1 and motor 2	0x00–0x14 Ones: Switchover channel 0: Switch over by terminal 1: Switch over by Modbus/Modbus TCP communication 2: Switch over by PROFIBUS/CANopen/DeviceNet communication 3: Switch over by Ethernet communication 4: Switch over by EtherCAT/PROFINET/EtherNet IP communication Tens: Motor switchover during running 0: Disable switchover during running 1: Enable switchover during running	0x00	0
P08.32	FDT1 electrical level detection value	When the output frequency exceeds the corresponding frequency of FDT electrical	50.00Hz	0
P08.33	FDT1 lagging detection value	level, the multifunction digital output terminal continuously outputs the signal of "Frequency level detection FDT". The signal is invalid only	5.0%	0
P08.34	FDT2 electrical level detection value	when the output frequency decreases to a value lower than the frequency corresponding to (FDT electrical level—FDT lagging detection value).	50.00Hz	0
P08.35	FDT2 lagging		5.0%	0

Function code	Name	Description	Default	Modify
	detection value	Setting range of P08.32: 0.00Hz–P00.03 (Max. output frequency) Setting range of P08.33: 0.0–100.0% (FDT1 electrical level) Setting range of P08.34: 0.00Hz–P00.03 (Max. output frequency) Setting range of P08.35: 0.0–100.0% (FDT2 electrical level)		
P08.36	Detection value for frequency being reached	electrical level)  When the output frequency is within the detection range, the multifunction digital output terminal outputs the signal of "Frequency reached".  Set frequency  Y1, R01, R02  Setting range: 0.00Hz—P00.03 (Max. output frequency)	0.00Hz	0
P08.37	Enabling energy consumption braking	0: Disable 1: Enable	1	0
P08.38	Energy	Used to set the starting bus voltage of energy	For 220V:	0

Function code	Name	Description	Default	Modify
	consumption	consumption braking. Adjust this value	380.0V;	
	braking threshold	properly to achieve effective braking for the	For 380V:	
	voltage	load. The default value varies depending on	700.0V;	
		the voltage class.	For 660V:	
		Setting range: 200.0–2000.0V	1120.0V	
	0 1	0: Normal mode		
P08.39	Cooling-fan running	1: Permanent running after power-on	0	0
	mode	2: Running mode 2		
		0x0000-0x1121		
		Ones place: PWM mode selection		
		0: PWM mode 1, 3PH modulation and 2PH		
		modulation		
		1: PWM mode 2, 3PH modulation		
		Tens place: PWM low-speed carrier limit		
		0: Low-speed carrier limit mode 1		
		1: Low-speed carrier limit mode 2		
P08.40	PWM selection	2: No limit	0x1101	0
		Hundreds place: Deadzone compensation		
		method		
		0: Compensation method 1		
		1: Compensation method 2		
		Thousands place: PWM loading mode		
		selection		
		0: Interruptive loading		
		1: Normal loading		
		0x0000-0x1111		
		Ones place: Whether to enable		
		overmodulation		
		0: Disable overmodulation		
		1: Enable overmodulation		
	0	Tens place: Overmodulation mode		
P08.41	Overmodulation	0: Mild overmodulation	0x1001	0
	selection	1: Deepened overmodulation		
		Hundreds: Carrier frequency limit		
		0: Yes		
		1: No		
		Thousands: Output voltage compensation		
		0: No		

Function code	Name	Description	Default	Modify
		1: Yes		
P08.42	Reserved			
P08.43	Reserved			
P08.44	UP/DOWN terminal control setting	0x000–0x221  Ones place: Frequency setting selection 0: The setting made through UP/DOWN is valid. 1: The setting made through UP/DOWN is invalid.  Ones place: Frequency control selection 0: Valid only when P00.06=0 or P00.07=0 1: Valid for all frequency setting methods 2: Invalid for multi-step speed running when multi-step speed running has the priority Hundreds place: Action selection for stop 0: Setting is valid. 1: Valid during running, cleared after stop 2: Valid during running, cleared after a stop command is received	0x000	0
P08.45	Frequency increment integral rate of the UP terminal	0.01–50.00Hz/s	0.50Hz/s	0
P08.46	Frequency integral rate of the DOWN terminal	0.01–50.00Hz/s	0.50Hz/s	0
P08.47	Action selection at power-off during frequency setting	0x000–0x111  Ones place: Action selection at power-off during frequency adjusting through digitals.  0: Save the setting at power-off.  1: Clear the setting at power-off.  Action selection at power-off during frequency adjusting through Modbus/ Modbus TCP communication  0: Save the setting at power-off.  1: Clear the setting at power-off.  Hundreds place: Action selection at power-off	0x000	0

Function code	Name	Description	Default	Modify
		during frequency adjusting through other communication methods 0: Save the setting at power-off. 1: Clear the setting at power-off.		
P08.48	Initial electricity consumption high-order bits	Used to set the initial electricity consumption.  Initial electricity consumption = P08.48*1000+ P08.49	0kWh	0
P08.49	Initial electricity consumption low-order bits	Setting range of <u>P08.48</u> : 0–59999 kWh (k) Setting range of <u>P08.49</u> : 0.0–999.9 kWh	0.0kWh	0
P08.50	Magnetic flux braking	Used to enable magnetic flux braking.  0: Invalid  100–150: A greater coefficient indicates greater braking strength.  The VFD can quickly slow down the motor by increasing the magnetic flux. The energy generated by the motor during braking can be transformed into heat energy by increasing the magnetic flux.  The VFD monitors the state of the motor continuously even during the magnetic flux period. Magnetic flux braking can be used for motor stop, as well as for motor rotation speed change. The other advantages include: Braking is performed immediately after the stop command is given. The braking can be started without waiting for magnetic flux weakening.  The cooling is better. The current of the stator other than the rotor increases during magnetic flux braking, while the cooling of the stator is more effective than the rotor.	0	0
P08.51	VFD input power factor	Used to adjust the display value on the AC input side. 0.00–1.00	0.56	0
P08.52	STO lock selection	0: Lock upon STO alarm Lock upon STO alarm indicates resetting is required after state restoration if STO occurs.	0	0

Function code	Name	Description	Default	Modify
		1: No lock on STO alarm No lock on STO alarm indicates STO alarm disappears automatically after state restoration if STO occurs.		
P08.53	Upper limit frequency bias value in torque control	0.00 Hz– <u>P00.03</u> (Max. output frequency) <b>Note:</b> Valid only for torque control.	0.00Hz	0
P08.54	Upper limit frequency ACC/DEC selection in torque control	0: No limit on acceleration or deceleration 1: ACC/DEC time 1 2: ACC/DEC time 2 3: ACC/DEC time 3 4: ACC/DEC time 4	0	0
P08.55	Enabling auto carrier frequency reduction	O: Disable  1: Enable  Note: Automatic carrier frequency reduction indicates that the VFD automatically reduces the carrier frequency when detecting the heat sink temperature exceeds the rated temperature. When the temperature decreases to a certain degree, the carrier frequency recovers. This function reduces the chance of VFD overheat alarm.	0	0
P08.56	Min. carrier frequency	0.0–15.0kHz	Depends on model	•
P08.57	Temperature point of auto carrier frequency reduction	40.0–85.0°C	70.0°C	0
P08.58	Interval of carrier frequency reduction	0–30min	10min	0
P08.59	Al1 disconnection detection threshold	0–100%	0	0
P08.60	Al2 disconnection detection threshold	0–100%	0	0
P08.61	AI3 disconnection detection threshold	0–100%	0	0
P08.62	Output current filter	0.000–10.000s	0.000s	0

Function code	Name	Description	Default	Modify
	time			
P08.63	Output torque filter times	0–8	8	0

### P09—PID control

Function code	Name	Description	Default	Modify
P09.00	PID reference source	When the frequency command selection (P00.06, P00.07) is 7 or the voltage setting channel selection ((P04.27) is 6, the VFD is process PID controlled.  The parameter determines the target given channel during the PID process.  0: Set by P09.01  1: Al1  2: Al2  3: Al3  4: High-speed pulse HDIA  5: Multi-step running  6: Modbus/Modbus TCP communication  7: PROFIBUS/CANopen/DeviceNet communication  8: Ethernet communication  9: High-speed pulse HDIB  10: EtherCAT/PROFINET/EtherNet IP communication  11: Programmable card  12: Reserved  The set target of process PID is a relative value, for which 100% equals 100% of the feedback signal of the controlled system.  The system always calculates a related value (0–100.0%).	0	0
P09.01	PID digital setting	The function code is mandatory when P09.00=0. The base value of The function code is the feedback of the system.  Setting range: -100.0%—100.0%	0.0%	0
P09.02	PID feedback	Used to select PID feedback channel.	0	0

Function code	Name	Description	Default	Modify
	source	0: Al1		
		1: Al2		
		2: Al3		
		3: HDIA		
		4: Modbus/Modbus TCP communication		
		5: PROFIBUS/CANopen/DevicneNET		
		communication		
		6: Ethernet communication		
		7: HDIB		
		8: EtherCAT/PROFINET/EtherNet IP		
		communication		
		9: Programmable card		
		10: Reserved		
		Note: The reference channel and feedback		
		channel cannot be duplicate. Otherwise,		
		effective PID control cannot be achieved.		
	PID output	0: PID output is positive. When the feedback		
		signal is greater than the PID reference value,		
		the output frequency of the VFD will decrease		
		to balance the PID. Example: PID control on		
Baa aa		strain during unwinding.		
P09.03	characteristics	1: PID output is negative. When the feedback	0	0
	selection	signal is greater than the PID reference value,		
		the output frequency of the VFD will increase		
		to balance the PID. Example: PID control on		
		strain during unwinding.		
		The function is applied to the proportional		
		gain P of PID input.		
		P determines the strength of the whole PID		
		adjuster. The value 100 indicates that when		
	Dranartianal gain	the difference between the PID feedback		
P09.04	Proportional gain	value and given value is 100%, the range	1.80	0
	(Kp)	within which the PID regulator can regulate		
		the output frequency command is the max.		
		frequency (ignoring integral function and		
		differential function).		
		Setting range: 0.00-100.00		
P09.05	Integral time (Ti)	It determines the speed of integral regulation	0.90s	0

Function code	Name	Description	Default	Modify
code		made on the deviation between PID feedback and reference by PID regulator. When the deviation between PID feedback and reference is 100%, the regulation of integral regulator (ignoring integral and differential actions), after undergoing continuous regulation during this time period, can reach max. output frequency (P00.03) or max. voltage (P04.31).  The shorter the integral time, the stronger the		
		regulation intensity. Setting range: 0.00–10.00s		
P09.06	Differential time (Td)	It determines the intensity of the regulation made on the change rate of deviation between PID feedback and reference by PID regulator. If feedback changes by 100% during this period, the regulation of differential regulator (ignoring integral and differential actions) is max. output frequency (P00.03) or max. voltage (P04.31).  The longer the derivative time, the stronger the regulation intensity. Setting range: 0.00–10.00s	0.00s	0
P09.07	Sampling cycle (T)	It means the sampling cycle of feedback. The regulator operates once during each sampling cycle. The larger the sampling cycle, the slower the response.  Setting range: 0.001–10.000s	0.001s	0
P09.08	Limit of PID control deviation	It is the max. allowable deviation of PID system output value relative to closed-loop reference value. Within this limit, PID regulator stops regulation. Set this function code properly to regulate the precision and stability of PID system.	0.0%	0

Function code	Name	Description	Default	Modify
		Reference Peviation limit  Output frequency 1  Time t  Setting range: 0.0–100.0%		
P09.09	Upper limit value of PID output	Used to set the upper/lower limit value of PID regulator.	100.0%	0
P09.10	Lower limit value of PID output	100.0% corresponds to Max. output frequency ( <u>P00.03</u> ) or max. voltage ( <u>P04.31</u> ). Setting range of <u>P09.09</u> : <u>P09.10</u> –100.0% Setting range of <u>P09.10</u> : -100.0%— <u>P09.09</u>	0.0%	0
P09.11	Feedback offline detection value	Set PID feedback offline detection value, when the detection value is no more than the	0.0%	0
P09.12	Feedback offline detection time	feedback offline detection value, and the duration exceeds the value set in P09.12, the VFD will report "PID feedback offline fault", and keypad displays PIDE.  Output frequency 11<72, so the VFD continues running 12=P09.12  P09.11  Fault output PIDE  Setting range of P09.11: 0.0–100.0%  Setting range of P09.12: 0.0–3600.0s	1.0s	0
P09.13	PID control selection	0x0000–0x1111 Ones place: 0: Continue integral control after the frequency reaches upper/lower limit 1: Stop integral control after the frequency	0x0001	0

Function code	Name	Description	Default	Modify
code	Name	reaches upper/lower limit Tens place: 0: The same with the main reference direction 1: Contrary to the main reference direction Hundreds place: 0: Limit based on the max. frequency 1: Limit based on A frequency Thousands place: 0: A+B frequency, acceleration /DEC of main reference A frequency source buffering is invalid 1: A+B frequency, acceleration/ DEC of main reference A frequency source buffering is	Default	Modify
_		valid, acceleration and DEC are determined by P08.04 (acceleration time 4).  0.00–100.00		
P09.14	Low-frequency proportional gain (Kp)	Low-frequency switching point: 5.00Hz, high-frequency switching point: 10.00Hz (P09.04 corresponds to high-frequency parameter), and the middle is the linear interpolation between these two points.	1.00	0
P09.15	ACC/DEC time of PID command	0.0–1000.0s	0.0s	0
P09.16	PID output filter time	0.000–10.000s	0.000s	0
P09.17	Reserved			
P09.18	Low-frequency integral time (Ti)	0.00–10.00s	0.90s	0
P09.19	Low-frequency differential time (Td)	0.00–10.00s	0.00s	0
P09.20	Low-frequency point of PID parameter switching	0.00– <u>P09.21</u>	5.00Hz	0
P09.21	High-frequency point of PID parameter switching	P09.20-P00.04	10.00Hz	0
P09.22-	Reserved			

Function code	Name	Description	Default	Modify
P09.28				

## P10—Simple PLC and multi-step speed control

Function code	Name	Description	Default	Modify
P10.00	Simple PLC mode	O: Stop after running once; the VFD stops automatically after running for one cycle, and it can be started only after receiving running command.  1: Keep running in the final value after running once; The VFD keeps the running frequency and direction of the last section after a single cycle.  2: Cyclic running; the VFD enters the next cycle after completing one cycle until receiving stop command and stops.	0	0
P10.01	Simple PLC memory selection	O: No memory after power-off Hemory after power-off; PLC memories its running stage and frequency before power-off.	0	0
P10.02	Multi-step speed 0	Frequency setting range for steps from step 0	0.0%	0
P10.03	Running time of step 0	to step 15: -300.0–300.0%. 100.0% corresponds to the max. output frequency P00.03.	0.0s(min)	0
P10.04	Multi-step speed 1	Running time setting range for steps from step 0 to step 15: 0.0–6553.5s(min). The time	0.0%	0
P10.05	Running time of step 1	unit is specified by P10.37. When simple PLC operation is selected, it is required to set P10.02–P10.33 to determine	0.0s(min)	0
P10.06	Multi-step speed 2	the running frequency and running time of	0.0%	0
P10.07	Running time of step 2	each step.  Note: The symbol of multi-step speed determines the running direction of simple	0.0s(min)	0
P10.08	Multi-step speed 3	PLC, and the negative value means reverse	0.0%	0
P10.09	Running time of step 3	running.  Deceleration time P10.28 (two steps)  P10.30  P10.30	0.0s(min)	0
P10.10	Multi-step speed 4	P10.02	0.0%	0
P10.11	Running time of step 4	Acceleration lime (two steps) P10.06	0.0s(min)	0
P10.12	Multi-step speed 5	P10.09 P10.05 P10.07 P10.31 P10.33	0.0%	0
P10.13	Running time of step 5	When selecting multi-step speed running, the multi-step speed is within the range of -fmax-fmax, and it can be set continuously.	0.0s(min)	0

Function code	Name	Description	Default	Modify
P10.14	Multi-step speed 6	The start/stop of multi-step stop running is	0.0%	0
P10.15	Running time of step 6	also determined by P00.01. The VFD supports the setting of speeds of 16 steps, which are set by combined codes of	0.0s(min)	0
P10.16	Multi-step speed 7	multi-step terminals 1–4 (set by S terminals, corresponding to function code	0.0%	0
P10.17	Running time of step 7	P05.01–P05.06) and correspond to multi-step speed 0 to multi-step speed 15.	0.0s(min)	0
P10.18	Multi-step speed 8	Output freduency	0.0%	0
P10.19	Running time of step 8		0.0s(min)	0
P10.20	Multi-step speed 9		0.0%	0
P10.21	Running time of step 9	S 1	0.0s(min)	0
P10.22	Multi-step speed 10	S3	0.0%	0
P10.23	Running time of step 10	When terminal 1, terminal 2, terminal 3 and	0.0s(min)	0
P10.24	Multi-step speed 11	terminal 4 are OFF, the frequency input mode is set by P00.06 or P00.07. When terminal 1,	0.0%	0
P10.25	Running time of step 11	terminal 2, terminal 3 and terminal 4 are not all OFF, the frequency set by multi-step speed	0.0s(min)	0
P10.26	Multi-step speed 12	will prevail, and the priority of multi-step setting is higher than that of the keypad,	0.0%	0
P10.27	Running time of step 12	analog, high-speed pulse, PID, and communication settings. The relation between terminal 1, terminal 2,	0.0s(min)	0
P10.28	Multi-step speed 13	terminal 3 and terminal 4 are shown in the	0.0%	0
P10.29	Running time of step 13	following (T indicates terminal):  T1 OFF ON OFF ON OFF ON OFF ON ON  T2 OFF OFF ON ON OFF OFF ON ON	0.0s(min)	0
P10.30	Multi-step speed 14	T3 OFF OFF OFF ON ON ON ON	0.0%	0
P10.31	Running time of step 14	T4 OFF OFF OFF OFF OFF OFF OFF OFF OFF OF	0.0s(min)	0
P10.32	Multi-step speed 15	T1 OFF ON OFF ON OFF ON	0.0%	0
P10.33	Running time of step 15	T2 OFF OFF ON ON OFF OFF ON ON T3 OFF OFF OFF OFF ON	0.0s(min)	0
P10.34	ACC/DEC time of steps 0–7 of simple PLC	The description is as follows (St indicates step):	0x0000	0
P10.35	ACC/DEC time of steps 8–15 of		0x0000	0

Simple PLC   Code   Binary   St   DEC   DEC	
BIT3 BIT4 2 00 01 10 11  BIT7 BIT6 3 00 01 10 11	
BIT5 BIT4 2 00 01 10 11  BIT7 BIT6 3 00 01 10 11	
BIT7 BIT6 3 00 01 10 11	
BIT9 BIT8 4 00 01 10 11	
<u>BIT11</u> <u>BIT10</u> 5 00 01 10 11	
<u>BIT13</u> <u>BIT12</u> 6 00 01 10 11	
<u>BIT15</u> <u>BIT14</u> 7 00 01 10 11	
<u>BIT1</u> <u>BIT0</u> 8 00 01 10 11	
BIT3 BIT2 9 00 01 10 11	
BIT5 BIT4 10 00 01 10 11	
BIT7 BIT6 11 00 01 10 11	
BIT9 BIT8 12 00 01 10 11	
BIT11 BIT10 13 00 01 10 11	
BIT13 BIT12 14 00 01 10 11	
BIT15 BIT14 15 00 01 10 11	
Select corresponding	
acceleration/deceleration time, and then	
convert 16-bit binary number into	
hexadecimal number, finally, and then set corresponding function codes.	
ACC/DEC time 1 is set by P00.11 and P00.12; ACC/DEC time 2 is set by P08.00	
and P08.01; ACC/DEC time 3 is set by	
P08.02 and P08.03; Acceleration	
/deceleration time 4 is set by P08.04 and	
<u>P08.05</u> .	
Setting range:0x0000–0xFFFF	
0: Restart from the first step, namely if the	
P10.36 PLC restart mode VFD stops during running (caused by stop command, fault or power down), it will run	0
from the first step after restart.	

Function code	Name	Description	Default	Modify
		1: Continue running from the step frequency		
		when interruption occurred, namely if the VFD		
		stops during running (caused by stop		
		command or fault), it will record the running		
		time of current step, and enters this step		
		automatically after restart, then continue		
		running at the frequency defined by this step		
		in the remaining time.		
P10.37	Multi-step time unit	0: second; the running time of each step is		
		counted in seconds	0	(i)
		1: minute; the running time of each step is	0	0
		counted in minutes		

### P11—Protection parameters

Function code	Name	Description	Default	Modify
P11.00	Phase-loss protection	0x000–0x111 Ones place: 0: Disable software input phase loss protection 1: Enable software input phase loss protection Tens place: 0: Disable output phase loss protection 1: Enable output phase loss protection 1: Enable output phase loss protection Hundreds place: 0: Disable hardware input phase loss protection 1: Enable hardware input phase loss protection 1: Enable hardware input phase loss protection	0x110	0
P11.01	Frequency drop at transient power-off	0: Disable 1: Enable	0	0
P11.02	Energy braking in standby state	0: Enable 1: Disable	0	0
P11.03	Overvoltage stall protection	0: Disable 1: Enable	1	0

Function code	Name	Description	Default	Modify
		DC bus voltage V Overvoltage stat threehold  Time f		
	Overvoltage stall	120-150% (standard bus voltage) (380V)	136%	
P11.04	protection voltage	120-150% (standard bus voltage) (220V)	120%	0
P11.05	Current limit selection	During accelerated running, as the load is too large, the actual acceleration rate of motor is lower than that of output frequency, if no measures are taken, the VFD may trip due to overcurrent during acceleration.  0x00–0x11  Ones place: Current limit action selection 0: Invalid 1: Always valid Tens place: Hardware current limit overload alarm selection 0: Valid 1: Invalid	0x01	0
P11.06	Automatic current limit level	Current limit protection function detects output current during running, and compares it with the current-limit level defined by P11.06, if it exceeds the current-limit level, the VFD will	For G type: 160.0% For P type: 120.0%	0
P11.07	Frequency drop rate during current limit	run at stable frequency during accelerated running, or run in decreased frequency during constant-speed running; if it exceeds the current-limit level continuously, the VFD output frequency will drop continuously until reaching lower limit frequency. When the output current is detected to be lower than the current-limit level again, it will continue accelerated running.	10.00 Hz/s	0

Function code	Name	Description	Default	Modify
		Current in threshold  Output frequency f  Setting range of P11.06: 50.0–200.0%  Setting range of P11.07: 0.00–50.00Hz/s		
P11.08	Pre-alarm selection for VFD/motor OL/UL	Ox0000–0x1134 Ones place:  0: Motor overload/underload pre-alarm, relative to rated motor current.  1: VFD overload/underload pre-alarm, relative to rated VFD current.  2: VFD output torque overload/underload pre-alarm, relative to rated motor torque  3: Motor overload/underload pre-alarm. The overload is relative to the motor rated current; while the underload is relative to the motor rated power.  4: VFD overload/underload pre-alarm. The overload is relative to the VFD rated current; while the underload is relative to the VFD rated current; while the underload is relative to the VFD rated power.  Tens place:  0: The VFD continues running after overload/underload alarm.  1: The VFD continues running after overload fault.  2: The VFD continues running after overload alarm, and stops running after underload fault.  3: The VFD stops running after overload fault.  3: The VFD stops running after overload fault.  Hundreds place:  0: Always detect  1: Detect during constant-speed running Thousands place: VFD overload current	0x0000	0

Function code	Name	Description	Default	Modify
		reference selection  0: Related to current calibration coefficient  1: Irrelated to current calibration coefficient		
P11.09	Overload pre-alarm detection level	If the VFD or motor output current is larger than the overload pre-alarm detection level (P11.09), and the duration exceeds the overload pre-alarm detection time (P11.10),	G type: 150% P type: 120%	0
P11.10	Overload pre-alarm detection time	Overload pre-alarm signal will be outputted.  Overload pre-alarm  Overload pre-alarm  Overload pre-alarm  Overload pre-alarm  Overload pre-alarm  Time t  Pre-alarm time t  Pre-alarm time t  Setting range of P11.09: P11.11-200%  Setting range of P11.10: 0.1-3600.0s	1.0s	0
P11.11	Underload pre-alarm detection level	Underload pre-alarm signal will be outputted if the output current of the VFD or motor is lower than underload pre-alarm detection level	50%	0
P11.12	Underload pre-alarm detection time	( <u>P11.11</u> ), and the duration exceeds underload pre-alarm detection time ( <u>P11.12</u> ).  Setting range of <u>P11.11</u> : 0– <u>P11.09</u> Setting range of <u>P11.12</u> : 0.1–3600.0s	1.0s	0
P11.13	Fault output terminal action upon fault occurring	Used to set the action of fault output terminals at undervoltage and fault reset.  0x00–0x11  Ones place:  0: Act at undervoltage  1: Do not act at undervoltage  Tens place:  0: Act at fault reset	0x00	0

Function code	Name	Description	Default	Modify
		1: Do not act at fault reset		
P11.14	Speed deviation detection value	0.0–50.0% Used to set the speed deviation detection value.	10.0%	0
P11.15	Speed deviation detection time	Used to set the speed deviation detection time.  Note: Speed deviation protection is invalid when P11.15 is set to 0.0.  Actual detection value  Set detection value  Set detection value  11<12, the VFD continues running 12=P11.15  Setting range: 0.0-10.0s	2.0s	0
P11.16	Automatic frequency reduction during voltage drop	0–1	0	0
P11.17	Proportional coefficient of voltage regulator during undervoltage stall	Used to set the proportional coefficient of the bus voltage regulator during undervoltage stall.  Setting range:0–1000	100	0
P11.18	Integral coefficient of voltage regulator during undervoltage stall	Used to set the integral coefficient of the bus voltage regulator during undervoltage stall.  Setting range:0–1000	40	0
P11.19	Proportional coefficient of current regulator during undervoltage	Used to set the proportional coefficient of the active current regulator during undervoltage stall.	25	0

Function code	Name	Description	Default	Modify
	stall	Setting range: 0-1000		
P11.20	Integral coefficient of current regulator during undervoltage stall	Used to set the integral coefficient of the active current regulator during undervoltage stall.  Setting range: 0–2000	150	0
P11.21	Proportional coefficient of voltage regulator during overvoltage stall	Used to set the proportional coefficient of the bus voltage regulator during overvoltage stall.  Setting range: 0–1000	60	0
P11.22	Integral coefficient of voltage regulator during overvoltage stall	Used to set the integral coefficient of the bus voltage regulator during overvoltage stall. Setting range: 0–1000	10	0
P11.23	Proportional coefficient of current regulator during overvoltage stall	Used to set the proportional coefficient of the active current regulator during overvoltage stall.  Setting range: 0–1000	60	0
P11.24	· ·	Used to set the integral coefficient of the active current regulator during overvoltage stall.  Setting range: 0–2000	250	0
P11.25	Enabling VFD overload integral	0: Disable 1: Enable When the function code is set to 0, the overload timing value is reset to zero after the VFD is stopped. In this case, the determination of VFD overload takes more time, and therefore the effective protection over the VFD is weakened. When the function code is set to 1, the overload timing value is not reset, and the overload timing value is accumulative. In this case, the determination of VFD overload takes less time, and therefore the protection	0	©

Function code	Name	Description	Default	Modify
		over the VFD can be performed more quickly.		
P11.26	Reserved			
P11.27	VF vibration control method	0x00–0x11 Ones place: 0: Method 1 1: Method 2 Tens place: 0: Reserved	0x00	0
P11.28	SPO detection start delay time	1: Reserved 0.0–60.0s Note: The SPO detection is started only after the VFD runs for the delay time specified by P11.28 to advoid false alarms caused by the unstable frequency.	5.0s	0
P11.29	SPO unbalance factor	0–10	6	0
P11.30	Reserved			
P11.31	Fault severity group	0x0000-0x3333 Thousands place/Hundreds place/Tens	0x0000	0
P11.32	Fault severity group 2		0x0000	0
P11.33	Fault severity group 3	Report the fault after deceleration to stop     Pre-alarm, with the action executed	0x0000	0
P11.34	Fault severity group 4	according to P11.51 3: Screen out the fault	0x0000	0
P11.35	Fault severity group 5	<b>Note</b> : Different fault actions are taken for different fault severities. The first 10 faults are	0x0000	0
P11.36	Fault severity group 6	not grouped by severity, but each four of the subsequent faults are grouped by severity in	0x0000	0
P11.37	Fault severity group 7	ascending order from right to left in hexadecimal format, that is, from the ones	0x0000	0
P11.38	Fault severity group 8	place to the thousands place (for example, the ones place of fault severity group 1	0x0000	0
P11.39	Fault severity group	corresponds to fault 11). Group 1: Faults 11–14 (OL1, OL2, SPI, SPO)	0x0000	0
P11.40	Fault severity group 10	Group 2: Faults 15–18 (OH1, OH2, EF, CE) Group 3: Faults 19–22 (ItE, tE, EEP, PIDE)	0x0000	0

Function code	Name	Description	Default	Modify
P11.41	Fault severity group	Group 4: Faults 23–26 (bCE, END, OL3, PCE)	0x0000	0
P11.42	12	Group 5: Faults 27–30 (UPE, DNE, E-DP, E-NET)	0x0000	0
P11.43	13	Group 6: Faults 31–34 (E-CAN, ETH1, ETH2, dEu)	0x0000	0
P11.44	14	Group 7: Faults 35–38 (STo, LL, ENC1o, ENC1d)	0x0000	0
P11.45	Fault severity group 15	Group 8: Faults 39–42 (ENC1Z, STO, STL1, STL2)	0x0000	0
P11.46	Fault severity group 16	Group 9: Faults 43–46 (STL3, CrCE, P-E1, P-E2)	0x0000	0
P11.47	Fault severity group	Group 10: Faults 47–50 (P-E3, P-E4, P-E5, P-E6)	0x0000	0
P11.48	Fault severity group	Group 11: Faults 51–54 (P-E7, P-E8, P-E9, P-E10)	0x0000	0
P11.49	Fault severity group 19	Group 12: Faults 55–58 (E-Err, ENCU, E-PN, SECAN)	0x0000	0
P11.50	Fault severity group 20	Group 13: Faults 59–62 (OT, F1-Er, F2-Er, F3-Er) Group 14: Faults 63–66 (C1-Er, C2-Er, C3-Er, E-CAT) Group 15: Faults 67–70 (E-BAC, E-DEV, S-Err, OtE1) Group 16: Faults 71–75 (OtE2, E-EIP, E-PAO, E-AI1) Group 17: Faults 75–78 (E-AI2, E-AI3, Reserved, Reserved) Group 18: Faults 79–82 (Reserved, Reserved, Reserved, Reserved, Reserved) Group 19: Faults 83–86 (Reserved, Reserved, Reserved)	0x0000	0
P11.51	Action for fault pre-alarm	0-4 0: Run at the set frequency 1: Run at the output frequency at the time of fault	0	0

Function code	Name	Description	Default	Modify
		2: Run at the frequency upper limit 3: Run at the frequency lower limit 4: Run at the frequency reserved for exception		
P11.52	Frequency reserved for exception	0.00–630.00Hz	0.00Hz	0
P11.53	Fire mode function	0-2 0: Invalid 1: Fire mode 1 2: Fire mode 2 When P11.53=0, the fire mode is invalid, and the normal running mode is used. In this case, the VFD stops when encountering a fault. When the fire mode function is valid, the VFD runs at the speed specified by P11.54. When fire mode 1 is selected, the VFD always runs except when the VFD has been damaged. When fire mode 2 is selected, the VFD always runs, but the VFD stops when encountering OUT1, OUT2, OUT3, OC1, OC2, OC3, OV1, OV2, OV3, or SPO.  Note: Terminal control must be used for a fire mode. When the fire mode has lasted 5 minutes, it is reset, and no warranty of repair is processed.	0	0
P11.54	Running frequency in fire mode	0.00Hz–P00.03 (Max. output frequency)	50.00Hz	0
P11.55	Fire mode flag	0–1  Note: When the fire mode has lasted 5 minutes, it is reset, and no warranty of repair is processed.	0	•
P11.56– P11.69	Reserved			

# P12—Parameters of motor 2

Function code	Name	Description	Default	Modify
P12.00	Type of motor 2	0: Asynchronous motor (AM) 1: Synchronous motor (SM)	0	0
P12.01	Rated power of AM 2	0.1–3000.0kW	Model depended	0
P12.02	Rated frequency of AM 2	0.01Hz-P00.03 (Max. output frequency)	50.00Hz	0
P12.03	Rated speed of AM 2	1–60000rpm	Model depended	0
P12.04	Rated voltage of AM 2	0–1200V	Model depended	0
P12.05	Rated current of AM 2	0.8–6000.0A	Model depended	0
P12.06	Stator resistance of AM 2	0.001–65.535Ω	Model depended	0
P12.07	Rotor resistance of AM 2	0.001–65.535Ω	Model depended	0
P12.08	Leakage inductance of AM 2	0.1–6553.5mH	Model depended	0
P12.09	Mutual inductance of AM 2	0.1–6553.5mH	Model depended	0
P12.10	No-load current of AM 2	0.1–6553.5A	Model depended	0
P12.11	Magnetic saturation coefficient 1 of iron core of AM 2	0.0–100.0%	80%	0
P12.12	Magnetic saturation coefficient 2 of iron core of AM 2	0.0–100.0%	68%	0
P12.13	Magnetic saturation coefficient 3 of iron core of AM 2	0.0–100.0%	57%	0
P12.14	Magnetic saturation coefficient 4 of iron core of AM 2	0.0–100.0%	40%	0
P12.15	Rated power of SM 2	0.1–3000.0kW	Model depended	0

Function code	Name	Description	Default	Modify
P12.16	Rated frequency of SM 2	0.01Hz-P00.03 (Max. output frequency)	50.00Hz	0
P12.17	Number of pole pairs of SM 2	1–128	2	0
P12.18	Rated voltage of SM 2	0–1200V	Model depended	0
P12.19	Rated current of SM 2	0.8–6000.0A	Model depended	0
P12.20	Stator resistance of SM 2	0.001–65.535Ω	Model depended	0
P12.21	Direct-axis inductance of SM 2	0.01–655.35mH	Model depended	0
P12.22	Quadrature-axis inductance of SM 2	0.01–655.35mH	Model depended	0
P12.23	Counter-emf constant of SM 2	0–10000V	300	0
P12.24	Reserved			
P12.25	Reserved			
P12.26	Overload protection selection of motor 2	No protection     Common motor protection (with low-speed compensation).     Variable-frequency motor protection (without low speed compensation).	2	0
P12.27	Overload protection coefficient of motor 2	Motor overload multiples M=lout/(ln*K) In is rated motor current, lout is VFD output current, and K is motor overload protection coefficient.  A smaller value of K indicates a bigger value of M.  When M=116%, protection is performed after motor overload lasts for 1 hour; when M=150%, protection is performed after motor overload lasts for 12 minutes; when M=180%, protection is performed after motor overload lasts for 5 minutes; when M=200%, protection is performed after motor overload lasts for 60 seconds; and when M≥400%, protection is	100.0%	0

Function code	Name	Description	Default	Modify
		performed immediately.  Time (min)  Current overload  116% 150% 180% 200%		
	Power display	Setting range: 20.0% –120.0%		
P12.28	calibration coefficient of motor	0.00–3.00	1.00	0
P12.29	Parameter display selection of motor 2	O: Display by motor type. In this mode, only parameters related to the present motor type are displayed.  1: Display all. In this mode, all the motor parameters are displayed.	0	0
P12.30	System inertia of motor 2	0–30.000kgm²	0.000 kgm <sup>2</sup>	0
P12.31– P12.32	Reserved			

# P13—Control parameters of synchronous motor

Function code	Name	Description	Default value	Modify
P13.00	SM injection current	Used to set the reduction rate of the injection reactive current. When the active current of the SM increases to some extent, the injection reactive current can be reduced to improve the power factor of the motor.  Setting range: 0.0%–100.0% (of the motor rated current)	80.0%	0
P13.01	Initial pole detection	0: Invalid	0	0

Function code	Name	Description	Default value	Modify
	method	1: Pulse detection method		
		2: Pulse detection method		
P13.02	Pull-in current 1	Pull-in current is the pole positioning current. Pull-in current 1 is valid within the lower limit of pull-in current switchover frequency threshold. If you need to increase the starting torque, increase the value of the function code properly. Setting range: 0.0%–100.0% (of the motor rated current)	20.0%	0
P13.03	Pull-in current 2	Pull-in current is the pole positioning current. Pull-in current 2 is valid within the upper limit of pull-in current switchover frequency threshold. Generally, you do not need to modify the function code. Setting range: 0.0%–100.0% (of the motor rated current)	10.0%	0
P13.04	Pull-in current switchover frequency	0.0%–200.0% (of the motor rated current)	20.0%	0
P13.05	Reserved			
P13.06	Pulse current setting	Used to set the pulse current threshold when the initial magnetic pole position is detected by means of pulse. The value is a percentage in relative to the rated current of the motor. Setting range: 0.0–300.0% (of the motor rated voltage)	100.0%	0
P13.07	Reserved			
P13.08	Control parameter 1	0x0000-0xFFFF	0x0000	0
P13.09	Frequency threshold of phase-lock loop switch-in	This parameter is used to set the frequency threshold for enabling the counter-electromotive force phase-locked loop in SVC 0. When the running frequency is lower than the value of this parameter, the phase-locked loop is disabled; and when the	50.00	0

Function code	Name	Description	Default value	Modify
		running frequency is higher than that, the phase-locked loop is enabled.		
		Setting range: 0.00-655.35		
P13.10	Reserved			
P13.11	Maladjustment detection time	Used to adjust the responsiveness of anti-maladjustment function. If the load inertia is large, increase the value of the function code properly, however, the responsiveness may slow down accordingly.  Setting range: 0.0–10.0s	0.5s	0
P13.12	High-frequency compensation coefficient of SM	The function code is valid when the motor speed exceeds the rated speed. If motor oscillation occurred, adjust the function code properly.  Setting range: 0.0–100.0%	0.0%	0
P13.13	High-frequency injection current	0–300.0%	20.0%	0
P13.14– P13.19	Reserved			

### P14—Serial communication function

Function code	Name	Description	Default value	Modify
P14.00	Local communication address	Setting range: 1–247 When the master writes the slave communication address to 0 indicating a broadcast address in a frame, all the salves on the Modbus/Modbus TCP bus receive the frame but do not respond to it.  Local communication address is unique in the communication network, which is the basis for point-to-point communication between the upper computer and the VFD.  Note: The communication address of a slave cannot be set to 0.	1	0
P14.01	Communication baud rate	Used to set the data transmission speed between upper computer and the VFD.	4	0

Function code	Name	Description	Default value	Modify
		0: 1200BPS		
		1: 2400BPS		
		2: 4800BPS		
		3: 9600BPS		
		4: 19200BPS		
		5: 38400BPS		
		6: 57600BPS		
		7: 115200BPS		
		Note: The baud rate set on the VFD must be		
		consistent with that on the upper computer.		
		Otherwise, the communication fails. A greater		
		baud rate indicates faster communication.		
		The data format set on the VFD must be		
		consistent with that on the upper computer.		
		Otherwise, the communication fails.		
	Data bit check	0: No check (N, 8, 1) for RTU		
P14.02		1: Even check (E, 8, 1) for RTU	1	0
		2: Odd check (O, 8, 1) for RTU		
		3: No check (N, 8, 2) for RTU		
		4: Even check (E, 8, 2) for RTU		
		5: Odd check (O, 8, 2) for RTU		
		0–200ms		
		The parameter indicates the communication		
		response delay, that is, the interval from when		
		the VFD completes receiving data to when it		
		sends response data to the upper computer. If		
	Communication	the response delay is shorter than the VFD		
P14.03	response delay	processing time, the VFD sends response	5ms	0
	response delay	data to the upper computer after processing		
		data. If the delay is longer than the VFD		
		processing time, the VFD does not send		
		response data to the upper computer until the		
		delay is reached although data has been		
		processed.		
	RS485	0.0 (invalid)–60.0s		
P14.04	communication	When this parameter is set to 0.0, the	0.0s	0
F 14.04	timeout period	communication timeout time is invalid.		
	umeout penou	When it is set a non-zero value, the VFD		

Function code	Name	Description	Default value	Modify
		reports the "Modbus/Modbus TCP		
		communication fault" (CE) if the		
		communication interval exceeds the value.		
		In general, this parameter is set to 0.0. When		
		continuous communication is required, you		
		can set the function code to monitor		
		communication status.		
		0: Report an alarm and coast to stop		
		1: Keep running without reporting an alarm		
		2: Stop in enabled stop mode without		
P14.05	Transmission error	reporting an alarm (applicable only to	0	0
	processing	communication mode)		
		3: Stop in enabled stop mode without		
		reporting an alarm (applicable to any mode)		
		0x000–0x111		
		Ones:		
		0: Write operation has response		
		1: Write operation has no response		
		Tens:		
		0: Communication password protection is		
	Modbus	invalid		
P14.06	communication	1: Communication password protection is	0x000	0
	processing action	valid		
		Hundreds place: Valid only for RS485		
		communication		
		0: User-defined addresses specified by		
		P14.07 and P14.08 are invalid		
		1: User-defined addresses specified by		
		P14.07 and P14.08 are valid		
	User-defined			
P14.07	running command	0x0000-0xFFFF	0x2000	0
	address			
	User-defined			
P14.08	frequency setting	0x0000-0xFFFF	0x2001	0
	address			
	Modbus TCP			
P14.09	communication	0.0–60.0s	5.0s	0
	timeout time			

Function code	Name	Description	Default value	Modify
	Enabling program	0–1		
P14.10	upgrade through	0: Disable	0	0
	RS485	1: Enable		
P14.11	Bootloader software version	0.00–655.35	0.00	•
	Displaying no	0–1		
P14.12	upgrade bootloader	0: Display	0	0
	fault	1: Do not display		
P14.13– P14.47	Reserved	/	/	/
P14.48	Channel selection for mapping between PZDs and function codes	0x00–0x12 Ones place: Channel for mapping function codes to PZDs 0: Reserved 1: Group P15 2: Group P16 Tens place: Save function at power failure 0: Disable 1: Enable	0x12	0
P14.49	Mapped function code of received PZD2	0x0000-0xFFFF	0x0000	0
P14.50	Mapped function code of received PZD3	0x0000-0xFFFF	0x0000	0
P14.51	Mapped function code of received PZD4	0x0000-0xFFFF	0x0000	0
P14.52	Mapped function code of received PZD5	0x0000-0xFFFF	0x0000	0
P14.53	Mapped function code of received PZD6	0x0000-0xFFFF	0x0000	0
P14.54	Mapped function code of received PZD7	0x0000-0xFFFF	0x0000	0

Function code	Name	Description	Default value	Modify
P14.55	Mapped function code of received PZD8	0x0000-0xFFFF	0x0000	0
P14.56	Mapped function code of received PZD9	0x0000-0xFFFF	0x0000	0
P14.57	Mapped function code of received PZD10	0x0000-0xFFFF	0x0000	0
P14.58	Mapped function code of received PZD11	0x0000-0xFFFF	0x0000	0
P14.59	Mapped function code of received PZD12	0x0000-0xFFFF	0x0000	0
P14.60	Mapped function code of sent PZD2	0x0000-0xFFFF	0x0000	0
P14.61	Mapped function code of sent PZD3	0x0000_0xFFFF	0x0000	0
P14.62	Mapped function code of sent PZD4	0x0000-0xFFFF	0x0000	0
P14.63	Mapped function code of sent PZD5	0x0000_0xFFFF	0x0000	0
P14.64	Mapped function code of sent PZD6	0x0000_0xFFFF	0x0000	0
P14.65	Mapped function code of sent PZD7	0x0000_0xFFFF	0x0000	0
P14.66	Mapped function code of sent PZD8	0x0000-0xFFFF	0x0000	0
P14.67	Mapped function code of sent PZD9	0x0000-0xFFFF	0x0000	0
P14.68	Mapped function code of sent PZD10	0x0000-0xFFFF	0x0000	0
P14.69	Mapped function code of sent PZD11	0x0000-0xFFFF	0x0000	0
P14.70	Mapped function code of sent PZD12	0x0000-0xFFFF	0x0000	0

## P15—Functions of communication expansion card 1

Function code	Name	Description	Default value	Modify
P15.00	Reserved			
P15.01	Module address	0–127	2	0
P15.02	Received PZD2	0–31 0: Invalid	0	0
P15.03	Received PZD3	1: Set frequency (0–Fmax. Unit: 0.01Hz)	0	0
P15.04	Received PZD4	2: PID reference (-1000–1000, in which 1000 corresponds to 100.0%)	0	0
P15.05	Received PZD5	3: PID feedback (-1000–1000, in which 1000 corresponds to 100.0%)	0	0
P15.06	Received PZD6	4: Torque setting (-3000—+3000, in which	0	0
P15.07	Received PZD7	1000 corresponds to 100.0% of the motor rated current)	0	0
P15.08	Received PZD8	5: Setting of the upper limit of forward running	0	0
P15.09	Received PZD9	frequency (0–Fmax. Unit: 0.01 Hz) 6: Setting of the upper limit of reverse running	0	0
P15.10	Received PZD10	frequency (0-Fmax. Unit: 0.01 Hz) 7: Upper limit of electromotive torque	0	0
P15.11	Received PZD11	(0–3000, in which 1000 corresponds to	0	0
P15.12	Received PZD12	100.0% of the motor rated current) 8: Upper limit of braking torque (0–3000, in which 1000 corresponds to 100% of the motor rated current) 9: Virtual input terminal command (Range: 0x000–0x3FF, corresponding to S8/S7/S6/S5/HDIB/HDIA/S4/S3/S2/S1) 10: Virtual output terminal command (Range: 0x00–0x0F, corresponding to RO2/RO1/HDO/Y1) 11: Voltage setting (special for V/F separation) (0–1000, in which 1000 corresponds to 100% of the motor rated voltage) 12: AO1 output setting 1 (-1000—+1000, in which 1000 corresponds to 100.0%) 13: AO2 output setting 2 (-1000–1000, in which 1000 corresponds to 100.0%)	0	0

Function code	Name	Description	Default value	Modify
code		14: High-order bit of position reference (signed) 15: Low-order bit of position reference (unsigned) 16: High-order bit of position feedback (signed) 17: Low-order bit of position feedback (unsigned) 18: Position feedback setting flag (position feedback can be set only after this flag is set to 1 and then to 0) 19: Function parameter mapping (PZD2–PZD12 correspond to P14.49–P14.59)	value	
P15.13	Sent PZD2	20–31: Reserved 0–31	0	0
P15.14	Sent PZD3	0: Invalid 1: Running frequency (x100, Hz)	0	0
P15.15	Sent PZD4	2: Set frequency (x100, Hz) 3: Bus voltage (x10, V)	0	0
P15.16	Sent PZD5	4: Output voltage (x1, V)	0	0
P15.17	Sent PZD6	5: Output current (x10, A) 6: Actual output torque (x10, %)	0	0
P15.18	Sent PZD7	7: Actual output power (x10, %) 8: Rotation speed of running (x1, RPM)	0	0
P15.19	Sent PZD8	9: Linear speed of running (x1, m/s)	0	0
P15.20	Sent PZD9	10: Ramp reference frequency 11: Fault code	0	0
P15.21	Sent PZD10	12: Al1 input (x100, V) 13: Al2 input (x100, V)	0	0
P15.22	Sent PZD11	14: Al3 input (x100, V)	0	0
P15.23	Sent PZD12	15: HDIA frequency value (x100, kHz) 16: Terminal input status 17: Terminal output status 18: PID reference (x100, %) 19: PID feedback (x100, %) 20: Motor rated torque 21: High-order bit of position reference	0	0

Function code	Name	Description	Default value	Modify
code		(signed) 22: Low-order bit of position reference (unsigned) 23: High-order bit of position feedback (signed) 24: Low-order bit of position feedback (unsigned) 25: Status word 26: HDIB frequency value (x100, kHz) 27: High-order bit of PG card pulse feedback 28: Low-order bit of PG card pulse feedback 29: High-order bit of PG card pulse reference 30: Low-order bit of PG card pulse reference 31: Function parameter mapping	value	
		(PZD2–PZD12 correspond to P14.60–P14.70)		
P15.24	Reserved			
P15.25	DP communication timeout time	0.0 (invalid)–60.0s	5.0s	0
P15.26	CANopen communication timeout time	0.0 (invalid)–60.0s	5.0s	0
P15.27	CANopen communication baud rate	0-7 0: 1000kbps 1: 800kbps 2: 500kbps 3: 250kbps 4: 125kbps 5: 100kbps 6: 50kbps 7: 20kbps	3	0
P15.28	Master/slave CAN communication address	0–127	1	0
P15.29	Master/slave CAN	0: 50Kbps	2	0

Function code	Name	Description	Default value	Modify
	communication	1: 100 Kbps		
	baud rate selection	2: 125Kbps		
		3: 250Kbps		
		4: 500Kbps		
		5: 1M bps		
P15.30	Master/slave CAN communication timeout time	0.0 (invalid)–300.0s	0.0s	0
P15.31-	Danasad			
P15.42	Reserved			
P15.43	Communication control word expression format	0-1 0: Decimal format 1: Binary format	0	0

# P16—Functions of communication expansion card 2

Function code	Name	Description	Default value	Modify
P16.00-	Reserved			
P16.01	Reserved			
P16.02	Ethernet monitoring card IP address 1	0–255	192	0
P16.03	Ethernet monitoring card IP address 2	0–255	168	0
P16.04	Ethernet monitoring card IP address 3	0–255	0	0
P16.05	Ethernet monitoring card IP address 4	0–255	1	0
P16.06	Ethernet monitoring card subnet mask 1	0–255	255	0
P16.07	Ethernet monitoring card subnet mask 2	0–255	255	0
P16.08	Ethernet monitoring card subnet mask 3	0–255	255	0
P16.09	Ethernet monitoring card subnet mask 4	0–255	0	0
P16.10	Ethernet monitoring card gateway 1	0–255	192	0

Function code	Name	Description	Default value	Modify
P16.11	Ethernet monitoring card gateway 2	0–255	168	0
P16.12	Ethernet monitoring card gateway 3	0–255	0	0
P16.13	Ethernet monitoring card gateway 4	0–255	1	0
P16.14	Ethernet monitoring variable address 1	0x0000-0xFFFF	0x0000	0
P16.15	Ethernet monitoring variable address 2	0x0000-0xFFFF	0x0000	0
P16.16	Ethernet monitoring variable address 3	0x0000_0xFFFF	0x0000	0
P16.17	Ethernet monitoring variable address 4	0x0000_0xFFFF	0x0000	0
P16.18– P16.23	Reserved			
P16.24	Identification time for the expansion card in card slot 1	0.0–600.0s  If it is set to 0.0, identification fault will not be detected.	0.0s	0
P16.25	Identification time for the expansion card in card slot 2	0.0–600.0s  If it is set to 0.0, offline fault will not be detected.	0.0s	0
P16.26	Identification time for the expansion card in card slot 3	0.0–600.0s  If it is set to 0.0, offline fault will not be detected.	0.0s	0
P16.27	Communication timeout period of expansion card in card slot 1	0.0–600.0s If it is set to 0.0, offline fault will not be detected.	0.0s	0
P16.28	Communication timeout period of expansion card in card slot 2	0.0–600.0s  If it is set to 0.0, offline fault will not be detected.	0.0s	0
P16.29	Communication timeout period of expansion card in card slot 3	0.0–600.0s If it is set to 0.0, offline fault will not be detected.	0.0s	0

Function code	Name	Description	Default value	Modify
P16.30	Reserved			
P16.31	PROFINET			
	communication	0.0–60.0s	5.0s	0
	timeout time			
P16.32	Received PZD2	0–31	0	0
P16.33	Received PZD3	0: Invalid	0	0
P16.34	Received PZD4	1: Set frequency (0–Fmax. Unit: 0.01Hz) 2: PID reference (-1000–1000, in which 1000	0	0
P16.35	Received PZD5	corresponds to 100.0%)	0	0
P16.36	Received PZD6	3: PID feedback (-1000–1000, in which 1000	0	0
P16.37	Received PZD7	corresponds to 100.0%)	0	0
P16.38	Received PZD8	4: Torque setting (-3000—+3000, in which 1000 corresponds to 100.0% of the motor	0	0
P16.39	Received PZD9	rated current)	0	0
P16.40	Received PZD10	5: Setting of the upper limit of forward running	0	0
P16.41	Received PZD11	frequency (0-Fmax. Unit: 0.01 Hz)	0	0
P16.42	Received PZD12	6: Setting of the upper limit of reverse running frequency (0–Fmax. Unit: 0.01 Hz) 7: Upper limit of electromotive torque (0–3000, in which 1000 corresponds to 100.0% of the motor rated current) 8: Upper limit of braking torque (0–3000, in which 1000 corresponds to 100% of the motor rated current) 9: Virtual input terminal command (Range: 0x000–0x3FF, corresponding to S8/S7/S6/S5/HDIB/HDIA/S4/S3/S2/S1) 10: Virtual output terminal command (Range: 0x00–0x0F, corresponding to RO2/RO1/HDO/Y1) 11: Voltage setting (special for V/F separation) (0–1000, in which 1000 corresponds to 100% of the motor rated voltage) 12: AO1 output setting 1 (-1000–+1000, in which 1000 corresponds to 100.0%) 13: AO2 output setting 2 (-1000–1000, in which 1000 corresponds to 100.0%)	0	0

Function code	Name	Description	Default value	Modify
		14: High-order bit of position reference		
		(signed)		
		15: Low-order bit of position reference		
		(unsigned)		
		16: High-order bit of position feedback		
		(signed)		
		17: Low-order bit of position feedback		
		(unsigned)		
		18: Position feedback setting flag (position		
		feedback can be set only after this flag is set		
		to 1 and then to 0)		
		19: Function parameter mapping		
		(PZD2–PZD12 correspond to		
		P14.49–P14.59)		
		20–31: Reserved		
P16.43	Sent PZD2	0–31	0	0
P16.44	Sent PZD3	0: Invalid 1: Running frequency (x100, Hz)	0	0
P16.45	Sent PZD4	2: Set frequency (x100, Hz)	0	0
P16.46	Sent PZD5	3: Bus voltage (x10, V)	0	0
P16.47	Sent PZD6	4: Output voltage (x1, V)	0	0
P16.48	Sent PZD7	5: Output current (x10, A)	0	0
P16.49	Sent PZD8	6: Actual output torque (x10, %)	0	0
P16.50	Sent PZD9	7: Actual output power (x10, %)	0	0
P16.51	Sent PZD10	8: Rotation speed of running (x1, RPM) 9: Linear speed of running (x1, m/s)	0	0
P16.52	Sent PZD11	10: Ramp reference frequency	0	0
P16.53		11: Fault code		
1 10.00		12: Al1 input (x100, V)		
		13: Al2 input (x100, V)		
		14: Al3 input (x100, V)		
		15: HDIA frequency value (x100, kHz)		
	Sent PZD12	16: Terminal input status	0	0
	_	17: Terminal output status		
		18: PID reference (x100, %)		
		19: PID feedback (x100, %)		
		20: Motor rated torque		
		21: High-order bit of position reference		

Function code	Name	Description	Default value	Modify
5545		(signed)	valuo	
		22: Low-order bit of position reference		
		(unsigned)		
		23: High-order bit of position feedback		
		(signed)		
		24: Low-order bit of position feedback		
		(unsigned)		
		25: Status word		
		26: HDIB frequency value (x100, kHz)		
		27: High-order bit of PG card pulse feedback		
		28: Low-order bit of PG card pulse feedback		
		29: High-order bit of PG card pulse reference		
		30: Low-order bit of PG card pulse reference		
		31: Function parameter mapping		
		(PZD2–PZD12 correspond to		
		P14.60–P14.70)		
	Ethernet			
P16.54	IPcommunication	0.0–60.0s	5.0s	0
	timeout time			
		0–4		
		0: Self-adaptive		
P16.55	Ethernet IP	1: 100M full-duplex	0	(i)
1 10.55	communication rate	2: 100M half-duplex	O	
		3: 10M full-duplex		
		4: 10M half-duplex		
P16.56	Bluetooth pairing code	0–65535	0	•
		0–65535		
		0: No host connection		
P16.57	Bluetooth host type	1: Mobile APP	0	•
		2: Bluetooth box		
		3–65535: Reserved		
	Industrial Ethernet			
P16.58	communication	0–255	192	0
	card IP address 1			
P16.59	Industrial Ethernet	0–255	168	(O)
1 10.09	communication	200	100	

Function code	Name	Description	Default value	Modify
	card IP address 2			
P16.60	Industrial Ethernet communication card IP address 3	0–255	0	0
P16.61	Industrial Ethernet communication card IP address 4	0–255	20	0
P16.62	Industrial Ethernet communication card subnet mask 1	0–255	255	0
P16.63	Industrial Ethernet communication card subnet mask 2	0–255	255	0
P16.64	Industrial Ethernet communication card subnet mask 3	0–255	255	0
P16.65	Industrial Ethernet communication card subnet mask 4	0–255	0	0
P16.66	Industrial Ethernet communication card gateway 1	0–255	192	0
P16.67	Industrial Ethernet communication card gateway 2	0–255	168	0
P16.68	Industrial Ethernet communication card gateway 3	0–255	0	0
P16.69	Industrial Ethernet communication card gateway 4	0–255	1	0

## P17—Status viewing

Function code	Name	Description	Default value	Modify
P17.00	Set frequency	Displays current set frequency of the VFD.  Range: 0.00Hz–P00.03	50.00Hz	•

Function code	Name	Description	Default value	Modify
P17.01	Output frequency	Displays current output frequency of the VFD. Range: 0.00Hz–P00.03	0.00Hz	•
P17.02	Ramp reference frequency	Displays current ramp reference frequency of the VFD.  Range: 0.00Hz– <u>P00.03</u>	0.00Hz	•
P17.03	Output voltage	Displays current output voltage of the VFD.  Range: 0–1200V	0V	•
P17.04	Output current	Displays the valid value of current output current of the VFD. Range: 0.0–5000.0A	0.0A	•
P17.05	Motor speed	Displays current motor speed. Range: 0–65535RPM	0 RPM	•
P17.06	Torque current	Displays current torque current of the VFD.  Range: -3000.0–3000.0A	0.0A	•
P17.07	Exciting current	Displays current exciting current of the VFD. Range: -3000.0–3000.0A	0.0A	•
P17.08	Motor power	Displays current motor power; 100% relative to rated motor power, positive value is motoring state, negative value is generating state.  Range: -300.0–300.0% (relative to rated motor power)	0.0%	•
P17.09	Motor output torque	Displays current output torque of the VFD; 100% relative to rated motor torque, during forward running, positive value is motoring state, negative value is generating state, during reverse running, positive value is generating state, negative value is motoring state.  Range: -250.0–250.0%	0.0%	•
P17.10	Estimated motor frequency	Displays the estimated motor rotor frequency under open-loop vector condition.  Range: 0.00–P00.03	0.00Hz	•
P17.11	DC bus voltage	Displays current DC bus voltage of the VFD. Range: 0.0–2000.0V	0V	•
P17.12	Digital input terminal state	Displays current digital input terminal state of the VFD.	0x00	•

Function code	Name	Description	Default value	Modify
		Bit0: S1 Bit1: S2		
		Bit2: S3		
		Bit3: S4 Bit4: HDIA		
		Bit5: HDIB		
		Range: 0x00–0x3F		
		Displays current digital output terminal state of the VFD.		
		0x00-0x0F		
P17.13	Digital output	Bit0: Y1	0x00	•
	terminal state	Bit1: HDO		
		Bit2: RO1		
		Bit3: RO2		
P17.14	Digital adjustment value	Displays the regulating variable of UP/DOWN.	0.00Hz	•
	value	Range: 0.00Hz–P00.03		
P17.15	Torque reference value	Relative to percentage of the rated torque of current motor, display torque reference.  Range: -300.0%—300.0% (motor rated	0.0%	•
		current)		
P17.16	Linear speed	0–65535	0	•
P17.17	Reserved			
P17.18	Counting value	0–65535	0	•
P17.19	Al1 input voltage	Displays input signal of Al1 Range: 0.00–10.00V	0.00V	•
P17.20	Al2 input voltage	Displays input signal of Al2 Range: -10.00V–10.00V	0.00V	•
P17.21	HDIA input frequency	Displays input frequency of HDIA Range: 0.000–50.000kHz	0.000 kHz	•
P17.22	HDIB input frequency	Displays input frequency of HDIB Range: 0.000–50.000kHz	0.000 kHz	•
P17.23	PID reference value	Displays PID reference value Range: -100.0–100.0%	0.0%	•

Function code	Name	Description	Default value	Modify
P17.24	PID feedback value	Displays PID feedback value Range: -100.0–100.0%	0.0%	•
P17.25	Motor power factor	Displays the power factor of current motor.  Range: -1.00–1.00	1.00	•
P17.26	Time elapsed of this run	Displays the time elapsed of this run. Range: 0–65535min	0min	•
P17.27	Simple PLC and current step number of multi-step speed	Displays simple PLC and current step number of multi-step speed Range: 0–15	0	•
P17.28	Motor ASR controller output	Displays the speed loop ASR controller output value under vector control mode, relative to the percentage of rated torque of the motor.  Range: -300.0%—300.0% (of the rated motor current)	0.0%	•
P17.29	Pole angle of open-loop SM	Displays initial identification angle of SM Range: 0.0–360.0	0.0	•
P17.30	Phase compensation of SM	Displays phase compensation of SM Range: -180.0–180.0	0.0	•
P17.31	High-frequency superposition current of SM	0.0%–200.0% (of the rated motor current)	0.0%	•
P17.32	Motor flux linkage	0.0%–200.0%	0.0%	•
P17.33	Exciting current reference	Displays the exciting current reference value under vector control mode Range: -3000.0–3000.0A	0.0A	•
P17.34	Torque current reference	Displays torque current reference value under vector control mode Range: -3000.0–3000.0A	0.0A	•
P17.35	AC incoming current	Displays the valid value of incoming current on AC side Range: 0.0–5000.0A	0.0A	•
P17.36	Output torque	Displays output torque value, during forward running, positive value is motoring state, negative value is generating state; during reverse running, positive value is generating	0.0Nm	•

Function code	Name	Description	Default value	Modify
		state, negative value is motoring state.		
		Range: -3000.0Nm-3000.0Nm		
P17.37	Motor overload count value	0–65535	0	•
P17.38	Process PID output	-100.0%—100.0%	0.00%	•
	Function code in			
P17.39	parameter	0.00–99.00	0.00	•
	download error			
		0x000-0x123		
		Ones place: Control mode		
		0: Vector control 0		
		1: Vector control 1		
		2: Space voltage vector control		
		3: Closed-loop vector control		
P17.40	Motor control mode	Tens place: Control status	0x000	•
		0: Speed control		
		1: Torque control		
		2: Position control		
		Hundreds place: Motor number		
		0: Motor 1		
		1: Motor 2		
	Electromotive			_
P17.41	torque upper limit	0.0%–300.0% (of the motor rated current)	180.0%	•
P17.42	Braking torque	0.0%-300.0% (of the motor rated current)	180.0%	•
	upper limit	,		
	Forward rotation			
P17.43	upper-limit	0.00-P00.03	50.00Hz	
1 17.10	frequency	1	00.00112	
	in torque control			
	Reverse rotation			
P17.44	upper-limit	0.00 B00.03	50.00Hz	
P17.44	frequency	0.00– <u>P00.03</u>	30.00HZ	
	in torque control			
	Inertia			
P17.45	compensation	-100.0%—100.0%	0.0%	•
	torque			
P17.46	Friction	-100.0%—100.0%	0.0%	•

Function code	Name	Description	Default value	Modify
	compensation torque			
P17.47	Motor pole pairs	0–65535	0	•
P17.48	VFD overload count value	0–65535	0	•
P17.49	Frequency set by A source	0.00- <u>P00.03</u>	0.00Hz	•
P17.50	Frequency set by B source	0.00- <u>P00.03</u>	0.00Hz	•
P17.51	PID proportional output	-100.0%–100.0%	0.0%	•
P17.52	PID integral output	-100.0%—100.0%	0.0%	•
P17.53	PID differential output	-100.0%—100.0%	0.0%	•
P17.54	PID present proportional gain	0.00–100.00	0.00	•
P17.55	PID present integral gain	0.00–10.00s	0.00s	•
P17.56	PID present differential time	0.00–10.00s	0.00s	•
P17.57	Peak value at 100Hz frequency component (square-wave orthogonal function detected)	0.0–300.0V  Peak value of bus voltage fluctuation at  100Hz frequency component, which is detected by using a square-wave orthogonal function	0.0V	•
P17.58	Peak value at 100Hz frequency component (sine-wave orthogonal function detected)	0.0–300.0V  Peak value of bus voltage fluctuation at  100Hz frequency component, which is detected by using a sine-wave orthogonal function	0.0V	•
P17.59– P17.63	Reserved	0–65535	0	•

## P18—Closed-loop control state check

Function code	Name	Description	Default value	Modify
P18.00	Actual frequency of encoder	The actual-measured encoder frequency; the value of forward running is positive; the value of reverse running is negative.  Range: -999.9–3276.7Hz	0.0Hz	•
P18.01	Encoder position count value	Encoder count value, quadruple frequency, Range: 0–65535	0	•
P18.02	Encoder Z pulse count value	Corresponding count value of encoder Z pulse. Range: 0–65535	0	•
P18.03	High-order bit of position reference value	High-order bit of position reference value, zero out after stop. Range: 0–30000	0	•
P18.04	Low-order bit of position reference value	Low-order bit of position reference value, zero out after stop. Range: 0–65535	0	•
P18.05	High-order bit of position feedback value	High-order bit of position feedback value, zero out after stop. Range: 0–30000	0	•
P18.06	Low-order bit of position feedback value	Low-order bit of position feedback value, zero out after stop. Range: 0–65535	0	•
P18.07	Position deviation	Deviation between current reference position and actual running position. Range: -32768–32767	0	•
P18.08	Position of position reference point	Position of reference point of Z pulse when the spindle stops accurately.  Range: 0–65535	0	•
P18.09	Present position setting of spindle	Current position setup when the spindle stops accurately. Range: 0–359.99	0.00	•
P18.10	Present position when spindle stops accurately	Current position when spindle stops accurately. Range: 0–65535	0	•
P18.11	Encoder Z pulse direction	Z pulse direction display. When the spindle stops accurately, there may be a couple of pulses' error between the position of forward	0	•

Function code	Name	Description	Default value	Modify
		and reverse orientation, which can be		
		eliminated by adjusting Z pulse direction of		
		P20.02 or exchanging phase AB of encoder.		
		0: Forward		
		1: Reverse		
P18.12	Encoder Z pulse	Reserved.	0.00	•
	angle	Range: 0.00–359.99		
P18.13	Encoder Z pulse	Reserved.	0	•
1 10.10	error times	Range: 0–65535		
	High-order bit of	Encoder pulse count value. The count value is		
P18.14	encoder pulse	accumulated only if the VFD is powered on.	0	•
	count value	0–65535		
	Low-order bit of	Encoder pulse count value. The count value is		
P18.15	encoder pulse	accumulated only if the VFD is powered on.	0	•
	count value	0–65535		
	Main control board			
P18.16	measured speed	-3276.8–3276.7Hz	0.0Hz	•
	value			
		Pulse command (A2, B2 terminal) is		
	Pulse command	converted to the set frequency, and it is valid		
P18.17	frequency	under pulse position mode and pulse speed	0.00Hz	•
	, ,	mode.		
		Range: -3276.8–3276.7Hz		
		Pulse command (A2, B2 terminal) is		
	Pulse command	converted to the set frequency, and it is valid		_
P18.18	feedforward	under pulse position mode and pulse speed	0.00Hz	•
		mode.		
		Range: -3276.8–3276.7Hz		
P18.19	Position regulator output	-327.68–327.67Hz	0.00Hz	•
P18.20	Count value of	Count value of resolver.	0	
F 10.20	resolver	Range: 0–65535	0	
		The pole position angle read according to the		
P18.21	Resolver angle	resolver-type encoder.	0.00	•
		Range: 0.00–359.99		
P18.22	Pole angle of	Current pole position.	0.00	
F 10.22	closed-loop SM	Range: 0.00–359.99	0.00	
P18.23	Status control word	0–65535	0	•

Function code	Name	Description	Default value	Modify
	3			
P18.24	High-order bit of count value of pulse reference	Pulse command (A2,B2) count value. The count value is accumulated only if the VFD is powered on. 0–65535	0	•
P18.25	Low-order bit of count value of pulse reference	Pulse command (A2,B2) count value. The count value is accumulated only if the VFD is powered on. 0–65535	0	•
P18.26	PG card measured speed value	-3276.8–3276.7Hz	0.0Hz	•
P18.27	Encoder UVW sector	0–7	0	•
P18.28	Encoder PPR (pulse-per- revolution) display	0–65535	0	•
P18.29	Angle compensation value of SM	-180.0–180.0	0.0	•
P18.30	Reserved	0–65535	0	•
P18.31	Pulse reference Z pulse value	0–65535	0	•
P18.32	Pulse-given main control board measured speed value	-3276.8–3276.7Hz	0.0Hz	•
P18.33	Pulse-given PG card measured speed value	-3276.8–3276.7Hz	0.0Hz	•
P18.34	Present encoder filter width	0–63	0	•
P18.35	8k test duration	0–65535	0	•

## P19—Expansion card state check

Function code	Name	Description	Default value	Modify
P19.00	Type of card at slot	0–65535	0	
P 19.00	1	0: No card	O	

Function code	Name	Description	Default value	Modify
P19.01	**	1: Programmable card	0	•
	2	2: I/O card		
		3: Incremental PG card		
		4: Incremental PG card with UVW		
		5: Ethernet communication card		
		6: DP communication card		
		7: Bluetooth card		
		8: Resolver PG card		
		9: CANopen communication card		
		10: WIFI card		
		11: PROFINET communication card		
		12: Sine/Cosine PG card without CD signal		
	Type of cord at alat	13: Sine/Cosine PG card with CD signal		
P19.02	Type of card at slot	14: Absolute encoder PG card	0	•
	3	15: CAN master/slave communication card		
		16: Modbus/Modbus TCP communication		
		card		
		17: EtherCAT communication card		
		18: BacNet communication card		
		19: DeviceNet communication card		
		20: PT100/PT1000 temperature detection		
		card		
		21: EtherNet IP communication card		
		22: MECHATROLINK communication card		
		23–65535: Reserved		
	Software version of			
P19.03	expansion card at	0.00–655.35	0.00	•
	slot 1			
	Software version of			
P19.04	expansion card at	0.00–655.35	0.00	•
	slot 2			
P19.05	Software version of			
	expansion card at	0.00–655.35	0.00	•
	slot 3			
P19.06	Terminal input			
	status of expansion	0x0000-0xFFFF	0x0000	•
	I/O card			
P19.07	Terminal output	0x0000-0xFFFF	0x0000	•

Function code	Name	Description	Default value	Modify
	status of expansion I/O card			
P19.08	HDI3 input frequency of expansion I/O card	0.000–50.000kHz	0.000 kHz	•
P19.09	Al3 input voltage of expansion I/O card	0.00–10.00V	0.00V	•
P19.10	EC PT100 detected temperature	-50.0–150.0°C	0.0°C	•
P19.11	EC PT100 detected digital	0–4096	0	•
P19.12	EC PT1000 detected temperature	-50.0–150.0°C	0.0°C	•
P19.13	EC PT1000 detected digital	0–4096	0	•
P19.14	Alarm display	0-4 0: No alarm 1: PT100 detected OH alarm (A-Ot1) 2: PT1000 detected OH alarm (A-Ot2) 3: PT100 disconnection alarm (A-Pt1) 4: PT1000 disconnection alarm (A-Pt2)	0	•
P19.15	VFD control word	0–65535	0	•
P19.16	VFD status word	0–65535	0	•
P19.17	Ethernet monitoring variable 1	0–65535	0	•
P19.18	Ethernet monitoring variable 2	0–65535	0	•
P19.19	Ethernet monitoring variable 3	0–65535	0	•

Function code	Name	Description	Default value	Modify
P19.20	Ethernet monitoring variable 4	0–65535	0	•
P19.21	AI/AO detected temperature	-20.0–200.0°C	0.0°C	•
P19.22– P19.39	Reserved			

### P20—Encoder of motor 1

Function code	Name	Description	Default value	Modify
P20.00	Encoder type display	O: Incremental encoder  1: Resolver-type encoder  2: Sin/Cos encoder  3: Endat absolute encoder	0	•
P20.01	Encoder pulse number	Number of pulses generated when the encoder revolves for one circle. Setting range: 0–60000	1024	0
P20.02	Encoder direction	Ones place: AB direction 0: Forward 1: Reverse Tens place: Z pulse direction (reserved) 0: Forward 1: Reverse Hundreds: CD/UVW pole signal direction 0: Forward 1: Reverse	0x000	©
P20.03	Detection time of encoder offline fault	Detection time of encoder offline fault. Setting range: 0.0–10.0s  Note: When the value is 0.0s, the fault will not be detected.	2.0s	0
P20.04	Detection time of encoder reversal fault	Detection time of encoder reversal fault. Setting range: 0.0–100.0s	0.8s	0
P20.05	Filter times of encoder detection	Setting range: 0x00–0x99 Ones place: Low-speed filter time, corresponds to 2^(0–9)x125µs.	0x33	0

Function code	Name	Description	Default value	Modify
		Tens place: High-speed filter times,		
		corresponds to2^(0-9)×125µs.		
	Speed ratio	You need to set the function code when the		
P20.06	between encoder	encoder is not installed on the motor shaft and	1 000	
P20.06	mounting shaft and	the drive ratio is not 1.	1.000	0
	motor	Setting range: 0.001–65.535		
		0x0000-0xFFFF		
		Bit0: Enable Z pulse calibration		
		Bit1: Enable encoder angle calibration		
		Bit2: Enable SVC speed measurement		
		Bit3: Reserved		
		Bit4: Reserved		
		Bit5: Reserved		
		Bit6: Enable CD signal calibration		
		Bit7: Reserved		
P20.07	Control parameters of SM	Bit8: Do not detect encoder fault during	0x0003	0
		autotuning		
		Bit9: Enable Z pulse detection optimization		
		Bit10: Enable initial Z pulse calibration		
		optimization .		
		Bit11: Reserved		
		Bit12: Clear Z pulse arrival signal after stop		
		Bit13: Reserved		
		Bit14: Detect Z pulse after one rotation		
		Bit15: Reserved		
	Enabling Z pulse offline detection	0x00–0x11		
		Ones place: Z pulse		
		0: Do not detect		
P20.08		1: Enable	0x10	0
		Tens place: UVW pulse (for SM)		
		0: Do not detect		
		1: Enable		
P20.09	Initial angle of Z pulse	Relative electric angle of encoder Z pulse and		
		motor pole position.	0.00	0
		Setting range: 0.00-359.99		
	Initial angle of the	Relative electric angle of encoder position and		
P20.10	Initial angle of the pole	motor pole position.	0.00	0
		Setting range: 0.00-359.99		

Function code	Name	Description	Default value	Modify
P20.11	Autotuning of initial angle of pole	0-3 0: No operation 1: Rotary autotuning (DC brake) 2: Static autotuning (suitable for resolver-type encoder, sin/cos with CD signal feedback) 3: Rotary autotuning (initial angle identification)	0	0
P20.12	Speed measurement optimization selection	0-2 0: No optimization 1: Optimization mode 1 2: Optimization mode 2	1	0
P20.13	CD signal zero offset gain	0–65535	0	0
P20.14	Encoder type selection	0x00-0x11 Ones place: Incremental encoder 0: without UVW 1: with UVW Tens place: Sin/Cos encoder 0: without CD signal 1: with CD signal	0x00	0
P20.15	Speed measurement mode	0: PG card 1: local; realized by HDIA and HDIB; supports incremental 24V encoder only	0	0
P20.16	Frequency division coefficient	0–255 When the function code is set to 0 or 1, frequency division of 1:1 is implemented.	0	0
P20.17	Pulse filter handling selection	0x0000–0xFFFF Bit0: Enable/disable encoder input filter 0: No filter 1: Filter Bit1: Encoder signal filter mode (set Bit0 or Bit2 to 1) 0: Self-adaptive filter 1: Use P20.18 filter parameters Bit2: Enable/disable encoder frequency-division output filter 0: No filter	0x0033	0

Function code	Name	Description	Default value	Modify
		1: Filter		
		Bit3: Enable/disable filter for		
		frequency-division output of pulse reference		
		0: No filter		
		1: Filter		
		Bit4: Enable/disable pulse reference filter		
		0: No filter		
		1: Filter		
		Bit5: Pulse reference filter mode (valid when		
		Bit4 is set to 1)		
		0: Self-adaptive filter		
		1: Use P20.19 filter parameters		
		Bit6: Frequency-divided output source setting		
		(valid only for incremental encoders)		
		0: Encoder signals		
		1: Pulse reference signals		
		Bits7–15: Reserved		
		0–63		
P20.18	Encoder pulse filter	The filtering time is P20.18*0.25µs. The value	2	0
	width	0 or 1 indicates 0.25µs.		
		0–63		
P20.19	Pulse reference	The filtering time is P20.19*0.25 µs. The value	2	0
	filter width	0 or 1 indicates 0.25 μs.		
200.00	Pulse number of		1001	
P20.20	pulse reference	0–16000	1024	0
	Enable angle			
P20.21	compensation of	0–1	0	0
	SM			
	Switchover			
	frequency threshold	0-630.00Hz		
P20.22	of speed	Note: Valid only when P20.12=0	1.00Hz	0
	measurement mode	, <u>——</u>		
	SM angle			
P20.23	compensation	-200.0–200.0%	100.0%	0
	coefficient			
	Number of pole			
P20.24	pairs in inital	1–128	2	0
<u></u>	pans in inital			

Function code	Name	Description	Default value	Modify
	magnetic pole angle autotuning			

### P21—Position control

Function code	Name	Description	Default value	Modify
P21.00	Positioning mode	0x0000–0x7121  Ones: Control mode selection  0: Speed control  1: Position control  Tens: Position command source  0: Pulse strain  1: Digital position  2: Positioning of photoelectric switch during stop  Hundreds: Position feedback source (reserved, fixed to channel P)  0: PG1  1: PG2  Thousands: Servo mode (Reserved)  0: Servo disabled, without position deviation  1: Servo disabled, with position deviation  2: Servo enabled, without position deviation  3: Servo enabled, with position deviation  4–7: Reserved  Note: In pulse train positioning mode or spindle positioning mode, when the servo enabling signal is valid, the VFD enters the servo running mode only after receiving the FWD or REV running mode.	0x0000	0
P21.01	Pulse command mode	0x0000–0x3133 Ones place: Pulse mode 0: A/B quadrature pulse; A leads B 1: A: PULSE; B: SIGN If channel B is of low electric level, the edge counts up; if channel B is of high electric level,	0x0000	0

Function code	Name	Description	Default value	Modify
		the edge counts down.		
		2: A: Positive pulse		
		Channel A is positive pulse; channel B needs		
		no wiring		
		3: A/B dual-channel pulse; channel A pulse		
		edge counts up, channel B pulse edge counts		
		down		
		Tens place: Pulse direction		
		Bit0: Set pulse direction		
		0: Forward		
		1: Reverse		
		Bit1: Set pulse direction by running direction		
		0: Disable, and BIT0 is valid;		
		1: Enable		
		Hundreds place: Frequency-multiplication		
		selection for pulse + direction (reserved)		
		0: No frequency-multiplication		
		1: Frequency-multiplication		
		Thousands place: Pulse control selection		
		Bit0: Pulse filter selection		
		0: Inertia filter		
		1: Average moving filter		
		Bit1: Overspeed control		
		0: No control		
		1: Control		
P21.02	APR gain 1	The two automatic position regulator (APR)	20.0	0
1 21.02	Ai it gair i	gains are switched based on the switching	20.0	0
		mode set in P21.04. When the spindle		
		orientation function is used, the gains are		
		switched automatically, regardless of the		
P21.03	APR gain 2	setting of P21.04. P21.03 is used for dynamic	30.0	0
		running, and P21.02 is used for maintaining		
		the locked state.		
		Setting range: 0.0–400.0		
	Switching mode of	Used to set the APR gain switching mode. To		
P21.04	position loop gain	use torque command-based switching, you need to set P21.05; and to use speed	0	0
	position toop gain	· ·		
		command-based switching, you need to set		

Function code	Name	Description	Default value	Modify
		<u>P21.06</u> .		
		0: No switching		
		2: Torque command		
		3: Speed command		
		3–5: Reserved		
P21.05	Torque command level during position gain switchover	Setting range: 0.0–100.0% (of the motor rated torque)	10.0%	0
P21.06	Speed command level during position gain switchover	0.0–100.0% (of the motor rated speed)	10.0%	0
P21.07	Smooth filter coefficient during gain switchover	Smooth filter coefficient during position gain switchover. Setting range: 0–15	5	0
P21.08	Output limit of position controller	The output limit of position regulator, if the limit value is 0, position regulator will be invalid, and no position control can be performed, however, speed control is available.  Setting range: 0.0–100.0% (of the max. output frequency P00.03)	20.0%	0
P21.09	Completion range of positioning	When the position deviation is less than P21.09, and the duration is larger than P21.10, positioning completion signal will be outputted.  Setting range: 0–1000	10	0
P21.10	Detection time for positioning completion	0.0–1000.0ms	10.0ms	0
P21.11	Numerator of position command ratio	Electronic gear ratio, used to adjust the corresponding relation between position command and actual running displacement.  Setting range: 1–65535	1000	0
P21.12	Denominator of position command ratio	Setting range: 1–65535	1000	0
P21.13	Position	0.00-120.00%	100.00%	0

Function code	Name	Description	Default value	Modify
	feedforward gain	For pulse train reference only (position control)		
P21.14	Position feedforward filter time constant	0.0–3200.0ms For pulse train reference only (position control)	3.0ms	0
P21.15	Position command filter time constant	The position feedforward filter time constant during pulse train positioning. 0.0–3200.0ms	0.0ms	0
P21.16	Digital positioning mode	0x0000–0xFFFF Bit0: Positioning mode selection 0: Relative position 1: Absolute position (home) (reserved) Bit1: Positioning cycle selection 0: Cyclic positioning by terminals 1: Automatic cyclic positioning Bit2: Cycle mode 0: Continuous 1: Repetitive (supported by automatic cyclic positioning only) Bit3: P21.17 digital setting mode 0: Incremental 1: Position type (do not support continuous mode) Bit4: Home searching mode 0: Search for the home just once 1: Search for the home during each run Bit5: Home calibration mode 0: Calibrate in real time 1: Single calibration Bit6: Positioning completion signal selection 0: Valid during the time set by P21.25 (Hold time of positioning completion signal) 1: Always valid Bit7: Initial positioning selection (for cyclic positioning by terminals) 0: Invalid (do not rotate) 1: Valid Bit8: Positioning enable signal selection (for	0x0000	0

Function code	Name	Description	Default value	Modify
		cyclic positioning by terminals only;		
		positioning function is always enabled for		
		automatic cyclic positioning)		
		0: Pulse signal		
		1: Level signal		
		Bit9: Position source		
		0: P21.17 setting		
		1: PROFIBUS/CANopen setting		
		Bit10: Whether to save encoder pulse		
		counting value at power failure		
		0: Not save		
		1: Save		
		Bit11: Reserved		
		Bit12: Positioning curve selection (reserved)		
		0: Straight line		
		1: S curve		
	<b>.</b>	Set digital positioning position.		
P21.17	Position digital	Actual position = P21.17*P21.11/P21.12	0	0
	reference	0–65535		
		0: P21.19		
		1: Al1		
D04.40	Positioning speed	2: AI2		
P21.18	setting selection	3: AI3	0	0
	-	4: High-speed pulse HDIA		
		5: High-speed pulse HDIB		
P21.19	Positioning speed	0–100.0% (of the max. frequency)	20.0%	0
	digits			
	ACC time of	Set the ACC/DEC time of positioning process.		
P21.20	positioning	ACC time of positioning means the time	3.00s	0
		needed for the VFD to accelerate from 0Hz to		
		Max. output frequency (P00.03).		
		DEC time of positioning means the time		
P21.21	DEC time of	needed for the VFD to decelerate from Max.	3.00s	0
	positioning	output frequency (P00.03) to 0hz.		
		Setting range of <u>P21.20</u> : 0.01–300.00s		
		Setting range of <u>P21.21</u> : 0.01–300.00s		
P21.22	Hold time of	Set the hold time of waiting when target	0.100s	0

Function code	Name	Description	Default value	Modify
	positioning arrival	positioning position is reached.		
		Setting range: 0.000–60.000s		
P21.23	Home search speed	0.00–50.00Hz	2.00Hz	0
P21.24	Home position offset	0–65535	0	0
		The hold time of positioning completion		
	Hold time of	signal, the function code is also valid for		
P21.25	positioning	positioning completion signal of spindle	0.200s	0
1 21.20	completion signal	orientation.		
		Setting range: 0.000–60.000s		
P21.26	Pulse superposition	<u>P21.26</u> : -9999–32767	0	0
P21.20	value	<u>P21.27</u> : 0–3000.0/ms	0	O
P21.27	Pulse superposition	The function is valid only when P00.06=12 or	0.0/22.0	0
P21.27	speed	<u>P21.00</u> =1:	8.0/ms	0
		1: Input terminal function 68		
		When the terminal rise edge is detected, the		
		pulse setting is increased by P21.26, and the		
		pulse given channel is compensated at the		
		rate specified by P21.27.		
		2: Input terminal function 67		
		When the terminal is valid, the pulse value is		
		superposed to the pulse given channel at the		
		rate specified by P21.27.		
		Note: P05.09 may have slight impact on the		
	ACC/DEC time after	actual superposition value.		
P21.28		Example:	5.0s	0
	pulse disabling	<u>P21.27</u> = 1.0/ms		
		<u>P05.05</u> = 67		
		When the S5 terminal input signal is 0.5s, the		
		actual number of pulses superposed is 500.		
		3: Input terminal function 69		
		The timing sequence of this value is the same		
		as that of the previous value, with the only		
		difference that the number is negative.		
		Note: The pulses are superposed to the pulse		
		given channels (A2 and B2), and the functions		
		such as the filter and electric cam for pulses		

Function code	Name	Description	Default value	Modify
		are valid for superposed pulses.		
		4: Input terminal function 28		
		The output terminal is valid during pulse		
		superposition, but it is invalid after pulse		
		superposition.		
	Speed feedforward	It is the filter time constant detected by pulse		
P21.29	filter time constant	train when the speed reference source is set	10.0ms	
P21.29	(pulse train speed	to pulse train (when <u>P00.06</u> =12 or <u>P00.07</u> =12	10.01118	0
	mode)	Setting range: 0–3200.0ms		
P21.30	Numerator of the	1–65535	1000	0
P21.30	2nd command ratio	1-00000	1000	0
	Pulse reference	0–2		
P21.31	speed measuring	0: Main control board	0	0
F21.31	method	1: PG card	U	O
	metriod	2: Hybrid		
P21.32	Pulse reference	0x0-0x1	0x0	©
P21.32	feedforward source	0x0=0x1	UXU	0
	Set value of			
P21.33	clearing encoder	0–65535	0	0
	count			

# P22—Spindle positioning

Function code	Name	Description	Default value	Modify
P22.00	Spindle positioning mode selection	0x0000–0xFFFF Bit0: Enable spindle positioning 0: Disable 1: Enable Bit1: Select spindle positioning reference point 0: Z pulse input 1: S2/S3/S4 terminal input Bit2: Search for reference point 0: Search the reference point only once 1: Search the reference point every time Bit3: Enable reference point calibration 0: Disable 1: Enable	0x0000	0

Function code	Name	Description	Default value	Modify
		Bit4: Positioning mode selection 1		
		0: Set direction positioning		
		1: Near-by direction positioning		
		Bit5: Positioning mode selection 2		
		0: Forward positioning		
		1: Reverse positioning		
		Bit6: Zeroing command selection		
		0: Electric level mode		
		1: Pulse mode		
		Bit7: Reference point calibration mode		
		0: Calibrate at the first time		
		1: Calibrate in real time		
		Bit8: Action selection after zeroing signal		
		cancellation (electric level type)		
		0: Switch to speed mode		
		1: Position lock mode		
		Bit9: Positioning completion signal selection		
		0: Electric level signal		
		1: Pulse signal		
		Bit10: Z pulse signal source		
		0: Motor		
		1: Spindle		
		Bits 11–15: Reserved		
		During spindle orientation, the speed of the		
	Consed of animals	position point of orientation will be searched,		
P22.01	Speed of spindle orientation	and then it will switch over to position control	10.00Hz	0
	onentation	orientation.		
		Setting range: 0.00–100.00Hz		
		DEC time of spindle orientation.		
	DEC time of animals	Spindle orientation DEC time means the time		
P22.02	DEC time of spindle orientation	needed for the VFD to decelerate from Max.	3.0s	0
	orientation	output frequency (P00.03) to 0Hz.		
		Setting range: 0.0–100.0s		
	Coindle marsing	You can select the zeroing positions of four		
P22.03	Spindle zeroing	spindles by terminals (function code 46, 47).	0	0
	position 0	Setting range: 0-65535		
P22.04	Spindle zeroing position 1	Setting range: 0–65535	0	0

Function code	Name	Description	Default value	Modify
P22.05	Spindle zeroing position 2	Setting range: 0–65535	0	0
P22.06	Spindle zeroing position 3	Setting range: 0–65535	0	0
P22.07	Spindle scale-division angle 1	You can select seven spindle scale-division values by terminals (function code 48, 49 and 50). Setting range: 0.00–359.99	15.00	0
P22.08	Spindle scale-division angle 2	Setting range: 0.00–359.99	30.00	0
P22.09	Spindle scale-division angle 3	Setting range: 0.00–359.99	45.00	0
P22.10	Spindle scale-division angle 4	Setting range: 0.00–359.99	60.00	0
P22.11	Spindle scale-division angle 5	Setting range: 0.00–359.99	90.00	0
P22.12	Spindle scale-division angle 6	Setting range: 0.00–359.99	120.00	0
P22.13	Spindle scale-division angle 7	Setting range: 0.00–359.99	180.00	0
P22.14	Spindle drive ratio	This function code sets the reduction ratio of the spindle and the mounting shaft of the encoder.  Setting range: 0.000–30.000	1.000	0
P22.15	Zero-point communication setup of spindle	P22.15 sets spindle zero-point offset, if the selected spindle zero point is P22.03, the final spindle zero point will be the sum of P22.03 and P22.15. Setting range: 0–39999	0	0
P22.16	Reserved			

Function code	Name	Description	Default value	Modify
P22.17	Reserved			
P22.18	Rigid tapping selection	Ones place: Whether to enable  0: Disable (but can be enabled through terminal, using function 58)  1: Enable (internally enabled)  Tens place: Analog input port selection  0: Invalid  1: Al1  2: Al2  3: Al3	0x00	0
P22.19	Analog filter time of rigid tapping	0.0ms-1000.0ms	1.0ms	0
P22.20	Max. frequency of rigid tapping	0.00–400.00Hz	50.00Hz	0
P22.21	Corresponding frequency of analog zero drift of rigid tapping	0.00–10.00Hz	0.00Hz	0
P22.22- P22.24	Reserved			

### P23—Vector control of motor 2

Function code	Name	Description	Default value	Modify
P23.00	Speed-loop proportional gain 1	The parameters <u>P23.00</u> – <u>P23.05</u> are	20.0	0
P23.01	Speed-loop integral time 1	applicable only to vector control mode. Below the switching frequency 1 (P23.02), the speed-loop PI parameters are: P23.00 and	0.200s	0
P23.02	Low-point frequency for switching	P23.01. Above the switching frequency 2 (P23.05), the speed-loop PI parameters are: P23.03 and P23.04. PI parameters are	5.00Hz	0
P23.03	Speed-loop proportional gain 2	obtained according to the linear change of two groups of parameters. See the following figure:	20.0	0
P23.04	Speed-loop integral		0.200s	0

Function code	Name	Description	Default value	Modify
	time 2	PI parameters		
P23.05	High-point frequency for switching	The speed loop dynamic response characteristics of vector control can be adjusted by setting the proportional coefficient and integral time of speed regulator. Increasing proportional gain or reducing integral time can accelerate dynamic response of speed loop; however, if the proportional gain is too large or integral time is too small, system oscillation and overshoot may occur; if proportional gain is too small, stable oscillation or speed offset may occur. PI parameters have a close relationship with the inertia of the system. Adjust PI parameters depending on different loads to meet various demands.  Setting range of P23.00: 0.0–200.0  Setting range of P23.01: 0.000–10.000s  Setting range of P23.02: 0.00Hz–P23.05  Setting range of P23.04: 0.000–10.000s  Setting range of P23.05: P23.02–P00.03  (Max. output frequency)	10.00Hz	0
P23.06	Speed-loop output filter	0-8 (corresponding to 0-2^8/10ms)	0	0
P23.07	Electromotive slip compensation coefficient of vector control	Slip compensation coefficient is used to adjust the slip frequency of the vector control and improve the speed control accuracy of the	100%	0
P23.08	Power-generation slip compensation coefficient of vector control	system. Adjusting the parameter properly can control the speed steady-state error. Setting range: 50–200%	100%	0

Function code	Name	Description	Default value	Modify
P23.09	Current-loop proportional	Note:  1. These two parameters are used to adjust PI	1000	0
1 25.05	coefficient P	parameters of current loop; it affects dynamic	1000	
P23.10	Current-loop integral coefficient I	response speed and control precision of the system directly. The default value needs no adjustment under common conditions;  2. Applicable to SVC mode 0 (P00.00=0), SVC mode 1 (P00.00=1), and FVC (P00.00=3) Setting range: 0–65535	1000	0
P23.11	Speed-loop differential gain	0.00-10.00s	0.00s	0
P23.12	High-frequency current-loop proportional coefficient	In the closed-loop vector control mode (P00.00=3), when the frequency is lower than the current-loop high-frequency switching threshold (P23.14), the current-loop PI	1000	0
P23.13	High-frequency current-loop integral coefficient	parameters are P23.09 and P23.10; and when the frequency is higher than the current-loop high-frequency switching	1000	0
P23.14	Current-loop high-frequency switching threshold	threshold, the current-loop PI parameters are P23.12 and P23.13.  Setting range of P23.12: 0–65535  Setting range of P23.13: 0–65535  Setting range of P23.14: 0.0–100.0% (of the max. frequency)	100.0%	0
P23.15- P23.19	Reserved			

### P24—Encoder of motor 2

Function code	Name	Description	Default value	Modify
P24.00	Encoder type display	O: Incremental encoder  1: Resolver-type encoder  2: Sin/Cos encoder  3: Endat absolute encoder	0	•
P24.01	Encoder pulse number	Number of pulses generated when the encoder revolves for one circle. Setting range: 0–60000	1024	0

Function code	Name	Description	Default value	Modify
		0x000–0x111 Ones: AB direction 0: Forward		
P24.02	Encoder direction	1: Reverse Tens: Z pulse direction (reserved) 0: Forward 1: Reverse Hundreds: CD/UVW pole signal direction 0: Forward	0x000	0
P24.03	Detection time of encoder offline fault	1: Reverse 0.0–10.0s	2.0s	0
P24.04	Detection time of encoder reversal fault	0.0–100.0s	0.8s	0
P24.05	Filter times of encoder detection	Setting range: 0x00–0x99  Ones place: Low-speed filter time, corresponds to 2^(0–9)x125µs.  Tens place: High-speed filter times, corresponds to 2^(0–9)x125µs.	0x33	0
P24.06	Speed ratio between encoder mounting shaft and motor	You need to set the function code when the encoder is not installed on the motor shaft and the drive ratio is not 1.  Setting range: 0.001–65.535	1.000	0
P24.07	Control parameters of SM	0x0000–0xFFFF Bit0: Enable/disable encoder input filter 0: No filter 1: Filter Bit1: Encoder signal filter mode 0: Self-adaptive filter 1: Use P24.18 filter parameters Bit2: Enable/disable encoder frequency-division output filter 0: No filter 1: Filter Bit3: Enable/disable pulse reference frequency-division output filter 0: No filter	0x0003	0

Function code	Name	Description	Default value	Modify
		1: Filter		
		Bit4: Enable/disable pulse reference filter		
		0: No filter		
		1: Filter		
		Bit5: Pulse reference filter mode		
		0: Self-adaptive filter		
		1: Use P24.19 filter parameters		
		Bit6: Frequency- division output source		
		setting (valid only for incremental encoders)		
		0: Encoder signals		
		1: Pulse reference signals		
		Bits 7–15: Reserved		
		0x00-0x11		
	.08 Enabling Z pulse offline detection	Ones place: Z pulse		
		0: Do not detect		
P24.08		1: Enable	0x10	0
		Tens place: UVW pulse (for SM)		
		0: Do not detect		
		1: Enable		
	latial analas 47	Relative electric angle of encoder Z pulse and		
P24.09	Initial angle of Z	motor pole position.	0.00	0
	pulse	Setting range: 0.00–359.99		
	latical annula af da	Relative electric angle of encoder position and		
P24.10	Initial angle of the	motor pole position.	0.00	0
	pole	Setting range: 0.00–359.99		
		0–3		
		0: No operation		
	Autotuning of initial	1: Rotary autotuning (DC brake)		
P24.11	Autotuning of initial	2: Static autotuning (suitable for resolver-type	0	0
	angle of pole	encoder, sin/cos with CD signal feedback)		
		3: Rotary autotuning (initial angle		
		identification)		
	Speed	0: No optimization		
P24.12	measurement	No optimization     Section 2	1	0
1 4-1.12	optimization	2: Optimization mode 2	ı	
	selection	2. Optimization mode 2		
P24.13	CD signal zero	0–65535	0	0

Function code	Name	Description	Default value	Modify
	offset gain			
P24.14	Encoder type selection	Ones place: Incremental encoder 0: without UVW 1: with UVW Tens place: Sin/Cos encoder 0: without CD signal 1: with CD signal	0x00	0
P24.15	Speed measurement mode	0: PG card 1: local; realized by HDIA and HDIB; supports incremental 24V encoder only	0	0
P24.16	Frequency division coefficient	0–255 When the function code is set to 0 or 1, frequency division of 1:1 is implemented.	0	0
P24.17	Pulse filter handling selection	0x0000–0xFFFF Bit0: Enable/disable encoder input filter 0: No filter 1: Filter Bit1: Encoder signal filter mode (set Bit0 or Bit2 to 1) 0: Self-adaptive filter 1: Use P24.18 filter parameters Bit2: Enable/disable encoder frequency-division output filter 0: No filter 1: Filter Bit3: Reserved Bit4: Enable/disable pulse reference filter 0: No filter 1: Filter Bit5: Pulse reference filter mode (valid when Bit4 is set to 1) 0: Self-adaptive filter 1: Use P24.19 filter parameters Bit6: Frequency-divided output source setting 0: Encoder signals 1: Pulse reference signals Bits7–15: Reserved	0x0033	0
P24.18	Encoder pulse filter	0–63	2	0

Function code	Name	Description	Default value	Modify
	width	The filtering time is P24.18*0.25us. The value 0 or 1 indicates 0.25µs.		
P24.19	Pulse reference filter width	0–63 The filtering time is <u>P24.19</u> *0.25us. The value 0 or 1 indicates 0.25µs.	2	0
P24.20	Pulse number of pulse reference	0–16000	1024	0
P24.21	Enable angle compensation of SM	0–1	0	0
P24.22	Switchover frequency threshold of speed measurement mode	0–630.00Hz	1.00Hz	0
P24.23	SM angle compensation coefficient	-200.0–200.0%	100.0%	0
P24.24	Number of pole pairs in inital magnetic pole angle autotuning	1–128	2	0

# P25—Expansion I/O card input functions

Function code	Name	Description	Default value	Modify
P25.00	HDI3 input type selection	0: HDI3 is high-speed pulse input 1: HDI3 is digital input	0	0
P25.01	Function of S5		0	0
P25.02	Function of S6		0	0
P25.03	Function of S7		0	0
P25.04	Function of S8	The same as those in P05	0	0
P25.05	Function of S9		0	0
P25.06	Function of S10		0	0

Function code	Name	Description	Default value	Modify
P25.07	Function of HDI3		0	0
P25.08	Expansion card input terminal polarity selection	0x00–0x7F	0x00	0
P25.09	Virtual terminal setting of expansion card	0x00–0x7F (0: Disable, 1: Enable) BIT0: S5 virtual terminal BIT1: S6 virtual terminal BIT2: S7 virtual terminal BIT3: S8 virtual terminal BIT4: S9 virtual terminal BIT5: S10 virtual terminal BIT5: HDI3 virtual terminal	0x00	0
P25.10	HDI3 switch-on delay		0.000s	0
P25.11	HDI3 switch-off delay		0.000s	0
P25.12	S5 switch-on delay		0.000s	0
P25.13	S5 switch-off delay	Used to specify the delay time corresponding to the electrical level changes when the	0.000s	0
P25.14	S6 switch-on delay	programmable input terminals switch on or switch off.	0.000s	0
P25.15	S6 switch-off delay	Si electrical level	0.000s	0
P25.16	S7 switch-on delay	Si valid //, valid ///, valid /// invalid  Switch-on Switch-off  delay delay	0.000s	0
P25.17	S7 switch-off delay	Setting range: 0.000–50.000s	0.000s	0
P25.18	S8 switch-on delay		0.000s	0
P25.19	S8 switch-off delay		0.000s	0
P25.20	S9 switch-on delay		0.000s	0
P25.21	S9 switch-off delay		0.000s	0

Function code	Name	Description	Default value	Modify
P25.22	S10 switch-on delay		0.000s	0
P25.23	S10 switch-off delay		0.000s	0
P25.24	Al3 lower limit	Used to define the relationship between the	0.00V	0
P25.25	Corresponding setting of Al3 lower limit	analog input voltage and its corresponding setting. When the analog input voltage exceeds the range from the upper limit to the lower limit, the upper limit or lower limit is	0.0%	0
P25.26	Al3 upper limit	used.	10.00V	0
P25.27	Corresponding setting of AI3 upper limit	When the analog input is current input,  0mA-20mA current corresponds to 0V-10V voltage.  In different applications, 100.0% of the analog	100.0%	0
P25.28	Al3 input filter time	setting corresponds to different nominal	0.030s	0
P25.29	Al4 lower limit	values. See the descriptions of each application section for details.	0.00V	0
P25.30	Corresponding setting of AI4 lower limit	The following figure illustrates the cases of several settings:   Corresponding setting	0.0%	0
P25.31	Al4 upper limit	100%	10.00V	0
P25.32	Corresponding setting of AI4 upper limit	0 AI AI 10V 20mA	100.0%	0
P25.33	Al4 input filter time	Input filter time: to adjust the sensitivity of analog input. Increasing the value properly can enhance analog input anti-interference but may reduce the sensitivity of analog input.  Note: Al3 and Al4 can support 0–10V/0–20mA input, when Al3 and Al4 select 0–20mA input, the corresponding voltage of 20mA is 10V.  Setting range of P25.24: 0.00V–P25.26	0.030s	0

Function code	Name	Description	Default value	Modify
Code		Setting range of P25.25: -300.0%–300.0%	value	
		Setting range of P25.26: P25.24–10.00V		
		Setting range of P25.27: -300.0%—300.0%		
		Setting range of <u>P25.28</u> : 0.000s–10.000s		
		Setting range of P25.29: 0.00V–P25.31		
		Setting range of P25.30: -300.0%–300.0%		
		Setting range of <u>P25.31</u> : <u>P25.29</u> –10.00V		
		Setting range of <u>P25.32</u> : -300.0%–300.0%		
		Setting range of <u>P25.33</u> : 0.000s–10.000s		
P25.34	HDI3 high-speed pulse input function	0: Input set through frequency 1: Count	0	0
	Lower limit		0.000	_
P25.35	frequency of HDI3	0.000 kHz – <u>P25.37</u>	kHz	0
	Corresponding			
P25.36	setting of lower limit	-300.0%—300.0%	0.0%	0
	frequency of HDI3			
P25.37	Upper limit	D25 25 50 000kHz	50.000	0
P25.37	frequency of HDI3	<u>P25.35</u> –50.000kHz	kHz	U
	Corresponding			
P25.38	setting of upper limit	-300.0%–300.0%	100.0%	0
	frequency of HDI3			
P25.39	HDI3 frequency	0.000s-10.000s	0.030s	0
	input filter time			
	Al3 input signal	Range: 0–1		
P25.40	type	0: Voltage	0	0
	,,	1: Current		
	Al4 input signal	Range: 0–1	_	
P25.41	type	0: Voltage	0	0
	· ·	1: Current		
P25.42-	Reserved			
P25.45				

# P26—Output functions of expansion I/O card

Function code	Name	Description	Default value	Modify
P26.00	HDO2 output type	0: Open collector high-speed pulse output	0	0
1 20.00	TIBOZ odipat typo	1: Open collector output	0	
P26.01	HDO2 output	Same as those in P06.01	0	0

Function code	Name	Description	Default value	Modify
P26.02	Y2 output		0	0
P26.03	Y3 output		0	0
P26.04	RO3 output		0	0
P26.05	RO4 output		0	0
P26.06	RO5 output		0	0
P26.07	RO6 output		0	0
P26.08	RO7 output		0	0
P26.09	RO8 output		0	0
P26.10	RO9 output		0	0
P26.11	RO10 output		0	0
P26.12	Expansion card output terminal polarity	0x0000-0x1FFF Bit0: Y2 Bit1: Y3 Bit2: HDO2 Bit3: RO3 Bit4: RO4 Bit5: RO5 Bit6: RO6 Bit7: RO7 Bit8: RO8 Bit9: RO9 Bit10: RO10 Bit11: RO11 Bit12: RO12	0x0000	0
P26.13	HDO2 switch-on delay		0.000s	0
P26.14	HDO2 switch-off delay	Used to specify the delay time corresponding to the electrical level changes when the programmable output terminals switch on or	0.000s	0
P26.15	Y2 switch-on delay	switch off.	0.000s	0
P26.16	Y2 switch-off delay	Y electric level	0.000s	0
P26.17	Y3 switch-on delay	inyalid	0.000s	0
P26.18	Y3 switch-off delay	Y valid Invalid /// Valid /// Valid ← Switch on →ı ← Switch off →	0.000s	0
P26.19	RO3 switch-on delay	delay delay Setting range: 0.000–50.000s  Note: P26.13 and P26.14 are valid only when	0.000s	0
P26.20	RO3 switch-off delay	P26.00=1.	0.000s	0
P26.21	RO4 switch-on		0.000s	0

Function code	Name	Description	Default value	Modify
	delay			
P26.22	RO4 switch-off		0.000s	0
F20.22	delay		0.0005	O
P26.23	RO5 switch-on		0.000s	0
1 20.25	delay		0.0003	U
P26.24	RO5 switch-off		0.000s	0
. 20.2	delay		0.0000	
P26.25	RO6 switch-on		0.000s	0
	delay			
P26.26	RO6 switch-off		0.000s	0
	delay			
P26.27	RO7 switch-on		0.000s	0
	delay			
P26.28	RO7 switch-off		0.000s	0
	delay			
P26.29	RO8 switch-on		0.000s	0
	delay RO8 switch-off			
P26.30	delay		0.000s	0
	RO9 switch-on			
P26.31	delay		0.000s	0
	RO9 switch-off			
P26.32	delay		0.000s	0
	RO10 switch-on			
P26.33	delay		0.000s	0
D00.04	RO10 switch-off			
P26.34	delay		0.000s	0
P26.35	AO2 output		0	0
P26.36	AO3 output	Same as <u>P06.14</u>	0	0
P26.37	Reserved		0	0
D26 20	AO2 output lower	Used to define the relationship between the	0.09/	0
P26.38	limit	output value and analog output. When the	0.0%	O
	AO2 output	output value exceeds the allowed range, the		
P26.39	corresponding to	output uses the lower limit or upper limit.	0.00V	0
	lower limit	When the analog output is current output,		
P26.40	AO2 output upper	1mA equals 0.5V.	100.0%	0
1 20.40	limit	In different applications, 100% corresponds to	100.076	

Function code	Name	Description	Default value	Modify
P26.41	AO2 output corresponding to upper limit	different analog outputs.	10.00V	0
P26.42	AO2 output filter time		0.000s	0
P26.43	AO3 output lower limit		0.0%	0
P26.44	AO3 output corresponding to lower limit	0.0% 100.0%  Setting range of <u>P26.38</u> : -300.0%— <u>P26.40</u> Setting range of <u>P26.39</u> : 0.00V–10.00V	0.00V	0
P26.45	AO3 output upper limit	Setting range of <u>P26.40</u> : <u>P26.38</u> –100.0% Setting range of <u>P26.41</u> : 0.00V–10.00V	100.0%	0
P26.46	AO3 output corresponding to upper limit	Setting range of <u>P26.42</u> : 0.000s–10.000s Setting range of <u>P26.43</u> : -300.0%– <u>P26.45</u> Setting range of <u>P26.44</u> : 0.00V–10.00V	10.00V	0
P26.47	AO3 output filter time	Setting range of <u>P26.45</u> : <u>P26.43</u> –300.0% Setting range of <u>P26.46</u> : 0.00V–10.00V Setting range of <u>P26.47</u> : 0.000s–10.000s	0.000s	0
P26.48- P26.52	Reserved	0–65535	0	0

# P27—Programmable expansion card functions

Function code	Name	Description	Default value	Modify
P27.00	Enabling programmable card	0–1 This function is reserved.	0	0
P27.01	I_WrP1	0–65535 Used to write a value to WrP1 of the programmable card.	0	0
P27.02	I_WrP2	0–65535 Used to write a value to WrP2 of the programmable card.	0	0
P27.03	I_WrP3	0–65535 Used to write a value to WrP3 of the programmable card.	0	0
P27.04	I_WrP4	0–65535 Used to write a value to WrP4 of the programmable card.	0	0

Function code	Name	Description	Default value	Modify
		0–65535		
P27.05	I_WrP5	Used to write a value to WrP5 of the	0	0
		programmable card.		
		0–65535		
P27.06	I_WrP6	Used to write a value to WrP6 of the	0	0
		programmable card.		
		0–65535		
P27.07	I_WrP7	Used to write a value to WrP7 of the	0	0
		programmable card.		
		0–65535		
P27.08	I_WrP8	Used to write a value to WrP8 of the	0	0
		programmable card.		
		0–65535		
P27.09	I_WrP9	Used to write a value to WrP9 of the	0	0
		programmable card.		
		0–65535		
P27.10	I_WrP10	Used to write a value to WrP10 of the	0	0
		programmable card.		
		0–1		
		Used to display the status of the		
P27.11	Programmable card	programmable card.	0	•
	status	0: Stopped		
		1: Running		
		0–65535		
P27.12	C_MoP1	Used to monitor/view the MoP1 value of the	0	•
		programmable card.		
		0–65535		
P27.13	C_MoP2	Used to monitor/view the MoP2 value of the	0	•
		programmable card.		
		0–65535		
P27.14	C_MoP3	Used to monitor/view the MoP3 value of the	0	•
		programmable card.		
		0–65535		
P27.15	C_MoP4	Used to monitor/view the MoP4 value of the	0	•
		programmable card.		
Do= 45	0 14 5-	0–65535	_	_
P27.16	C_MoP5	Used to monitor/view the MoP5 value of the	0	

Function code	Name	Description	Default value	Modify
		programmable card.		
		0–65535		
P27.17	C_MoP6	Used to monitor/view the MoP6 value of the	0	•
		programmable card.		
		0–65535		
P27.18	C_MoP7	Used to monitor/view the MoP7 value of the	0	•
		programmable card.		
		0–65535		
P27.19	C_MoP8	Used to monitor/view the MoP8 value of the	0	•
		programmable card.		
		0–65535		
P27.20	C_MoP9	Used to monitor/view the MoP9 value of the	0	•
		programmable card.		
		0–65535		
P27.21	C_MoP10	Used to monitor/view the MoP10 value of the	0	•
		programmable card.		
	Digital input	0x00-0x3F	0x00	
P27.22	terminal status of	Bit5–Bit0 indicate PS6–PS1 respectively.		•
	programmable card	Bito-Bito indicate 1 00-1 01 respectively.		
	Digital output	0x0-0x3		
P27.23	terminal status of	Bit0 indicates PRO1, and Bit1 indicates	0x0	•
	programmable card	PRO2.		
P27.24	Al1 of the	0–10.00V/0.00–20.00mA	0	
1 27.27	programmable card	Al1 value from the programmable card.	•	
P27.25	AO1 of	0–10.00V/0.00–20.00mA	0	
1 27 .20	programmable card	AO1 value from the programmable card.		
		0x00-0x28		
		Ones place: Quantity of data sent from the		
		programmable card and VFD (that is, quantity		
	Length of data sent	of data sent from the programmable card +		
P27.26	by programmable	from VFD sending table 1 + from VFD sending		
	card and PZD	table 2)	0x03	0
	communication	0: 0+24+60		
	object	1: 12+24+60		
		2: 24+24+60		
		3: 36+24+60		
		4: 48+24+60		

Function code	Name	Description	Default value	Modify
		5: 60+48+60		
		6: 72+24+60		
		7: 84+24+60		
		8: 96+96+96		
		Tens place: Card that communicates with the		
		programmable card through PZD (valid only		
		when the ones place of P27.26 is 5)		
		0: DP card		
		1: CANopen card		
		2: PN card		
		Note: P27.26 can be changed at any time, but		
		the change will only take effect after the		
		re-power on.		
	Programmable card	0–1		
P27.27	save function at	0: Disable	1	0
	power failure	1: Enable		

### P28—Master/slave control functions

Function code	Name	Description	Default value	Modify
P28.00	Master/slave mode	O: Master/slave control is invalid The local machine is a master The local machine is a slave	0	0
P28.01	Master/slave communication data selection	0: CAN 1: Reserved	0	0
P28.02	Master/slave control mode	0x000–0x112 Ones place: Master/slave running mode selection 0: Master/slave mode 0 (The master and slave adopt speed control and maintain the power balance by droop control) 1: Master/slave mode 1 (The master and slave must be in the same type of vector control mode. The master is speed control, and the slave will be forced to be in the torque control mode.	0x001	0

2: Master/slave mode 2   Start in the slave first speed mode (master/slave mode 0) and then switch to torque mode at a certain frequency point (master/slave mode 1)   Tens place: Slave start command source selection   0: Follow the master to start   1: Determined by P00.01   Hundreds place: Slave transmitting/master receiving data enable   0: Enable   1: Disable     1: Disable   1: Disable     1: Disable   1: Dis	Function code	Name	Description	Default value	Modify
torque mode at a certain frequency point (master/slave mode 1) Tens place: Slave start command source selection 0: Follow the master to start 1: Determined by P00.01 Hundreds place: Slave transmitting/master receiving data enable 0: Enable 1: Disable 1: Disable 0.0-500.0% 100.0% ○ P28.03 Slave speed gain 0.0-500.0% 100.0% ○ Speed/torque mode switching frequency point in master/slave mode 2 P28.05 Slave count 0-15 1			Start in the slave first speed mode		
Tens place: Slave start command source selection  0: Follow the master to start  1: Determined by P00.01 Hundreds place: Slave transmitting/master receiving data enable  0: Enable  1: Disable  1: Enabling EC  P1100/P11000 to detected of the responsion card (EC) with p1100.  P28.11  EC P1100 detected OH protection threshold of overheating (OH) detected by the expansion card (EC) with p1100.			, ,		
Selection   0: Follow the master to start   1: Determined by P00.01   Hundreds place: Slave transmitting/master receiving data enable   0: Enable   1: Disable			,		
0: Follow the master to start 1: Determined by P00.01 Hundreds place: Slave transmitting/master receiving data enable 0: Enable 1: Disable P28.03 Slave speed gain 0.0–500.0% 100.0% ○ Speed/torque gain 0.0–500.0% 100.0% ○ Speed/torque mode switching frequency P28.05 point in master/slave mode 2 P28.06 Slave count 0–15 1			•		
1: Determined by P00.01 Hundreds place: Slave transmitting/master receiving data enable 0: Enable 1: Disable  P28.03 Slave speed gain 0.0–500.0% 100.0% □ P28.04 Slave torque gain 0.0–500.0% 100.0% □ Speed/torque mode switching frequency P28.05 point in master/slave mode 2 P28.06 Slave count 0–15 1 □ P28.07—P28.08 Reserved  P28.09 CAN slave torque offset 0x00–0x11 Ones place: PT100 temperature detection 0: Disable 1: Enable 1: Enable  P28.10 PT100/PT1000 to detected OH protection threshold of overheating (OH) detected by the expansion card (EC) with PT100.					
Hundreds place: Slave transmitting/master receiving data enable  0: Enable 1: Disable  P28.03 Slave speed gain 0.0–500.0% 100.0% □  P28.04 Slave torque gain 0.0–500.0% 100.0% □  Speed/torque mode switching frequency P28.05 point in master/slave mode 2  P28.06 Slave count 0–15 1 □  P28.07—P28.08 CAN slave torque offset 0.00–10.00Hz  P28.09 CAN slave torque offset 0.00–100.0% 0.0% □  Enabling EC P7100 temperature detection 0.0 Disable 1: Enable 1: Enable 1: Enable 1: Enable 0.0H protection threshold 0.0H protection 0.0H protection threshold 0.0H protection 0					
0: Enable 1: Disable  P28.03 Slave speed gain 0.0-500.0% 100.0% ○ P28.04 Slave torque gain 0.0-500.0% 100.0% ○ Speed/torque mode switching frequency point in master/slave mode 2  P28.05 Slave count 0-15 1 ◎ P28.07-P28.08 Reserved  P28.09 CAN slave torque offset 0x00-0x11 Ones place: PT100 temperature detection 0: Disable 1: Enable 0H protection threshold 1: Disable 1: Enable 0H protection threshold 1: Disable 0H protection threshold of overheating (OH) detected by the expansion card (EC) with PT100. □					
1: Disable			receiving data enable		
P28.03 Slave speed gain 0.0–500.0% 100.0% □ P28.04 Slave torque gain 0.0–500.0% 100.0% □ Speed/torque mode switching frequency point in master/slave mode 2 P28.05 Slave count 0.00–10.00Hz 1 □ P28.07 Reserved P28.08 CAN slave torque offset 0.000–100.0% 0.0% □  P28.09 CAN slave torque offset 0.000–100.0% 0.0% □  P28.10 P1100/PT1000 to detect temperature detection 0.0 Disable 1.0 Enable 1.0 Enabl			0: Enable		
P28.04 Slave torque gain 0.0–500.0% 100.0%  Speed/torque mode switching frequency point in master/slave mode 2  P28.05 Slave count 0–15 1			1: Disable		
Speed/torque mode switching frequency point in master/slave mode 2  P28.05 Slave count 0-15 1  P28.07 Reserved -100.0-100.0% 0.0% 0  CAN slave torque offset 0x00-0x11 Ones place: PT100 temperature detection 0: Disable 1: Enable Tens place: PT1000 temperature detection 0: Disable 1: Enable Tens place: PT1000 temperature detection 0: Disable 1: Enable 0H protection threshold 0H protection threshold 120.0°C 0 T100.0°C 0  P28.11 Enable Protection threshold of overheating (OH) detected by the expansion card (EC) with PT100.	P28.03	Slave speed gain	0.0–500.0%	100.0%	0
switching frequency point in master/slave mode  2  P28.06 Slave count 0–15 1	P28.04	Slave torque gain	0.0–500.0%	100.0%	0
P28.05 point in master/slave mode 2  P28.06 Slave count 0–15 1		Speed/torque mode		5.00Hz	0
P28.06 Slave count 0–15 1 ©  P28.07—P28.08 Reserved  P28.09 CAN slave torque offset -100.0–100.0% 0.0% 0.0% 0  Enabling EC PT100/PT1000 to detect temperature detect temperature detect temperature detection 0: Disable 1: Enable 1: EC PT100 detected OH protection threshold 1: Enable 1: E					
P28.06 Slave count 0–15 1 ©  P28.07 Reserved  P28.09 CAN slave torque offset -100.0–100.0% 0.0% 0.0% 0.0% 0.0% 0.0% 0.0% 0.0	P28.05	•	0.00–10.00Hz		
P28.07 P28.08  Reserved  P28.09  CAN slave torque offset  Ox00-0x11 Ones place: PT100 temperature detection Enabling EC P28.10 P7100/P71000 to detect temperature  P28.11  EC PT100 detected OH protection threshold  P7100.  P28.11  P28.11  Reserved  Ox00-0x11 Ones place: PT100 temperature detection 0: Disable 1: Enable 1: Enable Protection threshold of overheating (OH) detected by the expansion card (EC) with PT100.					
P28.08 Reserved  P28.09 CAN slave torque offset  Ox00-0x11 Ones place: PT100 temperature detection Enabling EC PT100/PT1000 to detect temperature  P28.10 EC PT100 detected OH protection threshold  P28.11 OH protection threshold  P10.0-100.0%  Ox00-0x11 Ones place: PT100 temperature detection O: Disable 1: Enable Protection threshold of overheating (OH) detected by the expansion card (EC) with PT100.	P28.06	Slave count	0–15	1	0
P28.09 offset -100.0-100.0% 0.0% 0.0% 0.0% 0.0% 0.0% 0.0% 0.0		Reserved			
Ones place: PT100 temperature detection  Enabling EC  PT100/PT1000 to detect temperature  DEC PT100 detected OH protection threshold  DISABLE  P28.11  Ones place: PT100 temperature detection  D: Disable  Tens place: PT1000 temperature detection  D: Disable  Tens p	P28.09	· •	-100.0–100.0%	0.0%	0
P28.10 Enabling EC PT100/PT1000 to detect temperature  P28.11 Enable  P28.11 Enable  P28.11 P28.11 Protection threshold  P10. Disable  1: Enable  Protection threshold of overheating (OH) detected by the expansion card (EC) with PT100.			0x00–0x11		
P28.10 PT100/PT1000 to detect temperature  1: Enable  Tens place: PT1000 temperature detection 0: Disable 1: Enable  Protection threshold of overheating (OH) detected by the expansion card (EC) with PT100.			· ·		
detect temperature  Tens place: PT1000 temperature detection 0: Disable 1: Enable  PC PT100 detected OH protection threshold  PT100.  Tens place: PT1000 temperature detection 0: Disable 1: Enable 1: Enable  Protection threshold of overheating (OH) detected by the expansion card (EC) with PT100.					
0: Disable 1: Enable  Potection threshold of overheating (OH) detected by the expansion card (EC) with PT100.  120.0°C	P28.10			0x00	0
1: Enable  EC PT100 detected P28.11 OH protection threshold OH protection threshold  PT100.  1: Enable  Protection threshold of overheating (OH) detected by the expansion card (EC) with PT100.		detect temperature	·		
P28.11 EC PT100 detected OH protection threshold of overheating (OH) detected by the expansion card (EC) with PT100.					
P28.11 OH protection threshold detected by the expansion card (EC) with PT100.					
P28.11 OH protection threshold PT100.		EC PT100 detected	• ,		
threshold	P28.11	OH protection	* * *	120.0°C	0
		threshold			

Function code	Name	Description	Default value	Modify
P28.12	EC PT100 detected OH pre-alarm threshold	Pre-alarm threshold of OH detected by the EC with PT100. 0.0–150.0°C	100.0°C	0
P28.13	EC PT100 detected temperature calibration upper limit	Calibration upper limit of temperature detected by the EC with PT100. 50.0–150.0°C	120.0°C	0
P28.14	EC PT100 detected temperature calibration lower limit	Calibration lower limit of temperature detected by the EC with PT10020.0–50.0°C	10.0°C	0
P28.15	EC PT100 calibration upper limit digital	0–4096	2950	0
P28.16	EC PT100 calibration lower limit digital	0–4096	1270	0
P28.17	EC PT1000 detected OH protection threshold	0.0–150.0°C	120.0°C	0
P28.18	EC PT1000 detected OH pre-alarm threshold	0.0–150.0°C	100.0°C	0
P28.19	PT1000 detected temperature calibration upper limit	50.0–150.0°C	120.0°C	0
P28.20	EC PT1000 detected temperature calibration lower limit	-20.0–50.0°C	10.0°C	0

Function code	Name	Description	Default value	Modify
P28.21	EC PT1000 calibration upper limit digital	0–4096	3100	0
P28.22	EC PT1000 calibration lower limit digital	0–4096	1100	0
P28.23	Detecting for PT100/PT1000 disconnection from EC	0x00–0x11 Ones place: PT100 disconnection detection 0: Disable 1: Enable Tens place: PT1000 disconnection detection 0: Disable 1: Enable	0x00	0
P28.24	Enabling digital calibration in EC PT100/PT1000 temperature detection	<ul> <li>0-4</li> <li>0: Disable</li> <li>1: Enable PT100 lower limit digital calibration.</li> <li>2: Enable PT100 upper limit digital calibration.</li> <li>3: Enable PT1000 lower limit digital calibration.</li> <li>4: Enable PT1000 upper limit digital calibration.</li> </ul>	0	0
P28.25	Type of sensor for Al/AO card to detect motor temperature	0-4 0: No temperature sensor 1: PT100 2: PT1000 3: KTY84 4: PTC (Measuring resistance only) Note: Temperature is displayed through P19.11. To measure temperature, switch the output of AO1 to current, and connect one end of the temperature resistor to Al1 and AO1, and the other end to GND.	0	0
P28.26	AI/AO detected motor OH protection threshold	0.0–200.0°C  Note: When the motor temperature exceeds the threshold, the VFD releases the OT alarm.	110.0°C	0

Function code	Name	Description	Default value	Modify
P28.27	AI/AO detected motor OH	0.0–200.0°C  Note: When the motor temperature exceeds the value, the DO terminal with function 48 (Al detected motor OH pre-alarm) outputs a valid signal.	90.0°C	0

## P90—Tension control in speed mode

Function code	Name	Description	Default	Modify
P90.00	Tension control mode	O: Invalid 1: Speed mode 2: Open-loop torque mode 3: Closed-loop torque mode  Note: The value 0 indicates tension control is invalid. Select a non-0 value to enable the tension control function.	0	0
P90.01	Winding/ unwinding mode	0: Winding 1: Unwinding Note: The motor forward rotation direction is the winding direction. When using the tension control mode, check whether the motor rotation direction is correct in the winding mode; if not, change the rotation direction by swapping two phase wires of the motor. After the rotation direction is corrected, the winding mode can be switched to the unwinding mode by setting P90.01 to 1 or changing the winding/unwiding switchover terminals.	0	0
P90.02	Reel mechanical transmission rate	0.01–600.00 =Motor rotation speed/Reel rotation speed=Reel diameter/Motor shaft diameter	1.00	0
P90.03	Max. linear speed	0.0–6000.0 m/min	1000.0 m/min	0
P90.04	Input source of linear speed	0: Keypad 1: Al1 2: Al2 3: Al3 4: High-speed pulse HDI	0	0

Function code	Name	Description	Default	Modify
		5: Main traction encoder frequency-division input		
P90.05	Linear speed set through keypad	0.0–100.0%	20.0%	0
P90.06	Diameter of main traction	0.0–6000.0mm	99.0mm	0
P90.07	Main traction drive ratio	0.000–60.000	1.000	0
P90.08	Linear speed ACC time	0.00–600.00s	0.00s	0
P90.09	Linear speed DEC time	0.00–600.00s	0.00s	0
P90.10	Tension setting	0x00–0x14 Ones place: Tension setting source 0: Keypad 1: Al1 2: Al2 3: Al3 4: High-speed pulse HDI Tens place: Multiplier of max. tension (P90.12) 0: 1 1: 10	0x00	0
P90.11	Tension set through keypad	0.0–100.0%	10.0%	0
P90.12	Max. tension	When the tens place of P90.10 is 0, the setting range is 0–60000N. When the tens place of P90.10 is 1, the setting range is (0–60000)*10N.	1000N	0
P90.13	Roll diameter calculation mode	0: Not calculated 1: Al1 2: Al2 3: Al3 4: High-speed pulse HDI 5: Linear speed 6: Thickness (of wire) 7: Thickness (of strip)	0	0

Function code	Name	Description	Default	Modify
P90.14	Roll diameter calculation delay time	0.0–100.0s	1.0s	0
P90.15	Min. roll diameter	0.0mm-P90.16	50.0mm	0
P90.16	Max. roll diameter	P90.15–5000.0mm	1000.0 mm	0
P90.17	Initial roll diameter 1	P90.15-P90.16 (mm)	100.0 mm	0
P90.18	Initial roll diameter 2	P90.15–P90.16 (mm)	100.0 mm	0
P90.19	Initial roll diameter 3	P90.15–P90.16 (mm)	100.0 mm	0
P90.20	Linear speed roll diameter calculation filter time	0.000–60.000s	2.000s	0
P90.21	Linear speed roll diameter calculation restriction	0x00–0x11 Ones place: 0:No 1: Restrict changes in reverse direction Tens place: 0: No 1: Automatic restriction according to running frequency and material thickness	0x00	0
P90.22	Material thickness	0.001–65.535mm	0.010 mm	0
P90.23	Number of coils per layer	1–10000	1	0
P90.24	Revolution counting function selection	0–2 0: Digital terminal input 1: PG card input (Applicable to thickness calculation method) 2: Running frequency (No input automatic revolution counting)	0	0
P90.25	Number of pulses per revolution	1–60	1	0
P90.26	Roll diameter set value	0.0–100.0%	80.0%	0
P90.27	Roll diameter reset	0x0000–0x1111	0x1000	0

Function code	Name	Description	Default	Modify
	setting	Ones place: At stop		
		0: Remain current roll diameter		
		1: Restore to initial roll diameter		
		Tens place: Power off at running		
		0: Remain current roll diameter		
		1: Restore to initial roll diameter		
		Hundreds place: Reach the roll diameter set		
		value		
		0: Remain current roll diameter		
		1: Restore to initial roll diameter		
		Thousands place: Terminal reset limitation		
		0: Reset allowed at running		
		1: Reset only allowed at stop		
	T . DID	0–1		
P90.28	Tension PID output reference	0: Max. value	0	0
		1: Given value		
	Tension PID parameter source	0–5		
		0: First group of P90		
		1: Roll diameter (max. roll diameter)		
P90.29		2: Main reference frequency (max. Frequency)	0	0
		3: Running linear speed (max. linear speed)		
		4: Deviation (Reference 100%)		
		5: Terminal		
P90.30	Group 1	0.000–30.000	0.030	0
	proportional gain			
P90.31	Group 1 integral time	0.00-30.00s	5.00s	0
P90.32	Group 1 differential time	0.00–10.00s	0.00s	0
P90.33	Group 2	0.000–30.000	0.030	0
. 55.55	proportional gain	5.555 50.666	0.000	
P90.34	Group 2 integral time	0.00–30.00s	5.00s	0
P90.35	Group 2 differential time	0.00–10.00s	0.00s	0
P90.36	PID parameter adjustment	0.0%-P90.37	10.0%	0

Function code	Name	Description	Default	Modify
	reference point 1			
P90.37	PID parameter adjustment	P90.36–100.0%	50.0%	0
	reference point 2			
P90.38	Min. frequency for roll diameter calculation	0.00–50.00Hz	0.30Hz	0
P90.39	Min. linear speed for roll diameter calculation	0.0–100.0%	3.0%	0

## P91—Tension control in torque mode

Function code	Name	Description	Default	Modify
P91.00	Tension control zero speed reference	0-1 0: Max. linear speed 1: Max. frequency	0	0
P91.01	Tension control zero speed threshold	0.0–50.0%	3.0%	0
P91.02	Zero speed offset	0.0–50.0%	2.0%	0
P91.03	Upper-limit frequency source of torque control	<ul> <li>0-3</li> <li>0: P03.14, P03.15</li> <li>1: Forward rotation limit set by line speed</li> <li>2: Reverse rotation limit set by line speed</li> <li>3: Forward and reverse rotations limit set by line speed</li> </ul>	3	0
P91.04	Running frequency upper limit offset of tension control	0.0–100.0%	5.0%	0
P91.05	Differential separation threshold	0.0–100.0%	5.0%	0
P91.06	PID restricts reverse limit at zero speed	0–1 0: Enable 1: Disable	0	0
P91.07	Torque compensation	0x000–0x111 Ones place: Frictional torque compensation	0x000	0

Function	Nama	Description	Default	Madie.
code	Name	Description	Default	Modify
	selection	0: No		
		1: Yes		
		Tens place: Inertia compensation		
		0: No		
		1: Yes		
		Hundreds place: Compensation direction		
		0: In line with torque direction		
		1: Different from torque direction		
		0–2		
	Cuatam mashaniasi	0: No operation		
P91.08	System mechanical	1: Enable system mechanical inertia	0	0
P91.08	parameters identification	identification	U	0
	identification	2: Enable mechanical friction torque		
		identification		
	Static friction torque			
P91.09	compensation	0–100.0%	0.0%	0
	coefficient			
	Sliding friction			
D04.40	torque	0.0–100.0%	0.00/	0
P91.10	compensation		0.0%	
	coefficient 1			
	Sliding friction			
P91.11	torque	0.0.400.004	0.00/	
P91.11	compensation	0.0–100.0%	0.0%	0
	coefficient 2			
	Sliding friction			
P91.12	torque	0.0–100.0%	0.0%	0
F91.12	compensation	0.0-100.0%	0.076	
	coefficient 3			
	High speed torque			
P91.13	compensation	0.0–100.0%	0.0%	0
	coefficient			
	Compensation			
P91.14	frequency point of	0.0%-P91.15	1.0%	0
	static friction torque			
P91.15	Compensation	P91.14–P91.16 (%)	20.0%	0
P91.15	frequency point of	F 91.14=F 91.10 ( <i>//o)</i>	20.0%	

Function code	Name	Description	Default	Modify
	sliding friction			
	torque 1			
P91.16	Compensation frequency point of sliding friction torque 2	P91.15–P91.17 (%)	50.0%	0
P91.17	Compensation frequency point of sliding friction torque 3	P91.16–P91.18 (%)	80.0%	0
P91.18	High-speed friction torque compensation frequency point	P91.17–100.0%	100.0%	0
P91.19	ACC/DEC frequency source	0–1 0: Linear speed 1: Running frequency	0	0
P91.20	Material density	0–30000 kg/m <sup>3</sup>	0 kg/m <sup>3</sup>	0
P91.21	Reel width	0.000–60.000m	0.000m	0
P91.22	ACC inertia compensation coefficient	0.0–100.0%	10.0%	0
P91.23	DEC inertia compensation coefficient	0.0–100.0%	10.0%	0
P91.24	Tension taper coefficient source	0-4 0: Keypad 1: Al1 2: Al2 3: Al3 4: High-speed pulse HDI	0	0
P91.25	Tension taper set through keypad	0.0–100.0%	30.0%	0
P91.26	Tension taper compensation correction	0.0–5000.0mm	0.0mm	0
P91.27	Tension taper curve	0–1	0	0

Function code	Name	Description	Default	Modify
	selection	Inverse proportional curve     Multi-point curve		
P91.28	Roll diameter value 1	0.0–5000.0mm	200.0 mm	0
P91.29	Tension taper coefficient for roll diameter value 1	0.0–50.0%	3.0%	0
P91.30	Roll diameter value 2	0.0–5000.0mm	500.0 mm	0
P91.31	Tension taper coefficient for roll diameter value 2	0.0–50.0%	7.0%	0
P91.32	Tension offset value at zero speed	0.0–300.0%	0.0%	0
P91.33	Present roll diameter setting	0.0–5000.0mm	0.0mm	0

## P92—Customized tension control functions

Function code	Name	Description	Default	Modify
P92.00	Pre-drive speed gain	0.0–100.0%	100.0%	0
P92.01	Pre-drive torque limit	0–2 0: Set based on P03.20, P03.21 1: Set based on P93.02 2: Set based on the set tension	2	0
P92.02	Pre-drive torque limit setting	0.0–200.0%	100.0%	0
P92.03	Zero bit conversion enabling	0–1 0: Disable 1: Enable	0	0
P92.04	Initial zero bit	0.0–100.0%	10.0%	0
P92.05	Final zero bit	0.0–100.0%	50.0%	0
P92.06	Conversion time from initial zero bit to final zero bit	0.00–60.00s	5.00s	0
P92.07	Conversion time from final zero bit to	0.00-60.00s	5.00s	0

Function code	Name	Description	Default	Modify
	initial zero bit			
P92.08	Feeding interrupt detection mode	0-3 0: Not detect 1: Detect based on digital value 2: Detect based on roll diameter calculation value 3: Detect based on feedback position	0	0
P92.09	Feeding interrupt detection start delay time	0.0–200.0s	20.0s	0
P92.10	Frequency lower limit of feeding interrupt detection	0.00–300.00Hz	10.00 Hz	0
P92.11	Error range of feeding interrupt detection	0.1–50.0%	10.0%	0
P92.12	Determination delay time of feeding interrupt detection	0.1–60.0s	1.0s	0
P92.13	Handling mode of feeding interrupt	0x000–0x111  Ones place: Stop mode 0: Decelerate to stop in emergency manner 1: Coast to stop  Tens place: Alarm mode 0: Stop in enabled stop mode without reporting an alarm 1: Report an alarm and coast to stop  Hundreds place: Roll diameter memory function of feeding interrupt 0: Disable 1: Enable	0x000	0
P92.14	Stop braking frequency	0.00–300.00Hz	1.50Hz	0
P92.15	Stop braking time	0.0–600.0s	0.0s	0

# P93—Tension control status viewing

Function code	Name	Description	Default	Modify
P93.00	Actual control mode	0–3 0: Invalid tension control 1: Close-loop tension speed control 2: Open loop tension torque control 3: Close-loop tension torque control	0	•
P93.01	Actual winding/ unwinding mode	0–1 0: Winding 1: Unwinding	0	•
P93.02	Initial roll diameter	0.0–5000.0mm	0.0mm	•
P93.03	Reset roll diameter	0.0–5000.0mm	0.0mm	•
P93.04	Roll diameter change rate	0.00–655.35 mm/s	0.00 mm/s	•
P93.05	Present roll diameter	0.0–5000.0mm	0.0mm	•
P93.06	Roll diameter for linear speed calculation	0.0–5000.0mm	0.0mm	•
P93.07	Set linear speed	0.0–6000.0 m/min	0.0 m/min	•
P93.08	Present linear speed	0.0–6000.0 m/min	0.0 m/min	•
P93.09	Main reference frequency	0.00-600.00Hz	0.00 Hz	•
P93.10	Actual proportional gain	0.00–30.00	0.00	•
P93.11	Actual integral time	0.00-30.00s	0.00s	•
P93.12	Proportional output value	0–65535	0	•
P93.13	Integral output value	0–65535	0	•
P93.14	PID upper limit	-100.0–100.0%	0.0%	•
P93.15	PID lower limit	-100.0–100.0%	0.0%	•
P93.16	PID output frequency	-99.99–99.99Hz	0.00Hz	•
P93.17	Main traction running frequency	-300.0–300.0Hz	0.0Hz	•
P93.18	Set tension	0–30000N	0N	•

Function code	Name	Description	Default	Modify
P93.19	Tension taper coefficient	0.0–100.0%	0.0%	•
P93.20	Actual tension	0–30000N	0N	•
P93.21	Basic torque reference value	-300.0–300.0%	0.0%	•
P93.22	Friction compensation torque value	-300.0–300.0%	0.0%	•
P93.23	System rotational inertia	0.00–655.35 kg.m²	0.00 kg.m <sup>2</sup>	•
P93.24	Frequency change rate	-99.99–327.67 Hz/s	0.00 Hz/s	•
P93.25	Torque compensation value of system rotational inertia	-300.0–300.0%	0.0%	•
P93.26	Reference value after torque compensation	-300.0–300.0%	0.0%	•
P93.27	PID output torque	-300.0–300.0%	0.0%	•
P93.28	Final output torque	-300.0–300.0%	0.0%	•
P93.29	Measured tension	0–30000N	0N	•
P93.30	Number of material turns on the reel	-100–32767	0	•
P93.31	Length of material on the reel	0–65535m	0m	•
P93.32	Length increment	0.0–6553.5m	0.0m	•

# 7 Troubleshooting

## 7.1 What this chapter contains

The chapter instructs you how to reset faults and check faults history. A complete list of alarms and fault information as well as possible causes and corrective measures are presented in this chapter.



Only trained and qualified professionals are allowed to carry out the work described in this chapter. Operations should be carried out according to the instructions presented in Safety precautions.

### 7.2 Indications of alarms and faults

The fault is indicated by indicators (see "Operating the VFD through the keypad"). When <a href="TRIP">TRIP</a> indicator is on, the alarm or fault code displayed in the keypad indicates the VFD is in exception state. This chapter covers most of the alarms and faults, and their possible causes and corrective measures, if users cannot figure out the alarm or fault causes, contact local INVT office.

### 7.3 Fault reset

You can reset the VFD through the STOP/RST key on the keypad, digital inputs, or by cutting off the VFD power. After faults are removed, the motor can be start again.

## 7.4 Fault history

<u>P07.27</u>–<u>P07.32</u> record the six latest fault types; <u>P07.33</u>–<u>P07.40</u>, <u>P07.41</u>–<u>P07.48</u>, and <u>P07.49</u>–<u>P07.56</u> record the running data of the VFD when the latest three faults occurred.

### 7.5 VFD faults and solutions

When a fault occurred, handle the fault as follows.

- 1. When a VFD fault occurred, confirm whether keypad display is improper? If yes, contact INVT;
- If keypad works properly, check the function codes in P07 group to confirm the corresponding fault record parameters, and determine the real state when current fault occurred through parameters;
- Check the table below to see whether corresponding exception states exist based on the corresponding corrective measures;
- 4. Rule out the faults or ask for help from professionals;
- 5. After confirming faults are removed, reset the fault and start running.

### 7.5.1 Details of faults and solutions

**Note:** The numbers enclosed in square brackets such as [1], [2] and [3] in the **Fault type** column in the following table indicate the VFD fault type codes read through communication.

Fault code	Fault type	Possible cause	Corrective measures
OUt1	[1] Inverter unit	Acceleration is too fast;	Increase acceleration time;
OULI	phase-U protection	IGBT module is damaged;	Replace the power unit;

Fault code	Fault type	Possible cause	Corrective measures
OUt2	[2] Inverter unit	Misacts caused by	Check drive wires;
0012	phase-V protection	interference; drive wires are	Check whether there is strong
OUt3	[3] Inverter unit	poorly connected;	interference surrounds the
0013	phase-W protection	Shorted to ground.	peripheral equipment
OV1	[7] Over-voltage	Deceleration time is too	Check input power;
OVI	during acceleration	short;	Check whether load
0)/0	[8] Over-voltage	Exception occurred to input	deceleration time is too short;
OV2	during deceleration	voltage;	or the motor starts during
	[O] Over veltere	Large energy feedback;	rotating;
0)/0	[9] Over-voltage	Lack of braking units;	Install dynamic braking units;
OV3	during constant	Dynamic braking is not	Check the setup of related
	speed running	enabled	function codes
OC1	[4] Over-current		Increase acceleration
001	during acceleration		/deceleration time;
000	[5] Over-current	Acceleration is too fast;	Check input power;
OC2	during deceleration	Grid voltage is too low;	Select the VFD with larger
		VFD power is too small;	power;
		Load transient or exception	Check if the load is short
		occurred;	circuited (to-ground short
		To-ground short circuit or	circuit or line-to-line short
	[6] Over-current	output phase loss occur;	circuit) or the rotation is not
OC3	during constant	Strong external interference	smooth;
	speed running	sources;	Check the output wiring;
		Overcurrent stall protection	Check if there is strong
		is not enabled	interference;
			Check the setup of related
			function codes.
	[40] Due	Grid voltage is too low;	Check grid input power;
UV	[10] Bus	Overvoltage stall protection	Check the setup of related
	undervoltage fault	is not enabled	function codes
		Grid voltage is too low;	Charle and waltama
		Rated motor current is set	Check grid voltage;
OL1	[11] Motor overload	improperly;	Reset rated motor current;
		Motor stall or load jumps	Check the load and adjust
		violently	torque boost
		Acceleration is too fast;	Increase acceleration time;
OL2	[12] VFD overload	The motor in rotating is	Avoid restart after stop;
		restarted;	Check grid voltage;

Fault code	Fault type	Possible cause	Corrective measures
		Grid voltage is too low; Load is too large; Power is too small;	Select the VFD with larger power; Select proper motor
SPI	[13] Phase loss on input side	Phase loss or violent fluctuation occurred to R, S and T input	Check the input power; Check installation wiring
SPO	[14] Phase loss on output side	Phase loss occurred to U, V, W output (or the three phases of motor is asymmetrical)	Check the output wiring; Check the motor and cable
OH1	[15] Overheat of rectifier module	Air duct is blocked or fan is damaged;	Ventilate the air duct or replace the fan;
OH2	[16] Overheat of inverter module	Ambient temperature is too high; Long-time overload running	Lower the ambient temperature
EF	[17] External fault	SI external fault input terminal acts	Check external device input
CE	[18] Modbus/Modbus TCP communication fault	Baud rate is set improperly; Communication line fault; Communication address error; Communication suffers from strong interference	Set proper baud rate; Check the wiring of communication interfaces; Set proper communication address; Replace or change the wiring to enhance anti-interference capacity
ltE	[19] Current detection fault	Poor contact of the connector of control board; Hall component is damaged; Exception occurred to amplification circuit	Check the connector and re-plug; Replace the hall component; Replace the main control board
tE	[20] Motor autotuning fault	Motor capacity does not match with the VFD capacity, this fault may occur easily if the difference between them is exceeds five power classes; Motor parameter is set	Change the VFD model, or adopt V/F mode for control; Set proper motor type and nameplate parameters; Empty the motor load and carry out autotuning again; Check motor wiring and

Fault code	Fault type	Possible cause	Corrective measures
		improperly;	parameter setup;
		The parameters gained	Check whether upper limit
		from autotuning deviate	frequency is larger than 2/3 of
		sharply from the standard	the rated frequency
		parameters;	
		Autotuning timeout	
		R/W error occurred to the	Press STOP/RST to reset;
EEP	[21] EEPROM fault	control parameters;	Replace the main control
		EEPROM is damaged	board
	[22] DID foodbook	PID feedback offline;	Check PID feedback signal
PIDE	[22] PID feedback	PID feedback source	wires;
	offline fault	disappears;	Check PID feedback source
		Braking circuit fault or	Check the braking unit,
LOF	[23] Braking unit	braking tube is damaged;	replace with new braking
bCE	fault	The resistance of external	tubes;
		braking resistor is too small	Increase braking resistance
	IO 41 Demonstrate time a la	The actual running time of	A ale hada faran dha accanillan
END	[24] Running time is	the VFD is larger than the	Ask help from the supplier,
	up	set running time	adjust the set running time
	[05] 5]	The VFD releases overload	Ohl- th - l d d d d
OL3	[25] Electronic overload fault	pre-alarm based on the set	Check the load and overload
	ovenoad fault	value	pre-alarm threshold
		The keypad wire is poorly	
		contacted or disconnected;	Check the keypad wires to
		The keypad wire is too long	confirm whether fault exists;
PCE	[26] Keypad	and suffers strong	Check the surroundings to
FGE	communication fault	interference;	rule out interference source;
		Circuit fault occurred to the	Replace the hardware and
		keypad or communication	ask for maintenance service
		part of the main board	
		The keypad wire is poorly	
		contacted or disconnected;	Check the surroundings to
		The keypad wire is too long	rule out interference source;
UPE	[27] Parameter	and suffers strong	Replace the hardware and
UPE	upload error	interference;	ask for maintenance service;
		Circuit fault occurred to the	Replace the hardware and
		keypad or communication	ask for maintenance service
		part of the main board	

Fault code	Fault type	Possible cause	Corrective measures
DNE	[28] Parameter download error	The keypad wire is poorly contacted or disconnected; The keypad wire is too long and suffers strong interference; Data storage error occurred to the keypad	Check the surroundings to rule out interference source; Replace the hardware and ask for maintenance service; Re-backup keypad data
ETH1	[32] To-ground short circuit fault 1	VFD output is short connected to the ground; Current detection circuit is faulty; Actual motor power setup deviates sharply from the VFD power	Check whether motor wiring is proper; Replace the hall component; Replace the main control board; Reset the motor parameters properly
ETH2	[33] To-ground short circuit fault 1	VFD output is short connected to ground; Current detection circuit is faulty; Actual motor power setup deviates sharply from the VFD power	Check whether motor wiring is proper; Replace the hall component; Replace the main control board; Reset the motor parameters properly
dEu	[34] Speed deviation fault	Load is too heavy, or stall occurred	Check the load to ensure it is proper, increase the detection time; Check whether control parameters are set properly
STo	[35] Maladjustment fault	Control parameters of synchronous motor is set improperly; The parameter gained from autotuning is inaccurate; The VFD is not connected to motor	Check the load to ensure it is proper, Check whether load is proper; Check whether control parameters are set correctly; Increase maladjustment detection time
LL	[36] Electronic underload fault	The VFD performs underload pre-alarm based on the set value	Check the load and overload pre-alarm threshold
ENC1o	[37] Encoder offline fault	Encoder line sequence is wrong, or signal wires are	Check the encoder wiring

Fault code	Fault type	Possible cause	Corrective measures
		poorly connected	
ENC1d	[38] Encoder reversal fault	The encoder speed signal is contrary to the motor running direction	Reset encoder direction
ENC1Z	[39] Encoder Z pulse offline fault	Z signal wires are disconnected	Check the wiring of Z signal
ОТ	[59] Motor over-temperature fault	Motor over-temperature input terminal is valid; Exception occurred to t temperature detection Exception occurred to resistor; Long-time overload running or exception occurred	Check the wiring of motor over-temperature input terminal (terminal function 57); Check whether temperature sensor is proper; Check the motor and perform maintenance on the motor
STO	[40] Safe torque off	Safe torque off function is enabled by external forces	/
STL1	[41] Exception occurred to safe circuit of channel H1	The wiring of STO is improper; Fault occurred to external switch of STO; Hardware fault occurred to safety circuit of channel H1	Check whether terminal wiring of STO is proper and firm enough; Check whether external switch of STO can work properly and restart it; Replace the control board
STL2	[42] Exception occurred to channel H2 safe circuit	The wiring of STO is improper; Fault occurred to external switch of STO; Hardware fault occurred to safety circuit of channel H2	Check whether terminal wiring of STO is proper and firm enough; Check whether external switch of STO can work properly and restart it; Replace the control board
STL3	[43] Exception occurred to channel H1 and channel H2	Hardware fault occurred to STO circuit	Replace the control board
CrCE	[44] Safety code FLASH CRC check fault	Control board is faulty	Replace the control board
E-Err	[55] Repetitive expansion card type	The two inserted expansion cards are of the same type	You should not insert two cards with the same type;

Fault code	Fault type	Possible cause	Corrective measures
			check the type of expansion
			card, and remove one card
			after power down
ENCUV	[56] Encoder UVW	No electric level variation	Check the wiring of UVW;
LIVOOV	loss fault	occurred to UVW signal	Encoder is damaged
			Confirm whether the
			expansion card inserted can
			be supported;
	[60] Failed to	There is data transmission	Stabilize the expansion card
	identify the	in interfaces of card slot 1,	interfaces after power down,
F1-Er	expansion card in	however, it cannot read the	and confirm whether fault still
	card slot 1	card type	occurs at next power-on;
	cara sict 1	ourd type	Check whether the insertion
			port is damaged, if yes,
			replace the insertion port after
			power down
			Confirm whether the
	[61] Failed to identify the expansion card in card slot 2		expansion card inserted can
			be supported;
		There is data transmission	Stabilize the expansion card
		in interfaces of card slot 2,	interfaces after power down,
F2-Er		however, it cannot read the	and confirm whether fault still
		card type	occurs at next power-on;
			Check whether the insertion
			port is damaged, if yes,
			replace the insertion port after
			power down
			Confirm whether the
			expansion card inserted can
			be supported;
	[62] Failed to	There is data transmission	Stabilize the expansion card
	identify the	in interfaces of card slot 3,	interfaces after power down,
F3-Er	expansion card in	however, it cannot read the	and confirm whether fault still
	card slot 3	card type	occurs at next power-on;
	2	2 AL-	Check whether the insertion
			port is damaged, if yes,
			replace the insertion port after
			power down

Fault code	Fault type	Possible cause	Corrective measures
C1-Er	[63] Communication timeout occurred to the expansion card in card slot 1	There is no data transmission in interfaces of card slot 1	Confirm whether the expansion card inserted can be supported; Stabilize the expansion card interfaces after power down, and confirm whether fault still occurs at next power-on; Check whether the insertion port is damaged, if yes, replace the insertion port after power down
C2-Er	[64] Communication timeout occurred to the expansion card in card slot 2	There is no data transmission in interfaces of card slot 2	Confirm whether the expansion card inserted can be supported; Stabilize the expansion card interfaces after power down, and confirm whether fault still occurs at next power-on; Check whether the insertion port is damaged, if yes, replace the insertion port after power down
C3-Er	[65] Communication timeout occurred to the expansion card in card slot 3	There is no data transmission in interfaces of card slot 3	Confirm whether the expansion card inserted can be supported; Stabilize the expansion card interfaces after power down, and confirm whether fault still occurs at next power-on; Check whether the insertion port is damaged, if yes, replace the insertion port after power down
E-DP	[29] PROFIBUS card communication timeout fault	There is no data transmission between the communication card and the host controller (or PLC).	Check whether the communication card wiring is loose or dropped.
E-NET	[30] Ethernet card	There is no data	Check whether the

Fault code	Fault type	Possible cause	Corrective measures
	communication timeout fault	transmission between the communication card and the host controller.	communication card wiring is loose or dropped.
E-CAN	[31] CANopen card communication timeout fault	There is no data transmission between the communication card and the host controller (or PLC)	Check whether the communication card wiring is loose or dropped.
E-PN	[57] PROFINET card communication timeout fault	There is no data transmission between the communication card and the host controller (or PLC)	Check whether the communication card wiring is loose or dropped.
E-CAT	[66] EtherCAT card communication timeout fault	There is no data transmission between the communication card and the host controller (or PLC)	Check whether the communication card wiring is loose or dropped
E-BAC	[67] BACNet card communication timeout fault	There is no data transmission between the communication card and the host controller (or PLC).	Check whether the communication card wiring is loose or dropped
E-DEV	[68] DeviceNet card communication timeout fault	There is no data transmission between the communication card and the host controller (or PLC).	Check whether the communication card wiring is loose or dropped
SECAN	[58] CAN master/slave communication card communication timeout fault	There is no data transmission between the CAN master and slave communication cards	Check whether the communication card wiring is loose or dropped
S-Err	[69] CAN slave fault in master/slave synchronization	Fault occurred to one of the CAN slave VFDs	Detect the CAN slave VFD and analyze the corresponding fault cause of the VFD
P-E1-P-E10	[45]–[54] Programmable card customized faults 1–10	User program logic error in the programmable card. A fault occurred on the customized position.	Check the user program logic. Perform troubleshooting based on actual customized faults.
OtE1	[70] EC PT100 detected OH	The PT100 temperature sensor is inaccurate or not	Calibrate the sensor through parameter settings.


Fault code	Fault type	Possible cause	Corrective measures
		calibrated. Device or ambient temperature is too high.	Lower the device or ambient temperature.
OtE2	[71] EC PT1000 detected OH	The PT1000 temperature sensor is inaccurate or not calibrated.  Device or ambient temperature is too high.	Calibrate the sensor through parameter settings. Lower the device or ambient temperature.
E-EIP	[72] EtherNet IP communication timeout	There is no data transmission between the communication card and the host controller (or PLC).	Check whether the communication card wiring is loose or dropped.
E-PAO	[73] No upgrade bootloader	The upgrade bootloader is missing.	Contact us.
E-Al1	[74] AI1 disconnection	Input voltage of Al1 is too low; Al1 wiring is disconnected.	Connect a 5V or 10mA power source to check whether the input is normal; Check the wiring or replace the cables.
E-AI2	[75] AI2 disconnection	Input voltage of Al2 is too low; Al2 wiring is disconnected.	Connect a 5V or 10mA power source to check whether the input is normal; Check the wiring or replace the cables.
E-Al3	[76] AI3 disconnection	Input voltage of Al3 is too low; Al4 wiring is disconnected.	Connect a 5V or 10mA power source to check whether the input is normal; Check the wiring or replace the cables.

## 7.5.2 Other states


Displayed code	State type	Possible cause	Solution
PoFF	System power failure	The system is powered off or the bus voltage is too low.	Check the grid conditions.

# 7.6 Analysis on common faults


### 7.6.1 Motor fails to work




### 7.6.2 Motor vibrates




### 7.6.3 Overvoltage




### 7.6.4 Undervoltage




## 7.6.5 Unusual heating of motor




## 7.6.6 VFD overheating



## 7.6.7 Motor stalls during ACC



#### 7.6.8 Overcurrent



### 7.7 Countermeasures on common interference

### 7.7.1 Interference on meter switches and sensors

### Interference phenomenon

Pressure, temperature, displacement, and other signals of a sensor are collected and displayed by a human-machine interaction device. The values are incorrectly displayed as follows after the VFD is

#### started:

- 1. The upper or lower limit is wrongly displayed, for example, 999 or -999.
- 2. The display of values jumps (usually occurring on pressure transmitters).
- The display of values is stable, but there is a large deviation, for example, the temperature is dozens of degrees higher than the common temperature (usually occurring on thermocouples).
- 4. A signal collected by a sensor is not displayed but functions as a drive system running feedback signal. For example, the VFD is expected to decelerate when the upper pressure limit of the compressor is reached, but in actual running, it starts to decelerate before the upper pressure limit is reached.
- After the VFD is started, the display of all kinds of meters (such as frequency meter and current meter) that are connected to the analog output (AO) terminal of the VFD is severely affected, displaying the values incorrectly.
- Proximity switches are used. After the VFD is started, the indicator of a proximity switch flickers, and the output level flips.

#### Solution

- Check and ensure that the feedback cable of the sensor is 20 cm or farther away from the motor cable.
- 2. Check and ensure that the ground wire of the motor is connected to the PE terminal of the VFD (if the ground wire of the motor has been connected to the ground block, you need to use a multimeter to measure and ensure that the resistance between the ground block and PE terminal is lower than 1.5  $\Omega$ ).
- 3. Try to add a safety capacitor of 0.1  $\mu F$  to the signal end of the feedback signal terminal of the sensor.
- 4. Try to add a safety capacitor of  $0.1 \mu F$  to the power end of the sensor meter (pay attention to the voltage of the power supply and the voltage endurance of the capacitor).
- For interference on meters connected to the AO terminal of a VFD, if AO uses current signals of 0 to 20 mA, add a capacitor of 0.47 μF between the AO and GND terminals; and if AO uses voltage signals of 0 to 10 V, add a capacitor of 0.1 μF between the AO and GND terminals.

#### Note:

- When a decoupling capacitor is required, add it to the terminal of the device connected to the sensor. For example, if a thermocouple is to transmit signals of 0 to 20 mA to a temperature meter, the capacitor needs to be added on the terminal of the temperature meter; if an electronic ruler is to transmit signals of 0 to 30 V to a PLC signal terminal, the capacitor needs to be added on the terminal of the PLC.
- If a large number of meters or sensors are disturbed. It is recommended that you configure an

external C2 filter on the input power end of the VFD. For models of filters, see the filter model selection section D.7.2 Filter model selection.

## 7.7.2 Interference on RS485 communication

#### Interference phenomenon

The interference described in this section on 485 communication mainly includes communication delay, synchronization failure, occasional power-off, or complete power-off that occurs after the VFD is started.

If the communication cannot be implemented properly, regardless of whether the VFD is running, the exception is not necessarily caused by interference. You can find out the causes as follows:

- 1. Check whether the 485 communication bus is disconnected or in poor contact.
- 2. Check whether the two ends of line A or B are connected reversely.
- Check whether the communication protocol (such as the baud rate, data bits, and check bit) of the VFD is consistent with that of the upper computer.

If you are sure that communication exceptions are caused by interference, you can resolve the problem through the following measures:

- 1. Simple inspection.
- 2. Arrange the communication cables and motor cables in different cable trays.
- In multi-VFD application scenarios, adopt the chrysanthemum connection mode to connect the communication cables between VFDs, which can improve the anti-interference capability.
- In multi-VFD application scenarios, check and ensure that the driving capacity of the master is sufficient.
- 5. In the connection of multiple VFDs, you need to configure one 120  $\Omega$  terminal resistor on each end.

### Solution

- 1. Check and ensure that the ground wire of the motor is connected to the PE terminal of the VFD (if the ground wire of the motor has been connected to the ground block, you need to use a multimeter to measure and ensure that the resistance between the ground block and PE terminal is lower than 1.5  $\Omega$ ).
- Do not connect the VFD and motor to the same ground terminal as the upper computer. It is recommended that you connect the VFD and motor to the power ground, and connect the upper computer separately to a ground stud.
- 3. Try to short the signal reference ground terminal (GND) of the VFD with that of the upper computer controller to ensure that ground potential of the communication chip on the control board of the VFD is consistent with that of the communication chip of the upper computer.
- 4. Try to short GND of the VFD to its ground terminal (PE).

5. Try to add a safety capacitor of 0.1 μF on the power terminal of the upper computer (PLC, HMI, and touch screen). During this process, pay attention to the voltage of the power supply and the voltage endurance capability of the capacitor. Alternatively, you can use a magnet ring (Fe-based nanocrystalline magnet rings are recommended). Put the power L/N line or +/- line of the upper computer through the magnet ring in the same direction and wind 8 coils around the magnet ring.

### 7.7.3 Stop failure and indicator shimmering due to motor cable coupling

#### Interference phenomenon

### 1. Stop failure

In a VFD system where an S terminal is used to control the start and stop, the motor cable and control cable are arranged in the same cable tray. After the system is started properly, the S terminal cannot be used to stop the VFD.

### 2. Indicator shimmering

After a VFD is started, the relay indicator, power distribution box indicator, PLC indicator, and indication buzzer shimmers, blinks, or emits unusual sounds unexpectedly.

#### Solution

- Check and ensure that the exception signal cable is arranged 20 cm or farther away from the motor cable.
- 2. Add a safety capacitor of 0.1 µF between the digital input terminal (S) and the COM terminal.
- 3. Connect the digital input terminal (S) that controls the start and stop to other idle digital input terminals in parallel. For example, if S1 is used to control the start and stop and S4 is idle, you can try to connect S1 to S4 in parallel.

**Note:** If the controller (such as PLC) in the system controls more than 5 VFDs at the same time through digital input terminals (S), this scheme is not applicable.

## 7.7.4 Leakage current and interference on RCD

The VFD outputs high-frequency PWM voltage to drive motors. In this process, the distributed capacitance between the internal IGBT of the VFD and the heat sink and that between the stator and rotor of a motor may inevitably cause the VFD to generate high-frequency leakage current to the ground. A residual current operated protective device (RCD) is used to detect the power-frequency leakage current when a grounding fault occurs on a circuit. The application of the VFD may cause misoperation of a RCD.

- 1. Rules for selecting RCDs
- (1) VFD systems are special. In these systems, it is required that the rated residual current of common RCDs at all levels is larger than 200 mA, and the VFDs are grounded reliably.
- (2) For RCDs, the time limit of an action needs to be longer than that of a next action, and the time

difference between two actions need to be longer than 20 ms. For example, 1s, 0.5s, and 0.2s.

(3) For circuits in VFD systems, electromagnetic RCDs are recommended. Electromagnetic RCDs have strong anti-interference capability, and thus can prevent the impact of high-frequency leakage current.

Electronic RCD	Electromagnetic RCD
	Requiring highly sensitive, accurate, and
	stable zero-phase sequence current
Low cost, high sensitivity, small in volume,	transformer, using permalloy
susceptible to voltage fluctuation of the grid	high-permeability materials, complex process,
and ambient temperature, weak	high cost, not susceptible to voltage
anti-interference capability	fluctuation of the power supply and ambient
	temperature, strong anti- interference
	capability

- 2. Solution to RCD misoperation (handling the VFD)
- 1. Try to remove the jumper cap at "EMC/J10" on the middle casing of the VFD.
- 2. Try to reduce the carrier frequency to 1.5 kHz (P00.14=1.5).
- 3. Try to modify the modulation mode to "3PH modulation and 2PH modulation" (P08.40=0).
- 3. Solution to RCD misoperation (handling the system power distribution)
- (1) Check and ensure that the power cable is not soaking in water.
- (2) Check and ensure that the cables are not damaged or spliced.
- (3) Check and ensure that no secondary grounding is performed on the neutral wire.
- (4) Check and ensure that the main power cable terminal is in good contact with the air switch or contactor (all screws are tightened).
- (5) Check 1PH powered devices, and ensure that no earth lines are used as neutral wires by these devices.

Do not use shielded cables as VFD power cables and motor cables.

#### 7.7.5 Live device chassis

After the VFD is started, there is sensible voltage on the chassis, and you may feel an electric shock when touching the chassis. The chassis, however, is not live (or the voltage is far lower than the human safety voltage) when the VFD is powered on but not running.

## Solution

 If there is power distribution grounding or ground stud on the site, ground the cabinet chassis of the drive system through the power ground or stud.

If there is no grounding on the site, you need to connect the motor chassis to the ground terminal PE of the VFD, and ensure that the jumper at "EMC/J10" on the middle casing of the VFD is shorted.

## 8 Maintenance

## 8.1 What this chapter contains

This chapter describes how to carry out preventive maintenance on the VFD.

# 8.2 Periodical inspection

Only little maintenance is required when the VFD is installed in an environment that meets the requirements. The following table describes the routine maintenance periods recommended by INVT.

	Subject	Item	Method	Criterion
		Check the temperature, and		
		humidity, and whether there is	•	The requirements
		vibration, dust, gas, oil spray,	and use instruments	stated in this
		and water droplets in the	for measurement.	manual are met.
Ambie	nt environment	environment.		
		Check whether there are		There are no tools
		foreign matters, such as tools,	Visual inspection	or dangerous
		or dangerous substances	viodai iriopeotion	substances placed
		placed nearby.		nearby.
		Check the voltage of the main	Use multimeters or	The requirements
	Voltage	circuit and control circuit.	other instruments for	stated in this
		circuit and control circuit.	measurement.	manual are met.
		Check the display of	Visual inspection	The characters are
		information.	visual inspection	displayed properly.
	Keypad	Check whether characters are		The requirements
		not completely displayed.	Visual inspection	stated in this
		not completely displayed.		manual are met.
		Check whether the bolts	Screw them up.	No exception
		loose or come off.	ociew them up.	occurs.
		Check whether the machine		
		is deformed, cracked, or		No exception
		damaged, or their color	Visual inspection	occurs.
		changes due to overheating		occurs.
Main	Common	and aging.		
circuit	Common			No exception
				occurs.
		Check whether there are		Note:
		stains and dust attached.	Visual inspection	Discoloration of
		Stanis and dust attached.		copper bars does
				not mean that they
				cannot work

Subject	Item	Method	Criterion
			properly.
Conductor and	Check whether the conductors are deformed or their color change due to overheat.	Visual inspection	No exception occurs.
wire	Check whether the wire sheaths are cracked or their color changes.	Visual inspection	No exception occurs.
Terminal block	Check whether there is damage.	Visual inspection	No exception occurs.
	Check whether there is electrolyte leakage, discoloration, cracks, and chassis expansion.	Visual inspection	No exception occurs.
Filter capacitor	Check whether the safety valves are released.	Determine the service life based on the maintenance information, or measure them through electrostatic capacity.	No exception occurs.
	Check whether the electrostatic capacity is measured as required.	Use instruments to measure the capacity.	Electrostatic capacity ≥ initial value × 0.85
	Check whether there is displacement caused due to overheat.	Olfactory and visual inspection	No exception occurs.
Resistor	Check whether the resistors are disconnected.	Visual inspection, or remove one end of the connection cable and use a multimeter for measurement.	Resistance range: ±10% (of the standard resistance)
Transformer and reactor	Check whether there is unusual vibration sounds or smells.	Auditory, olfactory, and visual inspection	No exception occurs.
Electromagnetic contactor and	Check whether there are vibration sounds in the	Auditory inspection	No exception occurs.

	Subject	Item	Method	Criterion
	relay	workshop.		
		Check whether the contacts are in good contact.	Visual inspection	No exception occurs.
		Check whether the screws and connectors loose.	Screw them up.	No exception occurs.
Control circuit		Check whether there is unusual smell or discoloration.	Olfactory and visual inspection	No exception occurs.
	Control PCB, connector	Check whether there are cracks, damage, deformation, or rust.	Visual inspection	No exception occurs.
		Check whether there is electrolyte leakage or deformation.	Visual inspection, and determine the service life based on the maintenance information.	No exception occurs.
		Check whether there are unusual sounds or vibration.	Auditory and visual inspection, and turn the fan blades with your hand.	The rotation is smooth.
	Cooling fan	Check whether the bolts loose.	Screw them up.	No exception occurs.
Cooling system		Check whether there is discoloration caused due to overheat.	Visual inspection, and determine the service life based on the maintenance information.	No exception occurs.
	Ventilation duct	Check whether there are foreign matters blocking or attached to the cooling fan, air inlets, or air outlets.	Visual inspection	No exception occurs.

For more details about maintenance, contact the local INVT office, or visit our website www.invt.com, and choose **Support > Services**.

# 8.3 Cooling fan

The service life of the cooling fan of the VFD is more than 25,000 hours. The actual service life of the cooling fan is related to the use of the VFD and the temperature in the ambient environment.

You can view the running duration of the VFD through P07.14 (Accumulated running time).

The increase of the bearing noise indicates a fan fault. If the VFD is applied in a key position, replace the fan once the fan starts to generate unusual noise. You can purchase spare parts of fans from INVT.

## Cooling fan replacement



- Read the safety precautions carefully and follow the instructions to perform operations. Otherwise, physical injuries or damage to the device may be caused.
- Stop the device, disconnect the AC power supply, and wait for a time no shorter than the waiting time designated on the VFD.
- Open the cable clamp to loosen the fan cable (for 1.5–30kW VFD models, the middle casing needs to be removed).
- 3. Remove the fan cable.
- Remove the fan with a screwdriver.
- 5. Install a new fan in the VFD in the reverse steps. Assemble the VFD. Ensure that the air direction of the fan is consistent with that of the VFD, as shown in the following figure.




Figure 8.1 Fan maintenance for 7R5G/011P and higher models

6. Power on the VFD.

### 8.4 Capacitor

## 8.4.1 Capacitor reforming

If the VFD has been left unused for a long time, you need to follow the instructions to reform the DC bus capacitor before using it. The storage time is calculated from the date the VFD is delivered.

Storage time	Operation instruction
Less than 1 year	No charging operation is required.
1 to 2 years	The VFD needs to be powered on for 1 hour before the first running command.
2 to 3 years	Use a voltage controlled power supply to charge the VFD:  Charge the VFD at 25% of the rated voltage for 30 minutes, and then charge it at 50% of the rated voltage for 30 minutes, at 75% for another 30 minutes, and finally charge it at 100% of the rated voltage for 30 minutes.
More than 3 years	Use a voltage controlled power supply to charge the VFD:  Charge the VFD at 25% of the rated voltage for 2 hours, and then charge it at 50% of the rated voltage for 2 hours, at 75% for another 2 hours, and finally charge it at 100% of the rated voltage for 2 hours.

The method for using a voltage controlled power supply to charge the VFD is described as follows:

The selection of a voltage controlled power supply depends on the power supply of the VFD. For VFDs with an incoming voltage of 1PH/3PH 230 V AC, you can use a 230 V AC/2 A voltage regulator. Both 1PH and 3PH VFDs can be charged with a 1PH voltage controlled power supply (connect L+ to R, and N to S or T). All the DC bus capacitors share one rectifier, and therefore they are all charged.

For VFDs of a high voltage class, ensure that the voltage requirement (for example, 380 V) is met during charging. Capacitor changing requires little current, and therefore you can use a small-capacity power supply (2 A is sufficient).

The method for using a resistor (incandescent lamp) to charge the drive is described as follows:

If you directly connect the drive device to a power supply to charge the DC bus capacitor, it needs to be charged for a minimum of 60 minutes. The charging operation must be performed at a normal indoor temperature without load, and you must connect a resistor in series mode in the 3PH circuit of the power supply.

For a 380 V drive device, use a resistor of 1 k $\Omega$ /100W. If the voltage of the power supply is no higher than 380 V, you can also use an incandescent lamp of 100W. If an incandescent lamp is used, it may go off or the light may become very weak.




Figure 8.2 Charging circuit example of driving devices

### 8.4.2 Electrolytic capacitor replacement



Read the safety precautions carefully and follow the instructions to perform operations. Otherwise, physical injuries or damage to the device may be caused.

The electrolytic capacitor of the VFD must be replaced if it has been used for more than 35,000 hours. For details about the replacement, contact the local INVT office.

## 8.5 Power cable



- Read the safety precautions carefully and follow the instructions to perform operations. Otherwise, physical injuries or device damage may be caused.
- Stop the VFD, disconnect the power supply, and wait for a time no shorter than the waiting time designated on the VFD.
- 2. Check the connection of the power cables. Ensure that they are firmly connected.
- 3. Power on the VFD.

# 9 Communication

# 9.1 What this chapter contains

This chapter describes the communication protocols supported by the VFD.

The VFD provides RS485 communication interfaces and adopts the master/slave communication based on the international standard Modbus communication protocol. You can implement centralized control (setting commands for controlling the VFD, modifying the running frequency and related function parameters, and monitoring the running status and fault information of the VFD) through PC/PLC, upper control computers, or other devices to meet specific application requirements.

# 9.2 Modbus protocol introduction

Modbus is a software protocol, a common language used in electronic controllers. By using this protocol, a controller can communicate with other devices through transmission lines. It is a general industrial standard. With this standard, control devices produced by different manufacturers can be connected to form an industrial network and be monitored in a centralized way.

The Modbus protocol provides two transmission modes, namely American Standard Code for Information Interchange (ASCII) and Remote Terminal Unit (RTU). On one Modbus network, all the devices must be consistent in transmission modes, baud rates, data bits, check bits, stop bits, and other basic parameters.

A Modbus network is a control network with one master and multiple slaves, that is, on one Modbus network, there is only one device serving as the master, and other devices are the slaves. The master can communicate with one slave or all the slaves by sending broadcast messages. For separate access commands, a slave needs to return a response. For broadcast messages, slaves do not need to return responses.

### 9.3 Application

The VFD uses the Modbus RTU mode and communicates through RS485 interfaces.

#### 9.3.1 RS485

RS485 interfaces work in half-duplex mode and send data signals in the differential transmission way, which is also referred to as balanced transmission. An RS485 interface uses a twisted pair, in which one wire is defined as A (+), and the other B (-). Generally, if the positive electrical level between the transmission drives A and B ranges from +2 V to +6 V, the logic is "1"; and if it ranges from -2 V to -6 V, the logic is "0". On the VFD terminal block, the 485+ terminal corresponds to A, and 485- corresponds to B.

The communication baud rate (P14.01) indicates the number of bits sent in a second, and the unit is bit/s (bps). A higher baud rate indicates faster transmission and poorer anti-interference capability. When a twisted pair of 0.56mm (24 AWG) is used, the maximum transmission distance varies according to the baud rate, as described in the following table.

Baud rate (bps)	Max. transmission distance (meter)	Baud rate (bps)	Max. transmission distance (meter)
2400BPS	1800m	9600BPS	800m
4800BPS	1200m	19200BPS	600m

When RS485 interfaces are used for long-distance communication, it is recommended that you use shielded cables, and use the shielding layer as the ground wires.

When there are fewer devices and the transmission distance is short, the whole network works well without terminal load resistors. The performance, however, degrades as the distance increases. Therefore, it is recommended that you use a  $120\Omega$  terminal resistor when the transmission distance is long.

### 9.3.1.1 When one VFD is used

Figure 9.1 is the Modbus wiring diagram for the network with one VFD and PC. Generally, PCs do not provide RS485 interfaces, and therefore you need to convert an RS232 or USB interface of a PC to an RS485 interface through a converter. Then, connect end A of the RS485 interface to the 485+ port on the terminal block of the VFD, and connect end B to the 485- port. It is recommended that you use shielded twisted pairs. When an RS232-RS485 converter is used, the cable used to connect the RS232 interface of the PC and the converter cannot be longer than 15 m. Use a short cable when possible. It is recommended that you insert the converter directly into the PC. Similarly, when a USB-RS485 converter is used, use a short cable when possible.

When the wiring is completed, select the correct port (for example, COM1 to connect to the RS232-RS485 converter) for the upper computer of the PC, and keep the settings of basic parameters such as communication baud rate and data check bit consistent with those of the VFD.




Figure 9.1 RS485 wiring diagram for the network with one VFD

## 9.3.1.2 When multiple VFDs are used

In the network with multiple VFDs, chrysanthemum connection and star connection are commonly used.

According to the requirements of the RS485 industrial bus standards, all the devices need to be connected in chrysanthemum mode with one 120  $\Omega$  terminal resistor on each end, as shown in Figure 9.2. Figure 9.3 is the simplified wiring diagram, and Figure 9.4 is the practical application diagram.




Figure 9.2 Onsite chrysanthemum connection diagram




Figure 9.3 Simplified chrysanthemum connection diagram




Figure 9.4 Practical application diagram of chrysanthemum connection

Figure 9.5 shows the start connection diagram. When this connection mode is adopted, the two devices that are farthest away from each other on the line must be connected with a terminal resistor (in this figure, the two devices are devices 1# and 15#).




Figure 9.5 Star connection

Use shielded cables, if possible, in multi-VFD connection. The baud rates, data bit check settings, and other basic parameters of all the devices on the RS485 line must be set consistently, and addresses cannot be repeated.

#### 9.3.2 RTU

#### 9.3.2.1 RTU communication frame structure

When a controller is set to use the RTU communication mode on a Modbus network, every byte (8 bits) in the message includes 2 hexadecimal characters (each includes 4 bits). Compared with the ASCII mode, the RTU mode can help to send more data at the same baud rate.

### Code system

- · 1 start bit
- 7 or 8 data bits; the minimum valid bit is sent first. Each frame domain of 8 bits includes 2 hexadecimal characters (0-9, A-F).
- 1 odd/even check bit; this bit is not provided if no check is needed.
- 1 stop bit (with check performed), or 2 bits (without check)

#### Error detection domain

· Cyclic redundancy check (CRC)

The following table describes the data format.

11-bit character frame (Bits 1 to 8 are data bits)


Start bit	BIT1	BIT2	ВІТ3	BIT4	BIT5	BIT6	BIT7	BIT8	Check bit	Stop bit	
-----------	------	------	------	------	------	------	------	------	--------------	----------	--

10-bit character frame (Bits 1 to 7 are data bits)

Start bit BIT1 BIT2 BIT3 BIT4 BIT5 BIT6 BIT7	Check bit Stop	bit
--	-------------------	-----

In a character frame, only the data bits carry information. The start bit, check bit, and stop bit are used to facilitate the transmission of the data bits to the destination device. In practical applications, you must set the data bits, parity check bits, and stop bits consistently.

In RTU mode, a new frame always must be preceded by a time gap with a minimum length of 3.5 bytes. On a network where the transmission rate is calculated based on the baud rate, the transmission time of 3.5 bytes can be easily obtained. After the idle time ends, the data domains are sent in the following sequence: slave address, operation command code, data, and CRC check character. Each byte sent in each domain includes hexadecimal characters (0–9, A–F). The network devices always monitor the communication bus. After receiving the first domain (address information), each network device identifies the byte. After the last byte is sent, a similar transmission interval (with a minimum length of 3.5 bytes) is used to indicate that the frame transmission ends. Then, the transmission of a new frame starts.



The information of a frame must be sent in a continuous data flow. If there is an interval greater than the transmission time of 1.5 bytes before the transmission of the entire frame is complete, the receiving device deletes the incomplete information, and mistakes the subsequent byte for the address domain of a new frame. Similarly, if the transmission interval between two frames is shorter than the transmission time of 3.5 bytes, the receiving device mistakes it for the data of the last frame. The CRC check value is incorrect due to the disorder of the frames, and thus a communication fault occurs.

The following table describes the standard structure of an RTU frame.

START (frame header)		T1-T2-T3-T4(transmission time of 3.5 bytes)
ADDR (slav	e address	Communication address: 0–247 (in decimal system) (0 indicates the
domain)		broadcast address)
CMD (function domain)		03H: read slave parameters
		06H: write slave parameters
(Data domain)		
DATA(N-1)		Data of 2*N bytes, main content of the communication as well as the
		core of data exchanging
DATA(0)		
CRC CHK low-order bits		Detection value: CRC (16 bits)
CRC CHK high-order bits		
END (frame tail)		T1-T2-T3-T4 (transmission time of 3.5 bytes)

### 9.3.2.2 RTU communication frame error check modes

During the transmission of data, errors may occur due to various factors. Without check, the data receiving device cannot identify data errors and may make a wrong response. The wrong response may cause severe problems. Therefore, the data must be checked.

The check is implemented as follows: The transmitter calculates the to-be-transmitted data based on a specific algorithm to obtain a result, adds the result to the rear of the message, and transmits them together. After receiving the message, the receiver calculates the data based on the same algorithm to obtain a result, and compares the result with that transmitted by the transmitter. If the results are the same, the message is correct. Otherwise, the message is considered wrong.

The error check of a frame includes two parts, namely, bit check on individual bytes (that is, odd/even check using the check bit in the character frame), and whole data check (CRC check).

### Bit check on individual bytes (odd/even check)

You can select the bit check mode as required, or you can choose not to perform the check, which will affect the check bit setting of each byte.

Definition of even check: Before the data is transmitted, an even check bit is added to indicate whether the number of "1" in the to-be-transmitted data is odd or even. If it is even, the check bit is set to "0"; and if it is odd, the check bit is set to "1".

Definition of odd check: Before the data is transmitted, an odd check bit is added to indicate whether the number of "1" in the to-be-transmitted data is odd or even. If it is odd, the check bit is set to "0"; and if it is even, the check bit is set to "1".

For example, the data bits to be transmitted are "11001110", including five "1". If the even check is applied, the even check bit is set to "1"; and if the odd check is applied, the odd check bit is set to "0". During the transmission of the data, the odd/even check bit is calculated and placed in the check bit of the frame. The receiving device performs the odd/even check after receiving the data. If it finds that the odd/even parity of the data is inconsistent with the preset information, it determines that a communication error occurs.

#### Cyclical Redundancy Check (CRC) method

A frame in the RTU format includes an error detection domain based on the CRC calculation. The CRC domain checks all the content of the frame. The CRC domain consists of two bytes, including 16 binary bits. It is calculated by the transmitter and added to the frame. The receiver calculates the CRC of the received frame, and compares the result with the value in the received CRC domain. If the two CRC values are not equal to each other, errors occur in the transmission.

During CRC, 0xFFFF is stored first, and then a process is invoked to process a minimum of 6 contiguous bytes in the frame based on the content in the current register. CRC is valid only for the 8-bit data in each character. It is invalid for the start, end, and check bits.

During the generation of the CRC values, the "exclusive or" (XOR) operation is performed on the each 8-bit character and the content in the register. The result is placed in the bits from the low-order bit to the high-order bit, and 0 is placed in the high-order bit. Then, the low-order bit is detected. If the low-order bit is 1, the XOR operation is performed on the current value in the register and the preset value. If low-order bit is 0, no operation is performed. This process is repeated 8 times. After the last bit (8th bit) is detected and processed, the XOR operation is performed on the next 8-bit byte and the current content in the register. The final values in the register are the CRC values obtained after operations are performed on all the bytes in the frame.

The calculation adopts the international standard CRC check rule. You can refer to the related standard CRC algorithm to compile the CRC calculation program as required.

The following example is a simple CRC calculation function for your reference (using the C programming language):

```
unsigned int crc_cal_value(unsigned char*data_value,unsigned char
data length)
```

```
int i;
unsigned int crc_value=0xffff;
while(data_length--)
{
    crc_value^=*data_value++;
    for(i=0;i<8;i++)
    {
        if(crc_value&0x0001)
            crc_value=(crc_value>>1)^0xa001;
        else
            crc_value=crc_value>>1;
    }
}
return(crc_value);
}
```

In the ladder logic, CKSM uses the table look-up method to calculate the CRC value according to the content in the frame. The program of this method is simple, and the calculation is fast, but the ROM space occupied is large. Use this program with caution in scenarios where there are space occupation requirements on programs.

#### 9.4 RTU command code and communication data

#### 9.4.1 Command code 03H, reading N words (continuously up to 16 words)

The command code 03H is used by the master to read data from the VFD. The count of data to be read depends on the "data count" in the command. A maximum of 16 pieces of data can be read. The addresses of the read parameters must be contiguous. Each piece of data occupies 2 bytes, that is, one word. The command format is presented using the hexadecimal system (a number followed by "H" indicates a hexadecimal value). One hexadecimal value occupies one byte.

For example, starting from the data address of 0004H, to read two contiguous pieces of data (that is, to read content from the data addresses 0004H and 0005H) of the VFD whose address is 01H, the frame structures are described in the following.

RTU	master	command	(sent	from:	the ma	ster to	the VFD):	
-----	--------	---------	-------	-------	--------	---------	-----------	--

START	T1-T2-T3-T4 (time gap with a min. length of 3.5 bytes)		
ADDR (address)	01H		
CMD (command code)	03H		
Start address high-order bit	00H		
Start address low-order bit	04H		
Data count high-order bit	00H		
Data count low-order bit	02H		

CRC low-order bit	85H
CRC high-order bit	CAH
END	T1-T2-T3-T4 (time gap with a min. length of 3.5 bytes)

"START" and "END" are "T1-T2-T3-T4 (time gap with a min. length of 3.5 bytes)", indicating that a time gap with a minimum length of 3.5 bytes must be kept before RS485 communication is executed. The time gap is used to distinguish one message from another so that the two messages are not regarded as one message.

"ADDR" is "01H", indicating that the command is sent to the VFD whose address is 01H. The ADDR information occupies one byte.

"CMD" is "03H", indicating that the command is used to read data from the VFD. The CMD information occupies one byte.

"Start address" indicates that data reading is started from this address. It occupies two bytes, with the high-order bit on the left and low-order bit on the right.

"Data count" indicates the count of data to be read (unit: word). "Start address" is "0004H" and "Data count" is 0002H, indicating that data is to be read from the data addresses of 0004H and 0005H.

CRC check occupies two bytes, with the low-order bit on the left and high-order bit on the right.

RTU slave response (sent from the VFD to the master):

START	T1-T2-T3-T4 (time gap with a min. length of 3.5 bytes)		
ADDR	01H		
CMD	03H		
High-order bit of data in 0004H	04H		
Low-order bit of data in 0004H	13H		
High-order bit of data in 0005H	88H		
Low-order bit of data in 0005H	00H		
CRC low-order bits	00H		
CRC high-order bits	7EH		
High-order bit of data in 0004H	9DH		
END	T1-T2-T3-T4 (time gap with a min. length of 3.5 bytes)		

The definition of the response information is described as follows:

"ADDR" is "01H", indicating that the message is sent from the VFD whose address is 01H. The ADDR information occupies one byte.

"CMD" is "03H", indicating that the message is a VFD response to the 03H command from the master for reading data. The CMD information occupies one byte.

"Number of bytes" indicates the number of bytes between a byte (not included) and the CRC byte (not

included). The value "04" indicates that there are four bytes of data between "Number of bytes" and "CRC low-order bit", that is, "High-order bit of data in 0004H", "Low-order bit of data in 0004H", "High-order bit of data in 0005H", and "Low-order of data in 0005H".

A piece of data is two bytes, with the high-order bits on the left and low-order bit on the right. From the response, the data in 0004H is 1388H, and that in 0005H is 0000H.

CRC check occupies two bytes, with the low-order bit on the left and high-order bit on the right.

#### 9.4.2 Command word 06H, writing a word

This command is used by the master to write data to the VFD. One command can be used to write only one piece of data. It is used to modify the parameters and running mode of the VFD. For example, to write 5000 (1388H) to 0004H of the VFD whose address is 02H, the frame structures are described in the following.

RTU master command (sent from the master to the VFD):

START	T1-T2-T3-T4 (time gap with a min. length of 3.5 bytes)		
ADDR	02H		
CMD	06H		
High-order bit of data writing address	00H		
Low-order bit of data writing address	04H		
Data content high-order bit	13H		
Data content low-order bit	88H		
CRC low-order bit	C5H		
CRC high-order bit	6EH		
END	T1-T2-T3-T4 (time gap with a min. length of 3.5 bytes)		

RTU slave response (sent from the VFD to the master):

START	T1-T2-T3-T4 (time gap with a min. length of 3.5 bytes)		
ADDR	02H		
CMD	06H		
High-order bit of data writing address	00H		
Low-order bit of data writing address	04H		
Data content high-order bit	13H		
Data content low-order bit	88H		
CRC low-order bit	C5H		
CRC high-order bit	6EH		
END	T1-T2-T3-T4 (time gap with a min. length of 3.5 bytes)		

**Note:** Sections 9.4.1 and 9.4.2 mainly describe the command formats. For the detailed application, see section 9.4.8.

#### 9.4.3 Command code 08H, diagnosis

Sub-function code description:

Sub-function code	Description		
0000	Return data based on query requests		

For example, to query about the circuit detection information about the VFD whose address is 01H, the query and return strings are the same, and the formats are described in the following tables.

#### RTU master command:

START	T1-T2-T3-T4 (time gap with a min. length of 3.5 bytes)		
ADDR	01H		
CMD	08H		
Sub-function code high-order bit	00H		
Sub-function code low-order bit	00H		
Data content high-order bit	12H		
Data content low-order bit	ABH		
CRC CHK low-order bit	ADH		
CRC CHK high-order bit	14H		
END	T1-T2-T3-T4 (time gap with a min. length of 3.5 bytes)		

#### RTU slave response:

START	T1-T2-T3-T4 (time gap with a min. length of 3.5 bytes)		
ADDR	01H		
CMD	08H		
Sub-function code high-order bit	00H		
Sub-function code low-order bit	00H		
Data content high-order bit	12H		
Data content low-order bit	ABH		
CRC CHK low-order bit	ADH		
CRC CHK high-order bit	14H		
END	T1-T2-T3-T4 (time gap with a min. length of 3.5 bytes)		

#### 9.4.4 Command code 10H, continuous writing

The command code 10H is used by the master to write data to the VFD. The quantity of data to be

written is determined by "Data count", and a maximum of 16 pieces of data can be written.

For example, to write 5000 (1388H) and 50 (0032H) respectively to 0004H and 0005H of the VFD whose slave address is 02H, the frame structures are described in the following.

RTU master command (sent from the master to the VFD):

START	T1-T2-T3-T4 (time gap with a min. length of 3.5 bytes)		
ADDR	02H		
CMD	10H		
High-order bit of data writing address	00H		
Low-order bit of data writing address	04H		
Data count high-order bit	00H		
Data count low-order bit	02H		
Number of bytes	04H		
Content high-order bit of 0004H	13H		
Content low-order bit of 0004H	88H		
Content high-order bit of 0005H	00H		
Content low-order bit of 0005H	32H		
CRC low-order bit	C5H		
CRC high-order bit	6EH		
END	T1-T2-T3-T4 (time gap with a min. length of 3.5 bytes)		

RTU slave response (sent from the VFD to the master)

	·		
START	T1-T2-T3-T4 (time gap with a min. length of 3.5 bytes)		
ADDR	02H		
CMD	10H		
High-order bit of data writing address	00H		
Low-order bit of data writing address	04H		
Data count high-order bit	00H		
Data count low-order bit	02H		
CRC low-order bit	C5H		
CRC high-order bit	6EH		
END	T1-T2-T3-T4 (time gap with a min. length of 3.5 bytes)		

#### 9.4.5 Data address definition

This section describes the address definition of communication data. The addresses are used for controlling the running, obtaining the status information, and setting function parameters of the VFD.

#### 9.4.5.1 Function code address format rules

The address of a function code consists of two bytes, with the high-order bit on the left and low-order bit on the right. The high-order bit ranges from 00 to ffH, and the low-order bit also ranges from 00 to ffH. The high-order bit is the hexadecimal form of the group number before the dot mark, and low-order bit is that of the number behind the dot mark. Take P05.06 as an example: The group number is 05, that is, the high-order bit of the parameter address is the hexadecimal form of 05; and the number behind the dot mark is 06, that is, the low-order bit is the hexadecimal form of 06. Therefore, the function code address is 0506H in the hexadecimal form. For example, the parameter address of P10.01 is 0A01H.

Function code	Name	Description	Setting range	Default	Modify
<u>P10.00</u>	Simple PLC mode	Stop after running once     Keep running with the final value after running once     Cyclic running	0–2	0	0
<u>P10.01</u>	Simple PLC memory selection	Without memory after power-off     With memory after power-off	0–1	0	0

#### Note:

- The parameters in the P99 group are set by the manufacturer and cannot be read or modified.
   Some parameters cannot be modified when the VFD is running; some cannot be modified regardless of the VFD status. Pay attention to the setting range, unit, and description of a parameter when modifying it.
- The service life of the Electrically Erasable Programmable Read-Only Memory (EEPROM) may be reduced if it is frequently used for storage. Some function codes do not need to be stored during communication. The application requirements can be met by modifying the value of the on-chip RAM, that is, modifying the MSB of the corresponding function code address from 0 to 1. For example, if <a href="Poul.07">Poul.07</a> is not to be stored in the EEPROM, you need only to modify the value in the RAM, that is, set the address to 8007H. The address can be used only for writing data to the on-chip RAM, and it is invalid when used for reading data.

#### 9.4.5.2 Description of other function addresses

In addition to modifying the parameters of the VFD, the master can also control the VFD, such as starting and stopping it, and monitoring the operation status of the VFD. The following table describes other function parameters.

Function	Address	Data description	R/W
Communication-based	2000H	0001H: Forward running	R/W

Function	Address	Data description	R/W
control command		0002H: Reverse running	
		0003H: Forward jogging	
		0004H: Reverse jogging	
		0005H: Stop	
		0006H: Coast to stop (emergency stop)	
		0007H: Fault reset	
		0008H: Jogging to stop	
	2001H	Communication-based frequency setting (0–Fmax, unit: 0.01 Hz)	DAM
	2002H	PID setting, range (0–1000, 1000 corresponding to 100.0%)	R/W
	2003H	PID feedback, range (0–1000, 1000 corresponding to 100.0%)	R/W
	2004H	Torque setting (-3000 – +3000, 1000 corresponding to 100.0% of the motor rated current)	R/W
	2005H	Setting of the upper limit of the forward running frequency (0–Fmax, unit: 0.01 Hz)	R/W
Communication-based	2006H	Setting of the upper limit of the reverse running frequency (0–Fmax, unit: 0.01 Hz)	R/W
value setting	2007H	Upper limit of the electromotion torque (0–3000, 1000 corresponding to 100.0% of the motor rated current)	R/W
	2008H	Upper limit of the brake torque (0-3000, 1000 corresponding to 100.0% of the motor rated current)	R/W
		Special control command word:	
		Bit0-1: =00: Motor 1 =01: Motor 2	
	2009H	Bit2: =1 Enable speed/torque control switchover	
		=0: Disable speed/torque control switchover	
		Bit3: =1 Clear electricity consumption	

Function	Address	Data description	R/W
		=0: Not clear electricity consumption	
		Bit4: =1 Pre-excitation; =0: Disable pre-excitation	
		Bit5: =1 DC brake =0: Disable DC brake	
		Virtual input terminal command, range:	
	200AH	0x000-0x3FF	R/W
		Corresponding to S8/S7/S6/S5/HDIB/HDIA/S4/ S3/ S2/S1	
		Virtual output terminal command, range:	
	200BH	0x00-0x0F	R/W
		Corresponding to local RO2/RO1/HDO/Y1	
	000011	Voltage setting (used for V/F separation)	DAM
	200CH	(0–1000, 1000 corresponding to 100.0% of the motor rated voltage)	R/W
		AO output setting 1 (-1000—+1000, 1000	
	200DH	corresponding to 100.0%)	R/W
	200EH	AO output setting 2 (-1000-+1000, 1000	R/W
		corresponding to 100.0%)	
	2100H	0001H: Forward running	
		0002H: Reverse running	
VED		0003H: Stopped	
VFD status word 1		0004H: Faulty	R
		0005H: POFF	
		0006H: Pre-excited	
		Bit0: =0: Not ready to run =1: Ready to run	
VFD status word 2		Bi1-2: =00: Motor 1 =01: Motor 2	
		Bit3: =0: Asynchronous motor =1: Synchronous	
		motor	
	2 2101H	Bit4: =0: No overload alarm =1: Overload alarm	R
		Bit5-Bit6: =00: Keypad-based control =01:	
		Terminal-based control	
		=10: Communication-based control	
		Bit7: Reserved	

Function	Address	Data description		R/W
		Bit8: =0: Speed control =1: Torqu Bit9: =0: Non position control =1: Position control	ue control	
		Bit11-Bit10: =0: Vector 0 =1: Ve =2: Closed-loop vector	or	
VFD fault code	2102H	=3: Space voltage ver See the description of fault types.	CIOI	R
VFD identification code	2103H	GD350A0x01A2		R
Running frequency	3000H	0-Fmax (Unit: 0.01Hz)		R
Set frequency	3001H	0-Fmax (Unit: 0.01Hz)		R
Bus voltage	3002H	0.0–2000.0V (Unit: 0.1V)		R
Output voltage	3003H	0–1200V (Unit: 1V)		R
Output current	3004H	0.0–3000.0A (Unit: 0.1A)		R
Rotating speed	3005H	0–65535 (Unit: 1RPM)		R
Output power	3006H	-300.0–300.0% (Unit: 0.1%)		R
Output torque	3007H	-250.0–250.0% (Unit: 0.1%)	Compatible	R
Closed-loop setting	3008H	-100.0–100.0% (Unit: 0.1%)	with CHF100A and CHV100	R
Closed-loop feedback	3009H	-100.0–100.0% (Unit: 0.1%)	communication	R
Input state	300AH	000–3F Corresponding to the local HDIB/ HDIA/S4/S3/S2/S1	addresses	R
Output state	300BH	000–0F Corresponding to the local RO2/RO1/HDO/Y1		R
Analog input 1	300CH	0.00–10.00V (Unit: 0.01V)		R
Analog input 2	300DH	0.00-10.00V (Unit: 0.01V)		R
Analog input 3	300EH	-10.00–10.00V (Unit: 0.01V)		R
Analog input 4	300FH			R

Function	Address	Data description	R/W
Read input of HDIA high-speed pulse	3010H	0.00–50.00kHz (Unit: 0.01Hz)	R
Read input of HDIB high-speed pulse	3011H		R
Read current step of multi-step speed	3012H	0–15	R
External length	3013H	0–65535	R
External count value	3014H	0–65535	R
Torque setting	3015H	-300.0–300.0% (Unit: 0.1%)	R
Identification code	3016H		R
Fault code	5000H		R

The Read/Write (R/W) characteristics indicate whether a function can be read and written. For example, "Communication-based control command" can be written, and therefore the command code 6H is used to control the VFD. The R characteristic indicates that a function can only be read, and W indicates that a function can only be written.

**Note:** Some parameters in the preceding table are valid only after they are enabled. Take the running and stop operations as examples, you need to set "Running command channel" (<u>P00.01</u>) to "Communication", and set "Communication running command channel" (<u>P00.02</u>) to the Modbus communication channel. For another example, when modifying "PID setting", you need to set "PID reference source" (<u>P09.00</u>) to Modbus communication.

The following table describes the encoding rules of device codes (corresponding to the identification code 2103H of the VFD).

Eight high-order bits of code	Meaning	Eight low-order bits of code	Meaning
		0x08	GD35 vector VFD
		0x09	GD35-H1 vector VFD
0.404	GD	0x0a	GD300 vector VFD
0x01	GD	0xa0	GD350 vector VFD
		0xa1	GD350-UL vector VFD
		0xa2	GD350A vector VFD

#### 9.4.6 Fieldbus scale

In practical applications, communication data is represented in the hexadecimal form, but hexadecimal values cannot represent decimals. For example, 50.12 Hz cannot be represented in the hexadecimal form. In such cases, we can multiply 50.12 by 100 to obtain an integer 5012, and then 50.12 can be represented as 1394H (5012 in the decimal form) in the hexadecimal form.

In the process of multiplying a non-integer by a multiple to obtain an integer, the multiple is referred to as a fieldbus scale.

The fieldbus scale depends on the number of decimals in the value specified in "Detailed parameter description" or "Default value". If there are n decimals in the value, the fieldbus scale m is the n<sup>th</sup>-power of 10. Take the following table as an example, m is 10.

Function code	Name	Description	Setting range	Default	Modify
<u>P01.20</u>	Wake-up-from-sleep delay	0.0–3600.0s (valid when P01.19 is 2)	0.00–3600.0	0.0s	0
<u>P01.21</u>	Restart after power failure	0: Disable 1: Enable	0–1	0	0

The value specified in "Setting range" or "Default" contains one decimal, so the fieldbus scale is 10. If the value received by the upper computer is 50, the value of "Wake-up-from-sleep delay" of the VFD is 5.0 (5.0=50/10).

To set the "Wake-up-from-sleep delay" to 5.0s through Modbus communication, you need first to multiply 5.0 by 10 according to the scale to obtain an integer 50, that is, 32H in the hexadecimal form, and then transmit the following write command:

<u>01</u>	<u>06</u>	<u>01 14</u>	<u>00 32</u>	<u>49 E7</u>
VFD address	Write	Parameter	Parameter data	CRC

After receiving the command, the VFD converts 50 into 5.0 based on the fieldbus scale, and then sets "Wake-up-from-sleep delay" to 5.0s.

For another example, after the upper computer transmits the "Wake-up-from-sleep delay" parameter read command, the master receives the following response from the VFD:

<u>01</u>	<u>03</u>	<u>02</u>	<u>00 32</u>	<u>39 91</u>
VFD	Read	2-byte	Parameter	CRC
address	command	data	data	

The parameter data is 0032H, that is, 50, so 5.0 is obtained based on the fieldbus scale (50/10=5.0). In this case, the master identifies that the "Wake-up-from-sleep delay" is 5.0s.

#### 9.4.7 Error message response

Operation errors may occur in communication-based control. For example, some parameters can only be read, but a write command is transmitted. In this case, the VFD returns an error message response.

Error message responses are sent from the VFD to the master. The following table describes the codes and definitions of the error message responses.

Code	Name	Description
	Invalid	The command code received by the upper computer is not allowed to be executed. The possible causes are as follows:
01H	command	The function code is applicable only on new devices and is not implemented on this device.  The function code is applicable only on new devices and is not implemented on this device.
		The slave is in the faulty state when processing this request.
02H	Invalid data address	For the VFD, the data address in the request of the upper computer is not allowed. In particular, the combination of the register address and the number of the to-be-transmitted bytes is invalid.
03H	Invalid data value	The received data domain contains a value that is not allowed. The value indicates the error of the remaining structure in the combined request.
	value	<b>Note:</b> It does not mean that the data item submitted for storage in the register includes a value unexpected by the program.
04H	Operation failure	The parameter is set to an invalid value in the write operation. For example, a function input terminal cannot be set repeatedly.
05H	Password error	The password entered in the password verification address is different from that set in <u>P07.00</u> .
06H	Data frame error	The length of the data frame transmitted by the upper computer is incorrect, or in the RTU format, the value of the CRC check bit is inconsistent with the CRC value calculated by the lower computer.
07H	Parameter read-only	The parameter to be modified in the write operation of the upper computer is a read-only parameter.
08H	Parameter cannot be modified in running	The parameter to be modified in the write operation of the upper computer cannot be modified during the running of the VFD.

Code	Name	Description
09H	Password protection	A user password is set, and the upper computer does not provide the password to unlock the system when performing a read or write operation. The error of "system locked" is reported.

When returning a response, the slave device uses a function code domain and fault address to indicate whether it is a normal response (no error) or exception response (some errors occur). In a normal response, the device returns the corresponding function code and data address or sub-function code. In an exception response, the device returns a code that is equal to a normal code, but the first bit is logic 1.

For example, if the master device transmits a request message to a slave device for reading a group of function code address data, the code is generated as follows:

0 0 0 0 0 0 1 1 (03H in the hexadecimal form)

For an exception response, the following code is returned:

1 0 0 0 0 0 1 1 (83H in the hexadecimal form)

In addition to the modification of the code, the slave device returns a byte of exception code that describes the cause of the exception. After receiving the exception response, the typical processing of the master device is to transmit the request message again or modify the command based on the fault information.

For example, to set the "Channel of running commands" (P00.01, the parameter address is 0001H) of the VFD whose address is 01H to 03, the command is as follows:

<u>01</u>	<u>06</u>	<u>00 01</u>	<u>00 03</u>	<u>98 0B</u>
VFD	Write	Parameter	Parameter	CRC
address	command	address	data	

However, the setting range of the "Running command channel" is 0 to 2. The value 3 exceeds the setting range. In this case, the VFD returns an error message response as shown in the following:

<u>86</u>	<u>04</u>	<u>43 A3</u>
		CRC
	Exception	Exception Error code response code

The exception response code 86H (generated based on the highest-order bit "1" of the write command 06H) indicates that it is an exception response to the write command (06H). The error code is 04H. From the preceding table, we can see that it indicates the error "Operation failure", which means "The parameter is set to an invalid value in the write operation".

#### 9.4.8 Read/Write operation example

For details about the formats of the read and write commands, see sections 9.4.1 and 9.4.2.

#### 9.4.8.1 Examples of read command 03H

Example 1: Read status word 1 of the VFD whose address is 01H. According to the table of other function addresses, the parameter address of status word 1 of the VFD is 2100H.

The read command transmitted to the VFD is as follows:

<u>01</u>	<u>03</u>	<u>21 00</u>	<u>00 01</u>	<u>8E 36</u>
VFD address	Read command	Parameter address	Data quantity	CRC

Assume that the following response is returned:

<u>01</u>	<u>03</u>	<u>02</u>	<u>00 03</u>	<u>F8 45</u>
VFD address	Read command	Number of bytes	Data content	CRC

The data content returned by the VFD is 0003H, which indicates that the VFD is in the stopped state.

Example 2: View information about the VFD whose address is 03H, including "Present fault type" (P07.27) to "5th-last fault type" (P07.32) of which the parameter addresses are 071BH to 0720H (contiguous 6 parameter addresses starting from 071BH).

The command transmitted to the VFD is as follows:

<u>03</u>	<u>03</u>	<u>07 1B</u>	<u>00 06</u>	<u>B5 59</u>
VFD address	Read command	Start address	6 parameters in total	CRC

Assume that the following response is returned:

03	03	<u>0C</u> (	<u>00 23</u>	<u>00 23</u>	<u>00 23</u>	<u>00 23</u>	00 23	<u>00 23</u>	<u>5F D2</u>
VFD address	Read		Present fault type	Last fault type	2nd-last fault type	3rd-last fault type	4th-last fault type	5th-last fault type	CRC

According to the returned data, all the fault types are 0023H, that is, 35 in the decimal form, which means the maladjustment fault (STo)

#### 9.4.8.2 Examples of write command 06H

Example 1: Set the VFD whose address is 03H to be forward running. Refer to the table of other function parameters, the address of "Communication-based control command" is 2000H, and 0001H indicates forward running.

Function	Address	Data description	R/W
		0001H: Forward running	
Communication-based		0002H: Reverse running	DAM
control command	2000H	0003H: Forward jogging	R/W
		0004H: Reverse jogging	

Function	Address	Data description	R/W
		0005H: Stop	
		0006H: Coast to stop (emergency stop)	
		0007H: Fault reset	
		0008H: Jogging to stop	

The command transmitted by the master is as follows:

<u>03</u>	<u>06</u>	<u> 20 00</u>	<u>00 01</u>	<u>42 28</u>
VFD address	Write command	Parameter address	Forward running	CRC

If the operation is successful, the following response is returned (same as the command transmitted by the master):

<u>03</u>	<u>06</u>	<u>20 00</u>	<u>00 01</u>	<u>42 28</u>
VFD address	Write command	Parameter address	Forward running	CRC

Example 2: Set the "Max. output frequency" of the VFD whose address is 03H to 100 Hz.

Function code	Name	Description	Setting range	Default	Modify
P00.03	Max. output frequency	P00.04–600.00H (400.00Hz)	100.00-600.00	50.00Hz	0

According to the number of decimals, the fieldbus scale of the "Max. output frequency" (<u>P00.03</u>) is 100. Multiply 100 Hz by 100. The value 10000 is obtained, and it is 2710H in the hexadecimal form.

The command transmitted by the master is as follows:

<u>03</u>	<u>06</u>	<u>00 03</u>	<u>27 10</u>	<u>62 14</u>
VFD address	Write command	Parameter address	Parameter data	CRC

If the operation is successful, the following response is returned (same as the command transmitted by the master):

<u>03</u>	<u>06</u>	<u>00 03</u>	<u>27 10</u>	<u>62 14</u>
VFD address	Write command	Parameter address	Parameter data	CRC

**Note:** In the preceding command description, spaces are added to a command just for explanatory purposes. In practical applications, no space is required in the commands.

#### 9.4.8.3 Examples of continuously write command 10H

Example 1: Set the VFD whose address is 01H to be forward running at the frequency of 10 Hz. Refer to the table of other function parameters, the address of "Communication-based control command" is 2000H, 0001H indicates forward running, and the address of "Communication-based value setting" is 2001H, as shown in the following figure. 10 Hz is 03E8H in the hexadecimal form.

Function	Address	Data description	R/W	
		0001H: Forward running		
		0002H: Reverse running		
		0003H: Forward jogging		
Communication-based	000011	0004H: Reverse jogging	DAM	
control command	2000H	0005H: Stop	R/W	
		0006H: Coast to stop (emergency stop)		
		0007H: Fault reset		
		0008H: Jogging to stop		
20041		Communication-based frequency setting		
Communication-based value setting	2001H	(0-Fmax, unit: 0.01 Hz)	R/W	
	2002H	PID setting, range (0-1000, 1000	Ft/VV	
	2002H	corresponding to 100.0%)		

In the actual operation, set P00.01 to 2 and P00.06 to 8.

The command transmitted by the master is as follows:

<u>01</u>	<u>10</u>	<u>20 00</u>	<u>00 02</u>	<u>04</u>	<u>00 01</u>	<u>03 E8</u>	<u>3B 10</u>
VFD address	Continuous write command	Parameter address	Parameter quantity	Number of bytes	Froward running	10 Hz	CRC

If the operation is successful, the following response is returned:

<u>01</u>	<u>10</u>	<u> 20 00</u>	<u>00 02</u>	<u>4A 08</u>
VFD address	Continuous write	Parameter address	Parameter quantity	CRC
	command			

Example 2: Set "ACC time" of the VFD whose address is 01H to 10s, and "DEC time" to 20s.

P00.11	ACC time 1		Model	0
1 00.11	Add time 1	O-46	depended	
P00.12	DEC time 1	Setting range of <u>P00.11</u> and <u>P00.12</u> : 0.0–3600.0s	Model	
<u>P00.12</u>	DEC time i		depended	0

The address of <u>P00.11</u> is 000B, 10s is 0064H in the hexadecimal form, and 20s is 00C8H in the hexadecimal form.

The command transmitted by the master is as follows:

01 10 00 OB 00 02 04 00 64 00 C8 Number of **VFD** Continuous Parameter Parameter 10s 20s CRC bytes address write address quantity command

If the operation is successful, the following response is returned:

011000 0B00 0230 0AVFD continuous addressParameter addressParameter quantity

**Note:** In the preceding command description, spaces are added to a command just for explanatory purposes. In practical applications, no space is required in the commands.

#### 9.4.8.4 Modbus communication commissioning example

A PC is used as the host, an RS232-RS485 converter is used for signal conversion, and the PC serial port used by the converter is COM1 (an RS232 port). The upper computer commissioning software is the serial port commissioning assistant Commix, which can be downloaded from the Internet. Download a version that can automatically execute the CRC check function. The following figure shows the interface of Commix.



First, set the serial port to **COM1**. Then, set the baud rate consistently with <u>P14.01</u>. The data bits, check bits, and end bits must be set consistently with <u>P14.02</u>. If the RTU mode is selected, you need to select the hexadecimal form **Input HEX**. To set the software to automatically execute the CRC function, you need to select **ModbusRTU**, select **CRC16 (MODBU SRTU)**, and set the start byte to **1**. After the auto CRC check function is enabled, do not enter CRC information in commands. Otherwise, command errors may occur due to repeated CRC check.

The commissioning command to set the VFD whose address is 03H to be forward running is as

follows:

<u>03</u>	<u>06</u>	<u>20 00</u>	<u>00 01</u>	<u>42 28</u>
VFD address	Write command	Parameter address	Forward running	CRC

#### Note:

Set the address (P14.00) of the VFD to 03.

Set "Channel of running commands" (<u>P00.01</u>) to "Communication", and set "Communication channel of running commands" (<u>P00.02</u>) to the Modbus communication channel.

Click **Send**. If the line configuration and settings are correct, a response transmitted by the VFD is received as follows:

<u>03</u>	<u>06</u>	<u>20 00</u>	<u>00 01</u>	<u>42 28</u>
VFD address	Write command	Parameter address	Forward running	CRC

#### 9.5 Common communication faults

Common communication faults include the following:

- No response is returned.
- The VFD returns an exception response.

Possible causes of no response include the following:

- The serial port is set incorrectly. For example, the converter uses the serial port COM1, but COM2 is selected for the communication.
- The settings of the baud rates, data bits, end bits, and check bits are inconsistent with those set on the VFD.
- The positive pole (+) and negative pole (-) of the RS485 bus are connected reversely.
- The resistor connected to RS485 terminals on the terminal block of the VFD is set incorrectly.

### Appendix A Expansion cards

### A.1 Model definition

## EC-PG 5 01-05 B

1 2 3 4 5 6

Field	Field description	Naming example	
1)	Product category	EC: Expansion card	
2	Card category	IC: IoT card IO: IO card PC: Programmable card PG: PG card PS: Power supply card TX: Communication card	
3	Technical version	Indicates the generation of technical version by using an odd number. For example, 1, 3, 5, and 7 indicate the 1st, 2nd, 3rd and 4th generations of technical version.	
4	Distinguishing code	01: Incremental PG card + frequency-divided output 02: Sine/Cosine PG card + pulse direction setting + frequency-divided output 03: UVW PG interface + pulse direction setting + frequency-divided output 04: Resolver PG interface + pulse direction setting + frequency-divided output 05: Incremental PG card + pulse direction setting + frequency-divided output 06: Absolute PG interface + pulse direction setting + frequency-divided output 07: Simple incremental PG card	
(5)	Working power	00: Passive 05: 5V 12: 12–15 V 24: 24 V	
6	Expansion card version	Empty: Version A B: Version B C: Version C	

# EC-PC 5 02-00

1 2 3 4 5

Field	Field description	Naming example
1)	Product category	
		IC: IoT card
		IO: IO card
2	Card category	PC: Programmable card
	Card category	PG: PG card
		PS: Power supply card
		TX: Communication card
		Indicates the generation of technical version by
	Technical version	using an odd number. For example, 1, 3, 5, and 7
3		indicate the 1st, 2nd, 3rd and 4th generations of
		technical version.
		01: 10 points, with 6 inputs and 4 outputs (2
4		transistor outputs + 2 relay outputs)
	Distinguishing code	02: 8 points of IO, 1 point of AI, 1 point of AO, and 1
		point of RS485 communication
		03: Reserved
5	Special requirement	Reserved. The default value is 00.

## EC-TX 5 01 B

1 2 3 4 5

Field	Field description	Naming example
1)	Product category	EC: Expansion card
2	Card category	IC: IoT card IO: IO card PC: Programmable card PG: PG card PS: Power supply card TX: Communication card
3	Technical version	Indicates the generation of technical version by using an odd number. For example, 1, 3, 5, and 7 indicate the 1st, 2nd, 3rd and 4th generations of

Field	Field description	Naming example
		technical version.
		01: Bluetooth communication card
		02: WIFI communication card
		03: PROFIBUS communication card
		04: Ethernet communication card
		05: CANopen communication card
	Distinguishing code	06: DeviceNet communication card
4		07: BACnet communication card
		08: EtherCAT communication card
		09: PROFINET communication card
		10: EtherNet/IP communication card
		11: CAN master/slave control communication card
		15: Modbus TCP communication card
		Empty: Version A
(5)	Expansion card version	B: Version B
		C: Version C

## EC-IO 5 01-00

1	$\bigcirc$	(a)	4	
1	(2)	(3)	(4)	(C)
	$\overline{}$			

Field	Field description Naming example	
1)	Product category	EC: Expansion card
2	Card category	IC: IoT card IO: IO card PC: Programmable card PG: PG card PS: Power supply card TX: Communication card
3	Technical version	Indicates the generation of technical version by using an odd number. For example, 1, 3, 5, and 7 indicate the 1st, 2nd, 3rd and 4th generations of technical version.
4	Distinguishing code	01: Multiple-function I/O expansion card (4 digital inputs, 1 digital output, 1 analog input, 1 analog output, and 2 relay outputs)

Field	Field description	Naming example		
		02: Digital I/O card		
		03: Analog I/O card		
		04: Reserved		
		05: Reserved		
(5)	Special requirement			

Field	Field description	Naming example			
1)	Product category	t category EC: Expansion card			
		IC: IoT card			
		IO: IO card			
②	Card category	PC: Programmable card			
2	Card category	PG: PG card			
		PS: Power supply card			
		TX: Communication card			
		Indicates the generation of technical version by			
(3)	Technical version	using an odd number. For example, 1, 3, 5, and 7			
		indicate the 1st, 2nd, 3rd and 4th generations of			
		technical version.			
		01: GPRS card			
4	Distinguishing code	02: 4G card			
		03: Reserved			
(5)	Antenna type	1: Internal			
•	Antenna type	2: External			
<b>6</b>	SIM card type	0: Plug-in (standard)			
•	Silvi card type	1: Surface mounted			
(7)		G: With GPS			
	Special requirement	S: Surface mounted SIM card			
U		This field is blank for a standard model since it does			
		not have special functions.			

The following table describes expansion cards that the VFD supports. The expansion cards are optional and need to be purchased separately.

Name	Model	Specification	
IO avecasion aard	EC 10501 00		
IO expansion card	EC-10501-00	♦ 1 digital output	

Name	Model	Specification		
		♦ 1 analog input		
		↑ 1 analog output		
		♦ 2 relay outputs: 1 double-contact output, and 1		
		single-contact output		
IO expansion card 2	EC-IO502-00	♦ 1 PT100		
10 expansion card 2	20-10302-00	♦ 1 PT1000		
		♦ 2 relay outputs: single-contact output		
		Adopting the global mainstream development		
		environment PLC, supporting multiple types of		
		programming languages, such as the instruction		
		language, structural text, function block diagram,		
		ladder diagram, continuous function chart, and sequential function chart		
		Supporting breakpoint commissioning and periodic		
Programmable		task run mode selection		
expansion card	EC-PC502-00	<ul> <li>Providing user program storage space of 16K steps,</li> </ul>		
oxpanoion dara		and data storage space of 8K words		
		♦ 6 digital inputs		
		♦ 1 AI and 1 AO		
		♦ 1 RS485 communication channel, supporting the		
		host controller to switch the master/slave		
		♦ With INVT's mobile phone APP, you can set the		
		parameters and monitor the states of the VFD		
		through Bluetooth		
Bluetooth	EC-TX501-1	♦ The maximum communication distance in open		
communication card	EC-TX501-2	environments is 30 m.		
		♦ EC-TX501-1 is equipped with a built-in antenna and		
		applicable to molded case machines.		
		♦ EC-TX501-2 is configured with an external sucker		
		antenna and applicable to sheet metal machines.		
		♦ Meeting IEEE802.11b/g/n		
WIFI	EC-TX501-1 EC-TX502-2	♦ With INVT's mobile phone APP, you can monitor the		
communication card		VFD locally or remotely through WIFI communication		
		♦ The maximum communication distance in open		
		environments is 30 m.		

Name	Model	Specification
		♦ EC-TX501-1 is equipped with a built-in antenna and
		applicable to molded case machines.
		♦ EC-TX501-2 is configured with an external sucker
		antenna and applicable to sheetmetal machines.
PROFIBUS-DP communication card	EC-TX503	
Ethernet	EC-TX504	internal protocol
communication card	LO-17304	♦ Can be used in combination with INVT's upper
		computer monitoring software INVT Workshop
CANopen	EC-TX505	♦ Based on the CAN2.0A physical layer
communication card	E0-17/303	
PROFINET communication card	EC-TX509	♦ Supporting the PROFINET protocol
		protocol
Ethernet/IP	FC-TX510	♦ With two Ethernet IP ports, supporting 10/100M
communication card	LO-17/310	half/full duplex operating
		not supporting ring network monitoring)
CAN master/slave		♦ Based on the CAN2.0B physical layer
control	EC-TX511	♦ Adopting INVT's master-slave control proprietary
communication card		protocol
		♦ With two Modbus TCP IO ports, supporting 100M full
Modbus TCP	EC-TX515	duplex operating, and supporting line and star
communication card	20 17.010	network topologies, with the nodes up to 32
		♦ Able to function as a Modbus TCP slave
		♦ Applicable to Sin/Cos encoders with or without CD
Sin/Cos PG card	EC-PG502	signals
J, 555 1 5 54.4	20.0002	♦ Supporting A, B, Z frequency-divided output
		Supporting input of pulse train reference
		♦ Applicable to 5V differential encoders
UVW incremental		Supporting A, B, Z orthogonal input
PG card	EC-PG503-05	Supporting U, V, W 3PH pulse input
		Supporting A, B, Z frequency-divided output
		♦ Supporting input of pulse train reference
Resolver PG card	EC-PG504-00	Applicable to resolver encoders
		♦ Supporting simulated A, B, Z frequency-divided

Name	Model	Specification		
		output of resolvers		
		<ul> <li>Supporting input of pulse train reference</li> </ul>		
		♦ Applicable to OC encoders of 5 V or 12 V		
		♦ Applicable to push-pull encoders of 5 V or 12 V		
Multi-function		♦ Applicable to differential encoders of 5 V		
incremental PG card	EC-PG505-12	<ul> <li>Supporting the orthogonal input of A, B, and Z</li> </ul>		
incremental PG card		♦ Supporting the frequency-divided output of A, B, and		
		Z		
		♦ Supporting pulse train setting		
	EC-PG505-24	♦ Applicable to 24V OC encoders		
		♦ Applicable to 24 V push-pull encoders		
24V incremental PG		♦ Applicable to 5 V differential encoders		
card		<ul> <li>Supporting A, B, Z orthogonal input</li> </ul>		
		♦ Supporting A, B, Z frequency-divided output		
		♦ Supporting pulse train reference input		
Cimania in aram antal		♦ Applicable to 5 V or 12 V OC encoders		
Simple incremental PG card	EC-PG507-12	♦ Applicable to 5 V or 12 V push-pull encoders		
PG card		♦ Applicable to 5 V differential encoders		
0.4) / = i = lifi = -l		♦ Applicable to 24 V OC encoders		
24V simplified	EC-PG507-24	♦ Applicable to 24 V push-pull encoders		
incremental PG card		♦ Applicable to 24 V differential encoders		
ODD0	FO 10504 C	♦ Supporting IoT monitoring		
GPRS card	EC-IC501-2	♦ Supporting remote VFD upgrade		

**Remarks:** Contact us for details about the EtherCAT communication card, 24V power supply card, and the shockproof GPRS card with high-precision GPS positioning.



IO expansion card EC-IO501-00



IO expansion card 2 EC-IO502-00



Programmable expansion card EC-PC502-00



Bluetooth/WIFI communication card EC-TX501/502



PROFIBUS-DP communication card EC-TX503



Ethernet communication card EC-TX504



CANopen/CAN master/slave control communication card EC-TX505/511



PROFINET communication card EC-TX509



Ethernet/IP communication card EC-TX510/ EC-TX515



Sin/Cos PG card EC-PG502



UVW incremental PG card EC-PG503-05



Resolver PG card EC-PG504-00



Multifunction incremental PG card EC-PG505-12



24V incremental PG card EC-PG505-24



Simplified incremental PG card EC-PG507-12



24V simplified incremental PG card EC-PG507-24



GPRS card EC-IC501-2

#### A.2 Dimensions and installation

All expansion cards are of the same dimensions (108 mm  $\times$  39 mm) and can be installed in the same way.

Comply with the following operation principles when installing or removing an expansion card:

- 1. Ensure that no power is applied before installing an expansion card.
- 2. An expansion card can be installed into a respective card slot among SLOT1, SLOT2, and SLOT3.
- 3. VFDs of 5.5 kW or lower can be configured with two expansion cards at the same time, and those of 7.5 kW or higher can be configured with three expansion cards.
- 4. If interference occurs on the external wires after expansion cards are installed, change their installation card slots flexibly to facilitate the wiring. For example, the connector of the connection cable of the DP card is large, so it is recommended to be installed in the SLOT1 card slot.
- 5. To ensure high anti-interference capability in closed-loop control, you need to use a shielding wire in the encoder cable and ground the two ends of the shielding wire, that is, connect the shielding layer to the housing of the motor on the motor side, and connect the shielding layer to the PE terminal on the PG card side.

**Note:** For 2.2–5.5kW models, the 24V power suply card can be inserted into SLOT1; for 7.5kW and higher models, the 24V power supply card can be inserted into SLOT1 or SLOT3; for 11kW and higher models, the 24V power supply card can be inserted into any of the three slots.

Figure A.1 shows the installation diagram and a VFD with expansion cards installed.




Figure A.1 VFD of 7.5 kW or higher with expansion cards installed




Figure A.2 VFD of 5.5 kW or lower with expansion cards installed Expansion card installation process:




Figure A.3 Expansion card installation process diagram

### A.3 Wiring

1. Ground a shielded cable as follows:




Figure A.4 Expansion card grounding diagram

2. Wire an expansion card as follows:





Figure A.5 Expansion card wiring

#### A.4 IO expansion cards

#### A.4.1 IO expansion card 1 (EC-IO501-00)




CME and COM are shorted through J3 before delivery, and J5 is the jumper for selecting the output type (voltage or current) of AO2.

The terminals are arranged as follows:

Al3	AO2	GND
-----	-----	-----

СОМ	CME	Y2	S5	
PW	+24V	S6	S7	S8



#### Indicator definition

Indicator	Name	Description		
LED1	State indicator	On: The expansion card is establishing a connection with the control board.  Blinking periodically: The expansion card is properly connected to the control board (the period is 1s, on for 0.5s, and off for the other 0.5s).  Off: The expansion card is disconnected from the control board.		
LED4	Power indicator	On: The control board feeds power to the expansion card.		


The EC-IO501-00 expansion card can be used in scenarios where the I/O interfaces of a Goodrive350-UL VFD cannot meet the application requirements. It can provide 4 digital inputs, 1 digital output, 1 analog input, 1 analog output, and two relay outputs. It is user-friendly, providing relay outputs through European-style screw terminals and other inputs and outputs through spring terminals.

EC-IO501-00 terminal function description

Category	Symbol	Name	Description	
Power	PW	External power supply	The working power of digital input is provided by an external power supply.  Voltage range: 12–30 V  The terminals PW and +24V are shorted before delivery.	
Analog input/output	AI3—GND	Analog input 1	1. Input range: $0$ – $10$ V, $0$ – $20$ mA 2. Input impedance: $20$ k $\Omega$ for voltage input; $250$ $\Omega$ for current input 3. Set it to be voltage or current input through the corresponding function code. 4. Resolution: When $10$ V corresponds to $50$ Hz, the minimum resolution is $5$ mV.	

Category	Symbol	Name	Description
			5. Deviation: ±0.5%; input of 5 V or 10 mA
			or higher at the temperature of 25°C
			1. Output range: 0–10 V, 0–20 mA
			2. Whether it is voltage or current output is
	AO2—GND	Analog output 1	determined by J5.
			3. Deviation ±0.5%; output of 5 V or 10 mA
			or higher at the temperature of 25°C
	S5—COM	Digital input 1	1. Internal impedance: 3.3 kΩ
	S6—COM	Digital input 2	2. Power input range: 12–30 V
	S7—COM	Digital input 3	3. Bidirectional input terminal
Digital	S8—COM	Digital input 4	4. Max. input frequency: 1 kHz
input/output			1. Switch capacity: 50 mA/30 V
	Y2—CME	Digital output	2. Output frequency range: 0–1 kHz
	Y2—CIVIE		3. The terminals CME and COM are
			shorted through J3 before delivery.
	RO3A	NO contact of	
	ROSA	relay 3	
	RO3B	NC contact of	
	KO3B	relay 3	1. Contact capacity: 3A/AC 250 V, 1A/DC
Relay	RO3C	Common contact	30 V
output	ROSC	of relay 3	2. Do not use them as high-frequency
	RO4A	NO contact of	digital outputs.
	RO4A	relay 4	
	RO4C	Common contact	
	KU4C	of relay 4	


A.4.2 IO expansion card 2 (EC-IO502-00)



The terminals are arranged as follows.

PT1+	PT-	PT2+
------	-----	------

S5	S6	S7	S8
+24V	PW	СОМ	СОМ



#### Indicator definition

Indicator	Definition	Function	
LED1		This indicator is on when the expansion card is	
		establishing a connection with the control board; it	
	State	blinks periodically after the expansion card is properly	
	indicator	connected to the control board (the period is 1s, on for	
		0.5s, and off for the other 0.5s); and it is off when the	
		expansion card is disconnected from the control board.	
LED4	Power	This indicator is on after the IO expansion card is	
	indicator	powered on by the control board.	

The EC-IO502-00 expansion card can be used in scenarios where the IO interfaces of the VFD cannot meet the application requirements. It can provide four digital inputs, one PT100 temperature measurement input (PT1+), one PT1000 temperature measurement input (PT2+), and two relay outputs. It is user-friendly, providing relay outputs and digital inputs through European-style screw terminals and temperature measurement inputs through spring terminals.

#### EC-IO502-00 terminal function description

Category	Symbol	Name	Function	
Power	PW		The working power of digital input is	
		External power	provided by an external power supply.	
		supply	Voltage range: 24(-20%)-48VDC(+10%),	
			24(-10%)-48VAC(+10%)	
	+24V	Internal power	User power provided by the VFD.	
			Max. output current: 200mA	
	COM	Power reference	Common terminal of +24V	
Digital input	S5—COM	Digital input 5	Internal impedance: 6.6kΩ	
	S6—COM	Digital input 6	Supported external power:	
	S7—COM	Digital input 7	24(-20%)-48VDC(+10%),	
	S8—COM	Digital input 8	24(-10%)-48VAC(+10%)	
			Supporting internal power 24V	
			Bi-directional input terminals, supporting	
			NPN/PNP modes	

Category	Symbol	Name	Function	
			Max. input frequency: 1kHz	
			All are programmable digital input	
			terminals. You can set the terminal	
			function via function codes.	
	PT1+	PT100 input	Independent PT100 and PT1000 inputs.	
			PT1+ connects to PT100, and PT2+	
Temperature detection input	PT2+	PT1000 input	connects to PT1000.	
			1. Resolution: 1°C	
			2. Range: -20°C–150°C	
			3. Detection accuracy: 3°C	
			4. Supporting offline protection	
	PT-	Reference input of	Zero potential reference of	
		PT100/PT1000	PT100/PT1000	
Relay output	RO3A	Contact A of NO	RO3 relay output. RO3A: NO; RO3C:	
		relay 3		
	RO3C	Contact C of NO	common terminal	
		relay 3	Contact capacity: 3A/AC250V, 1A/DC30V	
	RO4A	Contact A of NO	RO4 relay output. RO4A: NO; RO4C:	
		relay 4	common terminal	
	RO4C	Contact C of NO	Contact capacity: 3A/AC250V, 1A/DC30V	
		relay 4		





Figure A.6 Control circuit wiring of IO expansion card 2

# A.5 Programmable expansion card (EC-PC502-00)




SW1 is the start/stop switch of the programmable expansion card. CN1 contains terminals PE, 485-, 485+, GND, Al1, and AO1, and a selection jumper resides on the next. "Al" and "AV" are the current type input selection and voltage type input selection of Al1, and they can be selected through J2. "AlO" and "AVO" are the current type output selection and voltage type output selection of AO1, and they can be selected through J5. "120" indicates  $120\Omega$  terminal resistor, and it can connect to J1. By default, J1 connects to NC, J2 to AV, and J5 to AVO.

The terminals are arranged as follows.

PE 485- 485	+ GND	Al1	AO1
-------------	-------	-----	-----

СОМ	СОМ	PS1	PS2	PS3
PW	24V	PS4	PS5	PS6



Indicator	Name	Description
LED1	PWR power indicator	The indicator is on when the expansion card is
LEDI	(green)	powered on.
LED3	COMM communication indicator (green)	This indicator is on when the expansion card is establishing a connection with the control board; it blinks periodically after the expansion card is properly connected to the control board (the period is 1s, on for 0.5s, and off for the other 0.5s); and it is off when the expansion card is
		disconnected from the control board.
LED4	ERR fault indicator (red)	Blinks: an error occurs (the period is 1s, on for 0.5s, and off for the other 0.5s), and the error type can be queries through the upper computer Auto Station; Off: no fault.
LED5	PWR power indicator	The indicator is on when the expansion card is

Indicator	Name	Description
	(green)	powered on.
LEDG	DLIN status indicator (are en)	On: PLC program is running
LED6	RUN status indicator (green)	Off: PLC program stops

The EC-PC502-00 programmable expansion card can replace some micro PLC applications. It adopts the global mainstream development environment PLC, supporting the instruction language (IL), ladder diagram (LD), and sequential function chart (SFC). It provides a user program storage space of 16K steps and data storage space of 8K words, and supports saving data of 1K words at power failure, which facilitate customers' secondary development and meets the customization requirements.

The EC-PC502-00 programmable expansion card provides six digital inputs, 2 relay outputs, 1 analog input, 1 analog output, 1 RS485 communication channel (supports master/slave switchover). It is user-friendly, providing relay outputs through European-style screw terminals and other inputs and outputs through spring terminals.

EC-PC502-00 terminal function description


Category	Symbol	Name	Function
Power supply	PW	External power supply	To provide input digital working power from external to internal.  Voltage range: 12–24V  PW and +24V are short connected by default.
	24V	Internal power supply	Internal output power supply, 100mA
Common	СОМ	Common terminal of +24V	Common terminal of +24V. If PS1 is connected, COM indicates PS1 is connected.
terminal/ground	GND	Analog ground	Reference zero potential of +10V
	PE	Protective earthing terminal	Protective earthing terminal
	PS1—COM	Digital input 1	1. Internal impedance: 4kΩ
	PS2—COM	Digital input 2	2. Accept 12–30V voltage input
Digital input	PS3—COM	Digital input 3	3. Bi-directional input terminal
Digital input	PS4—COM	Digital input 4	4. Max. input frequency: 1kHz
	PS5—COM	Digital input 5	5. Both source and sink inputs are allowed,
	PS6—COM	Digital input 6	but the input types must be the same
Analog input and output	Al1	Analog input 1	Input range: Al1 voltage and current range: 0–10V, 0–20mA     Input impedance: 20kΩ during voltage

Category	Symbol	Name	Function
			input; 250Ω during current input
			3. Voltage or current input is set through
			the jumper.
			4. Resolution ratio: When 10V corresponds
			to 50Hz, the min. resolution ratio is 5mV
			5. Deviation: ±1% when the input reaches
			full the measurement range at 25°C
			1. Output range: 0-10V voltage or 0-20mA
			current
	101	A made manufacture 4	2. Voltage or current output is set through
	AO1	Analog output 1	the jumper.
			3. Deviation: ±1% when the input reaches
			full the measurement range at 25°C.
	PRO1A	NO contact of relay 1	
	PRO1C	Common contact of	1. Contact capacity: 2A/AC250V,
Delevieuteut	PROTE	relay 1	1A/DC30V
Relay output	PRO2A	NO contact of relay 2	2. Unable to function as high frequency
	PRO2C	Common contact of	switch output
	PROZU	relay 2	
			RS485 communication port, which can be
	485+	RS485	set as the master or slave through the Auto
Communication		communication	Station. It is differential signal output.
	485-	terminal	Whether to connect the 120Ω resistor of
			RS485 is set through the jumper.

For details about how to use the programmable card, see the Goodrive350 series AutoStation programmable card manual.

#### A.6 Communication cards

#### A.6.1 Bluetooth communication card (EC-TX501) and WIFI communication card (EC-TX502)




#### Definitions of indicators and function buttons


Indicator	Name	Description	
		On: The expansion card is establishing a connection with	
		the control board.	
LED4/LED2	Bluetooth/WIFI	Blinking periodically: The expansion card is properly	
LED1/LED3	state indicator	connected to the control board (the period is 1s, on for	
		0.5s, and off for the other 0.5s).	
		Off: The expansion card is disconnected from the control	
		board.	
	Bluetooth	On: Bluetooth communication is online and data	
LED2	communication	exchange can be performed.	
	state indicator	Off: Bluetooth communication is not in the online state.	
LED5	Power indicator	On: The control board feeds power to the Bluetooth card.	
SW1	WIFI factory reset	It is used to restore the expansion card to default values	
3001	button	and return to the local monitoring mode.	
SW2	WIFI hardware	It is used to rectart the expansion card	
3002	reset button	It is used to restart the expansion card.	

The wireless communication card is especially useful for scenarios where you cannot directly use the keypad to operate the VFD due to the restriction of the installation space. With a mobile phone APP, you can operate the VFD in a maximum distance of 30 m. You can choose a PCB antenna or an external sucker antenna. If the VFD is located in an open space and is a molded case machine, you can use a built-in PCB antenna; and if it is a sheetmetal machine and located in a metal cabinet, you need to use an external sucker antenna.


When installing a sucker antenna, install a wireless communication card on the VFD first, and then lead the SMA connector of the sucker antenna into the VFD and screw it to CN2, as shown in the following figure. Place the antenna base on the chassis and expose the upper part. Try to keep it unblocked.




The wireless communication card must be used with the INVT VFD APP. Scan the QR code of the VFD nameplate to download it. For details, refer to the wireless communication card manual provided with the expansion card. The main interface is shown as follows.



## A.6.2 PROFIBUS-DP communication card (EC-TX503)



CN1 is a 9-pin D-type connector, as shown in the following figure.



Con	nector pin	Description
1	-	Unused
2	-	Unused
3	B-Line	Data+ (twisted pair 1)
4	RTS	Request transmission
5	GND_BUS	Isolation ground
6	+5V BUS	Isolated power supply of 5 V DC
7	-	Unused
8	A-Line	Data- (twisted pair 2)
9	-	Unused
Housing	SHLD	PROFIBUS cable shielding line

+5V and GND\_BUS are bus terminators. Some devices, such as the optical transceiver (RS485), may need to obtain power through these pins.


On some devices, the transmission and receiving directions are determined by RTS. In normal applications, only A-Line, B-Line, and the shield layer need to be used.

Indicator	Name	Description
		On: The expansion card is establishing a connection with the
LED1	State indicator	control board.
LEDI	State indicator	Blinking periodically: The expansion card is properly connected
		to the control board (the period is 1s, on for 0.5s, and off for the

Indicator	Name	Description	
		other 0.5s).	
		Off: The expansion card is disconnected from the control	
		board.	
		On: The communication card is online and data exchange can	
LED2	Online indicator	be performed.	
		Off: The communication card is not in the online state.	
		On: The communication card is offline and data exchange	
		cannot be performed.	
		Blinks: The communication card is not in the offline state.	
		Blinks at the frequency of 1 Hz: A configuration error occurs:	
		The length of the user parameter data set during the	
		initialization of the communication card is different from that	
LED3	Offline/Fault	during the network configuration.	
LEDS	indicator	Blinks at the frequency of 2 Hz: User parameter data is	
		incorrect. The length or content of the user parameter data set	
		during the initialization of the communication card is different	
		from that during the network configuration.	
		Blinks at the frequency of 4 Hz: An error occurs in the ASIC	
		initialization of PROFIBUS communication.	
		Off: The diagnosis function is disabled.	
LED4	Power indicator	On: The control board feeds power to the communication card.	

For details about the operation, see the *Goodrive350 Series VFD Communication Expansion Card Operation Manual.* 


## A.6.3 Ethernet communication card (EC-TX504)



The EC-TX504 communication card adopts standard RJ45 terminals. It is used only on the upper computer that supports INVT Workshop. If you want to support the standard EtherNet/IP protocol, select the card EC-TX510.

Indicator	Definition	Function
		On: The expansion card is establishing a connection with the control board.
		Blinking periodically: The expansion card is
LED1	State indicator	properly connected to the control board (the
LEDI	State indicator	period is 1s, on for 0.5s, and off for the other
		0.5s).
		Off: The expansion card is disconnected from the
		control board.
	Network connection	On: The physical connection to the upper
LED2	status indicator	computer is normal.
	Status indicator	Off: The upper computer is disconnected.
	Network	On: There is data exchange with the upper
LED3	communication status	computer.
LEDS	indicator	Off: There is no data exchange with the upper
	indicator	computer.
LED4	Power indicator	On: The control board feeds power to the
LED4	Fower indicator	communication card.

A.6.4 CANopen communication card (EC-TX505) and CAN master/slave control communication card (EC-TX511)



The EC-TX505/511 communication card is user-friendly, adopting spring terminals.

3-pin spring terminal	Pin	Function	Description
1 2 3	1	CANH	CANopen bus high level signal
888	2	CANG	CANopen bus shielding
	3	CANL	CANopen bus low level signal

Terminal resistor switch function description


Terminal resistor switch	Position	Function	Description	
	Left	OFF	CAN_H and CAN_L are not connected to a terminal resistor.	
	Right	ON	CAN_H and CAN_L are connected to a terminal resistor of 120 $\Omega$ .	

## Indicator definition

Indicator	Definition	Function
		On: The communication card is establishing a connection with the control board.
		Blinking periodically: The communication card is properly
LED1	State indicator	connected to the control board (the period is 1s, on for 0.5s,
		and off for the other 0.5s).
		Off: The communication card is disconnected from the control board.
		On: The control board feeds power to the communication
LED4	Power indicator	card.
		On: The communication card is running.
		Off: A fault occurs. Check whether the reset pin of the
LED5	Running indicator	communication card and the power supply are properly
LEDS		connected.
		Blinks: The communication card is in the pre-operation state.
		Blinks once: The communication card is in the stopped state.
		On: The CAN controller bus is off or a fault occurs on the
		VFD.
LED6	Error indicator	Off: The communication card is in the working state.
LEDO	LITOI IIIUICAIOI	Blinks: The address setting is incorrect.
		Blinks once: A received frame is missed or an error occurs
		during frame receiving.

For details about the operation, see the *Goodrive350 Series VFD Communication Expansion Card Operation Manual.* 

## A.6.5 PROFINET communication card (EC-TX509)



The terminal CN2 adopts a standard RJ45 interface, where CN2 is the dual RJ45 interface, and these two RJ45 interfaces are not distinguished from each other and can be interchangeably inserted. They are arranged as follows:

Pin	Name	Description
1	TX+	Transmit Data+
2	TX-	Transmit Data-
3	RX+	Receive Data+
4	n/c	Not connected
5	n/c	Not connected
6	RX-	Receive Data-
7	n/c	Not connected
8	n/c	Not connected

Definition of the state indicator


The PROFINET communication card has 9 indicators, of which LED1 is the power indicator, LEDs 2–5 are the communication state indicators of the communication card, and LEDs 6–9 are the state indicators of the network port.

Indicator	Color	State	Description
LED1	Green		3.3V power indicator
		On	No network connection
			The connection to the PROFINET
LED2		Dlinking	controller through a network cable is
	Red	Blinking	OK, but the communication is not
(Bus state indicator)			established.
		Off	Communication with the PROFINET
			controller has been established
LED3	0	On	PROFINET diagnosis is enabled
(System fault indicator)	Green	Off	PROFINET diagnosis is not enabled
LED4	Craan	On	TPS-1 protocol stack has started
(Slave ready indicator)	Green	Blinking	TPS-1 waits for MCU initialization

Indicator	Color	State	Description
		Off	TPS-1 protocol stack does not start
LED5 (Maintenance state indicator)	Green		Manufacturer-specific—depending on the characteristics of the device
LED6/7 (Network port state	Green	On	PROFINET communication card and PC/PLC have been connected through a network cable.
indicator)		Off	PROFINET communication card and PC/PLC have not been connected.
LED8/9 (Network port	On		PROFINET communication card and PC/PLC are communicating.
communication indicator)	Green	Off	PROFINET communication card and PC/PLC are not communicating.


#### **Electrical connection**

The PROFINET communication card adopts a standard RJ45 interface and can adopt the linear network topology or star network topology. The electrical connection in linear network topology mode is shown in the following.




Note: For the star network topology, you need to prepare PROFINET switches.

The electrical connection in start network topology mode is shown in the following.



# A.6.6 EtherNet/IP communication card (EC-TX510) and Modbus TCP communication card (EC-TX515)



The communication port adopts standard dual RJ45 interfaces, and the two RJ45 interfaces are not distinguished from each other and can be interchangeably inserted.



Figure A.7 Standard RJ45 interface

#### Standard RJ45 interface functions

Pin	Name	Description
1	TX+	Transmit Data+
2	TX-	Transmit Data-
3	RX+	Receive Data+
4	n/c	Not connected
5	n/c	Not connected
6	RX-	Receive Data-
7	n/c	Not connected
8	n/c	Not connected

#### Indicator definition

The EtherNet/IP communication card provides four LED indicators and four net port indicators to indicate its states.

Indicator	Color	State	Description	
		On	The card is shaking hands with the VFD.	
LED1	LED1 Green	Green Blinking (1Hz)		The card and VFD communicate normally.
		Off	The card and VFD communicate improperly.	
LED2	Green	On	The communication between the card and PLC is online and data interchange is allowed.	
	Groom	Blinking (1Hz)	IP address conflict between the card and PLC.	

Indicator	Color	State	Description						
		Off	The communication between the card and PLC is offline.						
		On	Failed to set up I/O between the card and PLC.						
		Blinking (1Hz)	Incorrect PLC configuration.						
LEDO	Dod	Blinking (2Hz)	The card failed to send data to the PLC.						
LED3	Red	Blinking (4Hz)	The connection between the card and PLC timed out.						
		Off	No fault.						
LED4	Red	On	3.3V power indicator.						
Net port	Net port	On	Link indicator, indicating successful Ethernet connection.						
indicator Yellow	Yellow	Off	Link indicator, indicating Ethernet connection not established.						
Net port		On	ACK indicator, indicating data interchange being performed.						
indicator	Green	Green	Green	Green	Green	Green	Green	Off	ACK indicator, indicating data interchange not be performed.

#### **Electrical wiring**

The EtherNet/IP communication card provides standard RJ45 ports and supports the linear, star, and ring topologies. The following three figures show the electrical wiring diagrams.

Use CAT5, CAT5e, and CAT6 network cables for electrical wiring. When the communication distance is greater than 50 meters, use high-quality network cables that meet the high-quality standards.




Figure A.8 Electrical wiring diagram for a linear topology




Figure A.9 Electrical wiring diagram for a star topology

Note: Ethernet switches must be available when the star topology is used.





Figure A.10 Electrical wiring diagram for a ring network

## A.7 PG cards

#### A.7.1 Sin/Cos PG card (EC-PG502)



The terminals are arranged as follows:

							C1+	C1-	D1+	D1-
PE	AO+	ВО+	ZO+	A1+	B1+	R1+	A2+	B2+	Z2+	PWR
GND	AO-	во-	ZO-	A1-	B1-	R1-	A2-	B2-	Z2-	GND


Indicator	Name	Description	
	Discommention	Off: A1 and B1 of the encoder are disconnected.	
LED1	Disconnection	Blinking: C1 and D1 of the encoder are disconnected.	
	indicator	On: The encoder signals are normal.	
LEDO	Power	One The exertise has and for a degree course to the DO exert	
LED2	indicator	On: The control board feeds power to the PG card.	
LEDO	State	On: The expansion card is establishing a connection with the	
LED3	indicator	control board.	

Indicator	Name	Description	
		Blinking periodically: The expansion card is properly	
		connected to the control board (the period is 1s, on for 0.5s,	
		and off for the other 0.5s).	
		Off: The expansion card is disconnected from the control	
		board.	


## EC-PG502 terminal function description

Signal	Port	Function				
PWR		Voltage: 5 V ± 5%				
GND	Encoder power	Max. output current: 150 mA				
A1+						
A1-						
B1+		1 0 1 0 1				
B1-		1. Supporting Sin/Cos encoders				
R1+	Encoder interface	2. SINA/SINB/SINC/SIND 0.6–1.2Vpp; SINR 0.2–0.85Vpp				
R1-	Encoder internace	3. Max. frequency response of A/B signals: 200 kHz				
C1+		Max. frequency response of C/D signals: 1 kHz				
C1-		Wax. requericy response of O/D signals. 1 KHZ				
D1+						
D1-						
A2+						
A2-						
B2+	Pulse reference	Supporting 5V differential signal				
B2-	Puise reference	2. Frequency response: 200 kHz				
Z2+						
Z2-						
AO+						
AO-		1. Differential output of 5 V				
BO+	Frequency-divided	2. Supporting frequency division of 2 <sup>N</sup> , which can be				
BO-	output	set through P20.16 or P24.16; Max. output				
ZO+		frequency: 200 kHz				
ZO-						


The following figure shows the external wiring of the PG card when it is used in combination with an encoder without CD signals.



The following figure shows the external wiring of the PG card when it is used in combination with an encoder with CD signals.



## A.7.2 UVW incremental PG card (EC-PG503-05)



The terminals are arranged as follows:

					A2+	A2-	B2+	B2-	Z2+	Z2-
PE	AO+	BO+	ZO+	A1+	B1+	Z1+	U+	V+	W+	PWR
GND	AO-	во-	ZO-	A1-	B1-	Z1-	U-	V-	W-	PGND

#### Indicator definition

Indicator	Name	Description
LED1 Disconnection		This indicator blinks only if A1 or B1 signal is disconnected
LEDI	indicator	during encoder rotating; and it is on in other cases.
LED2  On: The expansion card is establishing a connectic control board.  Blinking periodically: The expansion card is properly to the control board (the period is 1s, on for 0.5s, an other 0.5s).		Blinking periodically: The expansion card is properly connected to the control board (the period is 1s, on for 0.5s, and off for the
LED3	Power indicator	On: The control board feeds power to the PG card.


The EC-PG503-05 expansion card supports the input of absolute position signals and integrates the advantages of absolute and incremental encoders. It is user-friendly, adopting spring terminals.

#### EC-PG503-05 terminal function description

Signal	Port	Description		
PWR	Fd	Voltage: 5 V±5%		
PGND	Encoder power	Max. current: 200 mA		
A1+				
A1-		4 BW (11)		
B1+	Encoder interface	Differential incremental PG interface of 5 V		
B1-		2. Response frequency: 400 kHz		
Z1+				

Signal	Port	Description		
Z1-				
A2+				
A2-				
B2+	Dulas asttina	1. Differential input of 5 V		
B2-	Pulse setting	2. Response frequency: 200 kHz		
Z2+				
Z2-				
AO+				
AO-		4 5 1/2		
BO+	Frequency-divided	Differential output of 5 V     Supporting frequency division of 1–255, which can be set through P20.16 or P24.16		
BO-	output			
ZO+				
ZO-				
U+				
U-		4 41 1 4 22 41 44 44 4 4 4 4 4 4 4 4 4 4		
V+	UVW encoder interface	1. Absolute position (UVW information) of the		
V-	O v vv encoder interrace	hybrid encoder, differential input of 5 V		
W+		2. Response frequency: 40 kHz		
W-				

The following figure shows the external wiring of the EC-PG503-05 expansion card.



## A.7.3 Resolver PG card (EC-PG504-00)



PE	AO+	BO+	ZO+	EX+	SI+	CO+	A2+	B2+	Z2+	PWR
GND	AO-	во-	ZO-	EX-	SI-	CO-	A2-	B2-	Z2-	GND

#### Indicator definition

Indicator	Name	Description
LED1	State indicator	On: The expansion card is establishing a connection with the control board.  Blinking periodically: The expansion card is properly connected to the control board (the period is 1s, on for 0.5s, and off for the other 0.5s).  Off: The expansion card is disconnected from the control board.
LED2	Disconnection indicator	Off: The encoder is disconnected. On: The encoder signals are normal. Blinks: The encoder signals are not stable.
LED3	Power indicator	On: The control board feeds power to the PG card.


The EC-PG504-00 expansion card can be used in combination with a resolver of excitation voltage 7 Vrms. It is user-friendly, adopting spring terminals.

## EC-PG504-00 terminal function description


Signal	Port	Description		
SI+	Encoder signal input	Recommended resolver transformation ratio: 0.5		

Signal	Port	Description
SI-		
CO+		
CO-		
EX+	Encoder excitation	1. Factory setting of excitation: 10 kHz
EX-	signal	Supporting resolvers with an excitation voltage of 7 Vrms
A2+		
A2-		
B2+	<b>.</b>	1. Differential input of 5 V
B2-	Pulse setting	2. Response frequency: 200 kHz
Z2+		
Z2-		
AO+		1. Differential output of 5 V
AO-		Frequency-divided output of resolver simulated
BO+	Frequency-divided output	A1, B1, and Z1, which is equal to an incremental PG card of 1024 pps.
во-		3. Supporting frequency division of 2 <sup>N</sup> , which can
ZO+		be set through P20.16 or P24.16
ZO-		4. Max. output frequency: 200 kHz

The following figure shows the external wiring of the EC-PG504-00 expansion card.



A.7.4 Multifunction incremental PG card (EC-PG505-12)



The terminals are arranged as follows:

The dual in-line package (DIP) switch SW1 is used to set the voltage class (5 V or 12 V) of the power supply of the encoder. The DIP switch can be operated with an auxiliary tool.

Pl		AO+	BO+	ZO+	A1+	B1+	Z1+	A2+	B2+	Z2+	PWR
GN	ID	AO-	во-	ZO-	A1-	B1-	Z1-	A2-	B2-	Z2-	PGND

Indicator	Name	Description
LED1	State indicator	On: The expansion card is establishing a connection with the


Indicator	Name	Description
		control board.
		Blinking periodically: The expansion card is properly connected
		to the control board (the period is 1s, on for 0.5s, and off for the
		other 0.5s).
		Off: The expansion card is disconnected from the control
		board.
LED2	Disconnection	This indicator blinks only if A1 or B1 signal is disconnected
LED2	indicator	during encoder rotating; and it is on in other cases.
LED3	Power indicator	On: The control board feeds power to the PG card.

The EC-PG505-12 expansion card can be used in combination with multiple types of incremental encoders through different modes of wiring. It is user-friendly, adopting spring terminals.


## EC-PG505-12 terminal function description

Signal	Port	Description			
PWR		Voltage: 5 V/12 V ±5%			
		Max. output: 150 mA			
PGND	Encoder power	Select the voltage class through the DIP switch			
PGND		SW1 based on the voltage class of the used			
		encoder.			
A1+					
A1-		1. Supporting push-pull interfaces of 5 V/12 V			
B1+	Encodor interface	2. Supporting open collector interfaces of 5 V/12 V			
B1-	Encoder interface	3. Supporting differential interfaces of 5 V			
Z1+		4. Response frequency: 200 kHz			
Z1-					
A2+					
A2-					
B2+	Dulas authori	Supporting the same signal types as the encoder			
B2-	Pulse setting	signal types			
Z2+		2. Response frequency: 200 kHz			
Z2-					
AO+					
AO-		4 8%			
BO+	Frequency-divided	Differential output of 5 V     Output of 5 v			
ВО-	output	2. Supporting frequency division of 1–255, which			
ZO+		can be set through P20.16 or P24.16			
ZO-					


The following figure shows the external wiring of the expansion card used in combination with an open collector encoder. A pull-up resistor is configured inside the PG card.




The following figure shows the external wiring of the expansion card used in combination with a push-pull encoder.



The following figure shows the external wiring of the expansion card used in combination with a differential encoder.



# A.7.5 24V incremental PG card (EC-PG505-24)



The terminals are arranged as follows:

	PE	AO	ВО	A1+	B1+	Z1+	A2+	B2+	Z2+	PWR
ĺ	GND	PGND	ZO	A1-	B1-	Z1-	A2-	B2-	Z2-	PGND

#### Indicator definition

Indicator	Name	Description
LED1	State indicator	On: The expansion card is establishing a connection with the control board.  Blinking periodically: The expansion card is properly connected to the control board (the period is 1s, on for 0.5s, and off for the other 0.5s).  Off: The expansion card is disconnected from the control board.
LED2	Disconnection indicator	This indicator blinks only if A1 or B1 signal is disconnected during encoder rotating; and it is on in other cases.
LED3	Power indicator	On: The control board feeds power to the PG card.


EC-PG505-24 can work in combination with multiple types of incremental encoders through various external wiring modes. It is user-friendly, adopting spring terminals.

#### EC-PG505-24 terminal function description


Signal	Port	Description
PWR	Encoder power	Voltage: 24 V ± 5%
PGND	supply	Max. output current: 150 mA
A1+		
A1-		
B1+		1. Supporting 24 V push-pull interfaces
B1-	Encoder interface	2. Supporting 24 V open collector interfaces
Z1+		3. Frequency response: 200 kHz
Z1-		

Signal	Port	Description		
A2+				
A2-				
B2+	Pulse reference	Supporting interfaces whose signal type is the		
B2-		same as the encoder 2. Frequency response: 200 kHz		
Z2+				
Z2-				
AO		Open collector output		
ВО	Frequency-divided	2. Supporting frequency division of 1–255, which		
ZO	output	can be set through P20.16 or P24.16		


The following figure shows the external wiring of the PG card when it is used in combination with an open collector encoder. A pull-up resistor is configured in the PG card.



The following figure shows the external wiring of the PG card when it is used in combination with a push-pull encoder.



## A.7.6 Simplified incremental PG card (EC-PG507-12)



The DIP switch SW1 is used to set the voltage class (5 V or 12 V) of the power supply of the encoder. The DIP switch can be operated with an auxiliary tool.

The terminals are arranged as follows:

PE	A1+	B1+	Z1+	PWR
PGND	A1-	B1-	Z1-	PGND

Indicator	Name	Description
		On: The expansion card is establishing a connection with the
LED1 State indicator control board.	control board.	
LEDI	State indicator	Blinking periodically: The expansion card is properly connected to
		the control board (1s duration, on for 0.5s, and off for the other


Indicator	Name	Description
		0.5s).
		Off: The expansion card is disconnected from the control board.
1.500	Disconnection	Off: A1 or B1 of the encoder is disconnected.
LED2	indicator	On: The encoder pulses are normal.
LED3	Power indicator	On: The control board feeds power to the PG card.

The EC-PG507-12 expansion card can be used in combination with multiple types of incremental encoders through different modes of wiring. The wiring modes are similar with EC-PG505-12.

#### EC-PG507-12 terminal function description

Signal	Port	Description
PWR		Voltage: 5V/12V ± 5%; Max. current: 150 mA
PGND	Encoder power	The voltage class can be selected through SW1, depending
PGND		on the encoder voltage class.
A1+		
A1-	Encoder	Supporting push-pull interfaces of 5 V/12 V
B1+		2. Supporting open collector interfaces of 5 V/12 V
		3. Supporting differential interfaces of 5 V
B1-	interface	4. Response frequency: 400 kHz
Z1+		5. Supporting the encoder cable length of up to 50 m
Z1-		3. Supporting the encoder capie length of up to 30 m

## A.7.7 24V simplified incremental PG card (EC-PG507-24)



The terminals are arranged as follows:

PE	A1+	B1+	Z1+	PWR
PGND	A1-	B1-	Z1-	PGND

Indicator	Name	Description
1501	Ctata indicator	This indicator is on when the expansion card is establishing a
LED1	State indicator	connection with the control board; it blinks periodically after the


Indicator	Name	Description
		expansion card is properly connected to the control board (the period is 1s, on for 0.5s, and off for the other 0.5s); and it is off when the expansion card is disconnected from the control board.
LED2	Disconnection indicator	Off: A1 or B1 of the encoder is disconnected. On: The encoder pulses are normal.
LED3	Power indicator	This indicator is on after the control board feeds power to the PG card.

EC-PG507-24 can work in combination with multiple types of incremental encoders through various external wiring modes. It is easy to use for the use of 5.08mm pitch terminal.


# EC-PG507-24 terminal function description


Signal	Port	Description
PE	Grounding terminal	Connected to the ground to enhance anti-interference
PE	Grounding terminal	performance.
PWR	Encoder power	Voltage: 24V±5%; Max. output current: 150mA
PGND		(PGND is the ground for power isolation)
A1+		
A1-		Supporting push-pull interfaces of 24 V
B1+		Supporting open collector interfaces of 24 V
B1-		3. Supporting differential interfaces of 24 V
Z1+		4. Frequency response: 200 kHz
Z1-		5. Supporting upporting the encoder cable length of up to 100 m

The following figure shows the external wiring of the PG card when it is used in combination with an open collector encoder. A pull-up resistor is configured in the PG card.





The following figure shows the external wiring of the PG card when it is used in combination with a push-pull encoder.






The following figure shows the external wiring of the PG card when it is used in combination with a differential encoder.





# A.8 GPRS card (EC-IC501-2)



# CN6 pin definition

Pin	Name	Description
1	485-	485B
2	485+	485A
3	GND	Power ground
4	24V	24V power

#### State indicator definition

The GPRS IoT card has five state indicators.

Indicator	Name	Function
LED1	Handshaking indicator	It blinks at a frequency of 1s when the card
		normally connects to the control board.
LED2	Power indicator	It is on upon power on.
LED3	Run indicator	The card communicates normally.
LED4	GPRS state indicator	When GPRS connects to the network, it blinks
		fast at a specific interval (with 64ms on and
		300ms off); when GPRS does not connect to the
		network, it blinks slowly at a specific interval
		(with 64ms on and 800ms off).
LED5	State indicator	It is always on when the GPRS module is
		powered on.

For details, see the EC series GPRS expansion card manual.

# **Appendix B Technical data**

## B.1 What this chapter contains

This chapter describes the technical data of the VFD and its compliance to CE and other quality certification systems.

## **B.2 Derated application**

#### **B.2.1 Capacity**

Choose a VFD model based on the rated current and power of the motor. To ensure the rated power of the motor, the rated output current of the VFD must be greater or equal to the rated current of the motor. The rated power of the VFD must be higher or equal to that of the motor.

#### Note:


- The maximum allowable shaft power of the motor is limited to 1.5 times the rated power of the
  motor. If the limit is exceeded, the VFD automatically restricts the torque and current of the motor.
  This function effectively protect the input shaft against overload.
- The rated capacity is the capacity at the ambient temperature of 40°C.
- You need to check and ensure that the power flowing through the common DC connection in the common DC system does not exceed the rated power of the motor.

#### **B.2.2 Derating**

If the ambient temperature on the site where the VFD is installed exceeds 40°C, the altitude exceeds 1000 m, a cover with heat dissipation vents is used, or the carrier frequency is higher than the recommended, the VFD needs to be derated.

#### B.2.2.1. Derating due to temperature

When the temperature ranges from +40°C to +50°C, the rated output current is derated by 1% for each increased 1°C. For the actual derating, see the following figure.



**Note:** It is not recommended to use the VFD at a temperature higher than 50°C. If you do, you shall be held accountable for the consequences caused.

#### B.2.2.2. Derating due to altitude

When the altitude of the site where the VFD is installed is lower than 1000 m, the VFD can run at the

rated power. When the altitude exceeds 1000m, derate by 1% for every increase of 100m. When the altitude exceeds 3000m, consult the local INVT dealer or local INVT office for details.

#### B.2.2.3. Derating due to carrier frequency

The power of the VFD varies according to carrier frequencies. The VFD rated power is defined based on the carrier frequency set in factory. If the carrier frequency exceeds the factory setting, the power of the VFD is derated by 10% for each increased 1 kHz.

# B.3 Grid specifications

Grid voltage	AC 3PH 380V(-15%)-440V(+10%)	
	According to the definition of IEC 61439-1, the 1R5G/2R2P-015G/018P	
	VFD models are suitable for the use on the grid with the maximum expected	
	short-circuit current no more than 5kA at the maximum rated voltage; the	
Short-circuit	018G/022P-090G/011P VFD models are suitable for the use on the grid	
capacity	with the maximum expected short-circuit current no more than 22kA at the	
	maximum rated voltage; the 110G/132P-500G VFD models are suitable for	
	the use on the grid with maximum expected short-circuit current no more	
	than 100kA at the maximum rated voltage.	
Frequency	50/60 Hz±5%, with a maximum change rate of 20%/s	

#### **B.4 Motor connection data**

Motor type	Asynchronous induction motor or permanent magnetic synchronous motor	
Voltage	0-U1 (rated voltage of the motor), 3PH symmetrical, Umax (rated voltage	
	of the VFD) at the field-weakening point	
Short-circuit	The short-circuit protection for the motor output meets the requirements of	
protection	IEC 61800-5-1.	
Frequency	0–400 Hz	
Frequency	0.0411	
resolution	0.01 Hz	
Current	See 3.6 Product ratings.	
Power limit	1.5 times of the rated power of the motor	
Field-weakening	10–400 Hz	
point		
Carrier	4.0.4045111	
frequency	4, 8, 12, or 15 kHz	

# **B.5 Application standards**

The following table describes the standards that the VFD complies with.

EN/ISO 13849-1	Safety of machinery—Safety-related parts of control systems—Part
EIV/I3O 13049-1	1: General principles for design
IEC/EN 60204-1	Safety of machinery—Electrical equipment of machines. Part 1:

	General requirements
IEC/EN 62061	Safety of machinery—Safety-related functional safety of electrical, electronic, and programmable electronic control systems
IEC/EN 61800-3	Adjustable speed electrical power drive systems—Part 3:EMC requirements and specific test methods
IEC/EN 61800-5-1	Adjustable speed electrical power drive systems—Part 5-1: Safety requirements—Electrical, thermal and energy
IEC/EN 61800-5-2	Adjustable speed electrical power drive systems—Part 5-2: Safety requirements—Function
GB/T 30844.1	General-purpose variable-frequency adjustable-speed equipment of 1 kV and lower—Part 1: Technical conditions
GB/T 30844.2	General-purpose variable-frequency adjustable-speed equipment of 1 kV and lower—Part 2: Test methods
GB/T 30844.3	General-purpose variable-frequency adjustable-speed equipment of 1 kV and lower—Part 3: Safety regulations

#### B.5.1 CE marking

The CE marking on the name plate of the VFD indicates that the VFD is CE-compliant, meeting the regulations of the European low-voltage directive (2014/35/EU) and EMC directive (2014/30/EU).

#### **B.5.2 EMC compliance declaration**

European union (EU) stipulates that the electric and electrical devices sold in Europe cannot generate electromagnetic disturbance that exceeds the limits stipulated in related standards, and can work properly in environments with certain electromagnetic interference. The EMC product standard (EN 61800-3) describes the EMC standards and specific test methods for adjustable speed electrical power drive systems. INVT products have strictly followed these EMC regulations.

#### **B.6 EMC regulations**

The EMC product standard (EN 61800-3) describes the EMC requirements on VFDs.

Application environment categories

Category I: Civilian environments, including application scenarios where VFDs are directly connected to the civil power supply low-voltage grids without intermediate transformers

Category II: All environments except those in Category I.

VFD categories

C1: Rated voltage lower than 1000 V, applied to environments of Category I.

C2: Rated voltage lower than 1000 V, non-plug, socket, or mobile devices; power drive systems that must be installed and operated by specialized personnel when applied to environments of Category I

Note: The EMC standard IEC/EN 61800-3 no longer restricts the power distribution of VFDs, but it

specifies their use, installation, and commissioning. Specialized personnel or organizations must have the necessary skills (including the EMC-related knowledge) for installing and/or performing commissioning on the electrical drive systems.

C3: Rated voltage lower than 1000 V, applied to environments of Category II. They cannot be applied to environments of Category I.

C4: Rated voltage higher than 1000 V, or rated current higher or equal to 400 A, applied to complex systems in environments of Category II.

### B.6.1 VFD category of C2

The induction disturbance limit meets the following stipulations:

- Select an optional EMC filter according to "Optional peripheral accessories" and install it following the description in the EMC filter manual.
- 2. Select the motor and control cables according to the description in the manual.
- 3. Install the VFD according to the description in the manual.



Currently in environments in China, the VFD may generate radio interference, you need to take measures to reduce the interference.

## B.6.2 VFD category of C3

The anti-interference performance of the VFD meets the requirements of environments Category II in the IEC/EN 61800-3 standard.

The induction disturbance limit meets the following stipulations:

- Select an optional EMC filter according to "Optional peripheral accessories" and install it following the description in the EMC filter manual.
- 2. Select the motor and control cables according to the description in the manual.
- 3. Install the VFD according to the description in the manual.



VFDs of C3 category cannot be applied to civilian low-voltage common grids. When applied to such grids, the VFDs may generate radio frequency electromagnetic interference.

# **Appendix C Dimension drawings**

## C.1 What this chapter contains

This chapter describes the dimension drawings of the VFD. The dimension unit used in the drawings is mm.

## C.2 Keypad structure

## C.2.1 Structure diagram




Figure C.1 Keypad structure diagram

## C.2.2 Keypad installation bracket

**Note:** When installing an external keypad, you can directly use threaded screws or a keypad bracket. For VFD models of 1R5G/2R2P–075G/090P, you need to use optional keypad installation brackets. For those of 090G/110P–500G, you can use optional brackets or use the standard keypad brackets externally.




Figure C.2 1R5G/2R2P-500G keypad installation bracket (optional)

# C.3 VFD structure




Figure C.3 VFD structure diagram

## C.4 VFD structure

## C.4.1 Wall-mounting dimensions




Figure C.4 1R5G/2R2P-037G/045P wall-mounting diagram




Figure C.5 045G/055P-075/090P wall-mounting diagram




Figure C.6 090G/110P-110G/132P wall-mounting diagram




Figure C.7 132G/160P-200G/220P wall-mounting diagram






Figure C.8 220G/250P-315G/350P wall-mounting diagram
Table C.1 Wall-mounting dimensions (unit: mm)

VFD model	W1	W2	W3	H1	H2	D1	Installation hole	Screw
							diameter	
1R5G/2R2P-2R2G/003P	126	115	-	186	175	185	Ø 5	M4
004G/5R5P-5R5G/7R5P	126	115	-	186	175	201	Ø 5	M4
7R5G/011P	146	131	-	256	243.5	192	Ø6	M5
011G/015P-015G/018P	170	151	-	320	303.5	220	Ø6	M5
018G/022P-022G/030P	200	185	-	340.6	328.6	208	Ø6	M5
030G/037P-037G/045P	250	230	-	400	380	223	Ø6	M5
045G/055P-075/090P	282	160	226	560	542	258	Ø 9	M8
090/110P-110G/132P	338	200	-	554	535	330	Ø 10	M8
132G/160P-200G/220P	500	180	-	870	850	360	Ø 11	M10
220G/250P-315G/355P	680	230	-	960	926	380	Ø 13	M12

## C.4.2 Flange installation dimensions








Figure C.9 1R5G/2R2P-075/090P flange installation diagram




Figure C.11 132G/160P-200G/220P flange installation diagram
Table C.2 380V flange installation dimensions (unit: mm)

VFD model	W1	W2	W3	W4	Н1	H2	НЗ	H4	D1	D2	Hole diameter	Screw
1R5G/2R2P-2R2G/003P	150.2	115	130	7.5	234	220	190	13.5	185	65.5	Ø 5	M4
004G/5R5P-5R5G/7R5P	150.2	115	130	7.5	234	220	190	13.5	201	83	Ø 5	M4
7R5G/011P	170.2	131	150	9.5	292	276	260	6	192	84.5	Ø6	M5
011G/015P-015G/018P	191.2	151	174	11.5	370	351	324	12	220	113	Ø 6	M5
018G/022P-022G/030P	266	250	224	13	371	250	350.6	20.3	208	104	Ø6	M5
030G/037P-037G/045P	316	300	274	13	430	300	410	55	223	118.3	Ø 6	M5
045G/055P-075/090P	352	332	306	12	580	400	570	80	258	133.8	Ø9	M8
090/110P-110G/132P	418.5	389.5	361	14.2	600	370	559	108.5	330	149.5	Ø 10	M8
132G/160P-200G/220P	500	180	480	60	870	850	796	37	360	178.5	Ø 11	M10

## C.4.3 Floor installation dimensions




Figure C.12 220G/250P-315G/355P floor installation diagram




Figure C.13 355G/400P-500G floor installation diagram

Table C.3 380V floor installation dimensions (unit: mm)

VFD model	W1	W2	W3	W4	H1	H2	D1	D2	Hole diameter	Screw
220G/250P-315G/355P	750	230	714	680	1410	1390	380	150	Ø 13/12	M12/M10
355G/400P-500G	620	230	572	-	1700	1678	560	240	Ø 22/12	M20/M10


# Appendix D Optional peripheral accessories

## D.1 What this chapter contains

This chapter describes how to select optional accessories of the VFD.

## D.2 Wiring of peripheral accessories

The following figure shows the external wiring of the VFD.



#### Note:

- The VFD models of 037G/045P and lower are equipped with built-in braking units, and those of 045G/055P-055G/075P can be configured with optional built-in braking units.
- The VFD models of 018G-110G/132P are equipped with built-in DC reactors.
- P1 terminals are equipped only for the VFD models of 132G/160P and higher, which enable the VFD models to be directly connected to external DC reactors.
- The braking units are INVT DBU series standard braking units. For details, see the DBU
  operation manual.

Image	Name	Description
	Cable	Accessory for signal transmission
	Breaker	Device for electric shock prevention and protection against short-to-ground that may cause current leakage and fire. Select residual-current circuit breakers (RCCBs) that are applicable to VFDs and can restrict high-order harmonics, and of which the rated sensitive current for one VFD is larger than 30 mA.
	Input reactor	Accessories used to improve the current adjustment coefficient on the input side of the VFD, and thus restrict
	DC reactor	high-order harmonic currents.  The VFD models of 132G/160P and higher can be directly connected to external DC reactors.
500	Input filter	Accessory that restricts the electromagnetic interference generated by the VFD and transmitted to the public grid through the power cable. Try to install the input filter near the input terminal side of the VFD.
or	Braking unit or braking resistor	Accessories used to consume the regenerative energy of the motor to reduce the DEC time.  The VFD models of 037G/045P and lower need only to be configured with braking resistors, those of 132G/160P and higher also need to be configured with braking units, and those of 045G/055P-055G/075P can be configured with optional built-in braking units.
000	Output filter	Accessory used to restrict interference generated in the wiring area on the output side of the VFD. Try to install the output filter near the output terminal side of the VFD.
	Output reactor	Accessory used to lengthen the valid transmission distance of the VFD, which effectively restrict the transient high voltage generated during the switch-on and switch-off of the IGBT module of the VFD.

# **D.3 Power supply**

See Installation guidelines.



♦ Ensure that the voltage class of the VFD is consistent with that of the grid.

#### D.4 Cables


#### D.4.1 Power cables

The sizes of the input power cables and motor cables must meet the local regulation.

- The input power cables and motor cables must be able to carry the corresponding load currents.
- The maximum temperature margin of the motor cables in continuous operation cannot be lower than 70°C.
- The conductivity of the PE grounding conductor is the same as that of the phase conductor, that
  is, the cross-sectional areas are the same.
- For details about the EMC requirements, see Appendix B Technical data

To meet the EMC requirements stipulated in the CE standards, you must use symmetrical shielded cables as motor cables (as shown in the following figure).


Four-core cables can be used as input cables, but symmetrical shielded cables are recommended. Compared with four-core cables, symmetrical shielded cables can reduce electromagnetic radiation as well as the current and loss of the motor cables.



**Note:** If the conductivity of the shield layer of the motor cables cannot meet the requirements, separate PE conductors must be used.

To protect the conductors, the cross-sectional area of the shielded cables must be the same as that of the phase conductors if the cable and conductor are made of materials of the same type. This reduces grounding resistance, and thus improves impedance continuity.


To effectively restrict the emission and conduction of radio frequency (RF) interference, the conductivity of the shielded cable must at least be 1/10 of the conductivity of the phase conductor. This requirement can be well met by a copper or aluminum shield layer. The following figure shows the minimum requirement on motor cables of a VFD. The cable must consist of a layer of spiral-shaped copper strips. The denser the shield layer is, the more effectively the electromagnetic interference is restricted.



Cross-section of the cable

### **D.4.2 Control cables**

All analog control cables and cables used for frequency input must be shielded cables. Analog signal cables need to be double-shielded twisted-pair cables (as shown in figure a). Use one separate shielded twisted pair for each signal. Do not use the same ground wire for different analog signals.



Power cable arrangement

For low-voltage digital signals, double-shielded cables are recommended, but shielded or unshielded twisted pairs (as shown in figure b) also can be used. For frequency signals, however, only shielded cables can be used.

Relay cables need to be those with metal braided shield layers.

Keypads need to be connected by using network cables. In complicated electromagnetic environments, shielded network cables are recommended.

**Note:** Analog signals and digital signals cannot use the same cables, and their cables must be arranged separately.

Do not perform any voltage endurance or insulation resistance tests, such as high-voltage insulation tests or using a megameter to measure the insulation resistance, on the VFD or its components. Insulation and voltage endurance tests have been performed between the main circuit and chassis of each VFD before delivery. In addition, voltage limiting circuits that can automatically cut off the test voltage are configured inside the VFDs.

**Note:** Check the insulation conditions of the input power cable of a VFD according to the local regulations before connecting it.

## D.4.3 Recommended cable sizes

Table D.1 AC 3PH 380V(-15%)-440V(+10%)

Recommended cable size (mm²) Screw						
VFD model	R, S, T U, V, W	PE	P1 (+)	PB, (+)	Terminal screw	Tightening torque (Nm)
GD350A-1R5G/2R2P-4	1.0/1.0	1.0/1.0	1.0/1.0	1.0/1.0	M4	1.2–1.5
GD350A-2R2G/003P-4	1.0/1.5	1.0/1.5	1.0/1.5	1.0/1.5	M4	1.2–1.5
GD350A-004G/5R5P-4	1.5/2.5	1.5/2.5	1.5/2.5	1.5/2.5	M4	1.2–1.5
GD350A-5R5G/7R5P-4	2.5/4	2.5/4	2.5/4	2.5/4	M5	2–2.5
GD350A-7R5G/011P-4	4/6	4/6	4/6	4/6	M5	2–2.5
GD350A-011G/015P-4	6/10	6/10	6/10	6/10	M5	2–2.5
GD350A-015G/018P-4	10/10	10/10	10/10	10/10	M5	2–2.5
GD350A-018G/022P-4	10/10	10/10	10/10	10/10	M5	2-2.5
GD350A-022G/030P-4	10/16	10/16	10/16	10/16	M6	4–6
GD350A-030G/037P-4	16/25	16/16	116/25	16/25	M6	4–6
GD350A-037G/045P-4	25/25	16/16	25/25	25/25	M6	4–6
GD350A-045G/055P-4	25/35	16	25/35	25/35	M8	9–11
GD350A-055G/075P-4	35/50	16/25	35/50	35/50	M8	9–11
GD350A-075G-/090P4	50/70	25/35	50/70	50/70	M8	9–11
GD350A-090G/110P-4	70/95	35/50	70/95	70/95	M10	18–23
GD350A-110G/132P-4	95/95	50/50	95/95	95/95	M10	18–23
GD350A-132G/160P-4	95/150	50/70	95/150	95/150	M12	31–40
GD350A-160G/185P-4	150/185	70/95	150/185	150/185	M12	31–40
GD350A-185G/200P-4	185/185	95/95	185/185	185/185	M12	31–40
GD350A-200G/220P-4	185/2×9 5	95/95	185/2×95	185/2×95	M12	31–40
GD350A-220G/250P-4	2×95/2× 95	95/95	2×95/2×9 5	2×95/2×9 5	M12	31–40
GD350A-250G/280P-4	2×95/2× 150	95/150	2×95/2×1 50	2×95/2×1 50	M12	31–40
GD350A-280G/315P-4	2×150/2 ×150	150/15 0	2×150/2× 150	2×150/2× 150	M12	31–40
GD350A-315G/355P-4	2×150/2 ×185	150/18 5	2×150/2× 185	2×150/2× 185	M12	31–40
GD350A-355G/400P-4	2×185/3 ×150	185/2× 120	2×1853× 150	2×1853× 150	M12	31–40
GD350A-400G/450P-4	3×150	2×120/ 2×150	3×150	3×150	M12	31–40

	Recon	nmended	Sc	rew		
VFD model	R, S, T U, V, W	PE	P1 (+)	PB, (+) (-)	Terminal screw	Tightening torque (Nm)
GD350A-450G/500P-4	3×185	2×150/ 2×150	3×185	3×185	M12	31–40
GD350A-500G-4	3×185	2×150	3×185	3×185	M12	31–40

#### Note:

- Cables of the sizes recommended for the main circuit can be used in scenarios where the ambient temperature is lower than 40°C, the wiring distance is shorter than 100 m, and the current is the rated current.
- The terminals P1, (+), PB, and (-) are used to connect to DC reactors and brake accessories.


## **D.4.4 Cable arrangement**

Motor cables must be arranged away from other cables. The motor cables of several VFDs can be arranged in parallel. It is recommended that you arrange the motor cables, input power cables, and control cables separately in different trays. The output dU/dt of the VFDs may increase electromagnetic interference on other cables. Do not arrange other cables and the motor cables in parallel.

If a control cable and power cable must cross each other, ensure that the angle between them is 90 degrees.

The cable trays must be connected properly and well grounded. Aluminum trays can implement local equipotential.

The following figure shows the cable arrangement distance requirements.



Cable arrangement distances

## **D.4.5 Insulation inspection**

Check the motor and the insulation conditions of the motor cable before running the motor.

1. Ensure that the motor cable is connected to the motor, and then remove the motor cable from the

- U, V, and W output terminals of the VFD.
- Use a megameter of 500 V DC to measure the insulation resistance between each phase conductor and the protection grounding conductor. For details about the insulation resistance of the motor, see the description provided by the manufacturer.

**Note:** The insulation resistance is reduced if it is damp inside the motor. If it may be damp, you need to dry the motor and then measure the insulation resistance again.

## D.5 Breaker and electromagnetic contactor

You need to add a fuse to prevent overload.

You need to configure a manually manipulated molded case circuit breaker (MCCB) between the AC power supply and VFD. The breaker must be locked in the open state to facilitate installation and inspection. The capacity of the breaker needs to be 1.5 to 2 times the rated current of the VFD.



According to the working principle and structure of breakers, if the manufacturer's regulation is not followed, hot ionized gases may escape from the breaker enclosure when a short-circuit occurs. To ensure safe use, exercise extra caution when installing and placing the breaker. Follow the manufacturer's instructions.

To ensure safety, you can configure an electromagnetic contactor on the input side to control the switch-on and switch-off of the main circuit power, so that the input power supply of the VFD can be effectively cut off when a system fault occurs.

VFD model	Breaker rated current (A)	Quick fuse (A)	Contactor rated current (A)
GD350A-1R5G/2R2P-4	6/10	10/10	9/9
GD350A-2R2G/003P-4	10/20	10/20	9/18
GD350A-004G/5R5P-4	20/25	20/35	18/25
GD350A-5R5G/7R5P-4	25/32	35/40	25/32
GD350A-7R5G/011P-4	32/50	40/50	32/38
GD350A-011G/015P-4	50/63	50/60	38/50
GD350A-015G/018P-4	63/63	60/70	50/65
GD350A-018G/022P-4	63/80	70/90	65/80
GD350A-022G/030P-4	80/100	90/125	80/80
GD350A-030G/037P-4	100/125	125/125	80/98
GD350A-037G/045P-4	125/140	125/150	98/115
GD350A-045G/055P-4	140/180	150/200	115/150
GD350A-055G/075P-4	180/225	200/250	150/185
GD350A-075G-/090P4	225/250	250/300	185/225
GD350A-090G/110P-4	250/315	300/350	225/265

Table D.2 AC 3PH 380V(-15%)-440V(+10%)

VFD model	Breaker rated current (A)	Quick fuse (A)	Contactor rated current (A)
GD350A-110G/132P-4	315/400	350/400	265/330
GD350A-132G/160P-4	400/500	400/500	330/400
GD350A-160G/185P-4	500/500	500/600	400/400
GD350A-185G/200P-4	500/630	600/600	400/500
GD350A-200G/220P-4	630/630	600/700	500/500
GD350A-220G/250P-4	630/700	700/800	500/630
GD350A-250G/280P-4	700/800	800/1000	630/630
GD350A-280G/315P-4	800/1000	1000/1000	630/800
GD350A-315G/355P-4	1000/1000	1000/1000	800/800
GD350A-355G/400P-4	1000/1000	1000/1200	800/1000
GD350A-400G/450P-4	1000/1250	1200/1200	1000/1000
GD350A-450G/500P-4	1250/1250	1200/1400	1000/1000
GD350A-500G-4	1250	1400	1000

**Note:** The accessory specifications described in the preceding table are ideal values. You can select accessories based on the actual market conditions, but try not to use those with lower values.

#### D.6 Reactors

When the voltage of the grid is high, the transient large current that flows into the input power circuit may damage rectifier components. You need to configure an AC reactor on the input side, which can also improve the current adjustment coefficient on the input side.

When the distance between the VFD and motor is longer than 50 m, the parasitic capacitance between the long cable and ground may cause large leakage current, and overcurrent protection of the VFD may be frequently triggered. To prevent this from happening and avoid damage to the motor insulator, compensation must be made by adding an output reactor. When a VFD is used to drive multiple motors, take the total length of the motor cables (that is, sum of the lengths of the motor cables) into account. When the total length is longer than 50 m, an output reactor must be added on the output side of the VFD. If the distance between the VFD and motor is 50 m to 100 m, select the reactor according to the following table. If the distance is longer than 100 m, contact INVT's technical support technicians.

DC reactors can be directly connected to the VFD models of 132G/160P or higher and the 660 V series. DC reactors can improve the power factor, avoid damage to bridge rectifiers caused due to large input current of the VFD when large-capacity transformers are connected, and also avoid damage to the rectification circuit caused due to harmonics generated by grid voltage transients or phase-control loads.




Table D.3 Reactors for AC 3PH 380V(-15%)-440V(+10%)

.,	Input	reactor	Output	reactor
VFD model	G type	P type	G type	P type
GD350A-1R5G/2R2P-4	ACL2-1R5-4	ACL2-2R2-4	OCL2-1R5-4	OCL2-1R5-4
GD350A-2R2G/003P-4	ACL2-2R2-4	ACL2-004-4	OCL2-2R2-4	OCL2-2R2-4
GD350A-004G/5R5P-4	ACL2-004-4	ACL2-5R5-4	OCL2-004-4	OCL2-5R5-4
GD350A-5R5G/7R5P-4	ACL2-5R5-4	ACL2-7R5-4	OCL2-5R5-4	OCL2-7R5-4
GD350A-7R5G/011P-4	ACL2-7R5-4	ACL2-011-4	OCL2-7R5-4	OCL2-011-4
GD350A-011G/015P-4	ACL2-011-4	ACL2-015-4	OCL2-011-4	OCL2-015-4
GD350A-015G/018P-4	ACL2-015-4	ACL2-018-4	OCL2-015-4	OCL2-015-4
GD350A-018G/022P-4	ACL2-018-4	ACL2-018-4	OCL2-018-4	OCL2-018-4
GD350A-022G/030P-4	ACL2-022-4	ACL2-037-4	OCL2-022-4	OCL2-022-4
GD350A-030G/037P-4	ACL2-037-4	ACL2-037-4	OCL2-037-4	OCL2-037-4
GD350A-037G/045P-4	ACL2-037-4	ACL2-045-4	OCL2-037-4	OCL2-037-4
GD350A-045G/055P-4	ACL2-045-4	ACL2-055-4	OCL2-045-4	OCL2-045-4
GD350A-055G/075P-4	ACL2-055-4	ACL2-055-4	OCL2-055-4	OCL2-055-4
GD350A-075G/090P-4	ACL2-075-4	ACL2-075-4	OCL2-075-4	OCL2-075-4
GD350A-090G/110P-4	ACL2-110-4	ACL2-110-4	OCL2-110-4	OCL2-110-4
GD350A-110G/132P-4	ACL2-110-4	ACL2-160-4	OCL2-110-4	OCL2-200-4
GD350A-132G/160P-4	ACL2-160-4	ACL2-160-4	OCL2-200-4	OCL2-200-4
GD350A-160G/185P-4	ACL2-160-4	ACL2-200-4	OCL2-200-4	OCL2-200-4
GD350A-185G/200P-4	ACL2-200-4	ACL2-200-4	OCL2-200-4	OCL2-200-4
GD350A-200G/220P-4	ACL2-200-4	ACL2-280-4	OCL2-200-4	OCL2-280-4
GD350A-220G/250P-4	ACL2-280-4	ACL2-280-4	OCL2-280-4	OCL2-280-4
GD350A-250G/280P-4	ACL2-280-4	ACL2-280-4	OCL2-280-4	OCL2-280-4
GD350A-280G/315P-4	ACL2-280-4	ACL2-350-4	OCL2-280-4	OCL2-350-4

VED del	Input	reactor	Output	reactor
VFD model	G type	P type	G type	P type
GD350A-315G/355P-4	ACL2-350-4	ACL2-350-4	OCL2-350-4	OCL2-350-4
GD350A-355G/400P-4	Standard	Standard	OCL2-350-4	OCL2-400-4
GD350A-400G/450P-4	Standard	Standard	OCL2-400-4	OCL2-500-4
GD350A-450G/500P-4	Standard	Standard	OCL2-500-4	OCL2-500-4
GD350A-500G-4	Standard	/	OCL2-500-4	OCL2-500-4

#### Note:

- The rated input voltage drop of input reactors is 2%.
- The current adjustment coefficient on the input side of the VFD is higher than 90% after a DC reactor is configured.
- The rated output voltage drop of output reactors is 1%.
- The preceding table describes external accessories. You need to specify the ones you choose when purchasing accessories.

## **D.7 Filters**


J10 is not connected in factory for VFD models of 110G/132P and lower. Connect the J10 packaged with the manual if the requirements of IEC/EN 61800-3 C3 need to be met;

J10 is connected in factory for VFDs of 132G/160P and higher, all of which meet the requirements of level C3

### Note:

Disconnect J10 in the following situations:

- The EMC filter is applicable to the neutral-grounded grid system. If it is used for the IT grid system (that is, non-neutral grounded grid system), disconnect J10.
- If leakage protection occurs during configuration of a residual-current circuit breaker, disconnect J10.



Note: Do not connect C3 filters in IT power systems.

Interference filters on the input side can reduce the interference of VFDs (when used) on the surrounding devices.

Noise filters on the output side can decrease the radio noise caused by the cables between VFDs and motors and the leakage current of conducting wires.

INVT provides some of the filters for you to choose.

## D.7.1 Filter model description



Field identifier	Field description
А	FLT: Name of the VFD filter series
В	Filter type P: Power input filter L: Output filter
С	Voltage class 04: AC 3PH 380V(-15%)–440V(+10%) 06: AC 3PH 520V(-15%)–690V(+10%)
D	3-digit code indicating the rated current. For example, 015 indicates 15 A.
Е	Filter performance L: General H: High-performance

Field identifier	Field description
	Filter application environment
_	A: Environment Category I (IEC61800-3) category C1 (EN 61800-3)
F	B: Environment Category I (IEC61800-3) category C2 (EN 61800-3)
	C: Environment Category II (IEC61800-3) category C3 (EN 61800-3)

## D.7.2 Filter model selection

Table D.4 AC 3PH 380V(-15%)-440V(+10%)

VFD model	Input filter	Output filter			
GD350A-1R5G/2R2P-4	-	·			
GD350A-2R2G/003P-4	FLT-P04006L-B	FLT-L04006L-B			
GD350A-004G/5R5P-4	51.7.80.404.8	ELE   0.404.01 B			
GD350A-5R5G/7R5P-4	FLT-P04016L-B	FLT-L04016L-B			
GD350A-7R5G/011P-4	ELT 0040221 B	FLT-L04032L-B			
GD350A-011G/015P-4	FLT-P04032L-B	FLI-LU4U3ZL-D			
GD350A-015G/018P-4	FLT-P04045L-B	FLT-L04045L-B			
GD350A-018G/022P-4	FL1-F04045L-B				
GD350A-022G/030P-4	FLT-P04065L-B	FLT-L04065L-B			
GD350A-030G/037P-4	FLI-FU4U03L-D	FLI-LU4000L-D			
GD350A-037G/045P-4	FLT-P04100L-B	FLT-L04100L-B			
GD350A-045G/055P-4	FL1-F04100L-B	FL1-LU4100L-B			
GD350A-055G/075P-4	FLT-P04150L-B	FLT-L04150L-B			
GD350A-075G-/090P4	1 E1-F 04130E-B				
GD350A-090G/110P-4		FLT-L04240L-B			
GD350A-110G/132P-4	FLT-P04240L-B				
GD350A-132G/160P-4					
GD350A-160G/185P-4					
GD350A-185G/200P-4	FLT-P04400L-B	FLT-L04400L-B			
GD350A-200G/220P-4					
GD350A-220G/250P-4					
GD350A-250G/280P-4	FLT-P04600L-B	FLT-L04600L-B			
GD350A-280G/315P-4					
GD350A-315G/355P-4					
GD350A-355G/400P-4	FLT-P04800L-B	FLT-L04800L-B			
GD350A-400G/450P-4					
GD350A-450G/500P-4	FLT-P041000L-B	FLT-L041000L-B			
GD350A-500G-4	1 11-1 0410001-0	1 11-10410001-15			


#### Note:


- The input EMI meets the C2 requirements after an input filter is configured.
- The preceding table describes external accessories. You need to specify the ones you choose when purchasing accessories.

## D.8 Braking system

### D.8.1 Brake component selection

When the VFD driving a high-inertia load decelerates or needs to decelerate abruptly, the motor runs in the power generation state and transmits the load-carrying energy to the DC circuit of the VFD, causing the bus voltage of the VFD to rise. If the bus voltage exceeds a specific value, the VFD reports an overvoltage fault. To prevent this from happening, you need to configure brake components.







- Only qualified electricians are allowed to perform the wiring. Otherwise, damage to the VFD or brake components may be caused.
- Read the braking resistor or unit instructions carefully before connecting them to the VFD.
- Connect braking resistors only to the terminals PB and (+), and braking units only to the terminals (+) and (-). Do not connect them to other terminals. Otherwise, damage to the brake circuit and VFD and fire may be caused.



Connect the brake components to the VFD according to the wiring diagram. If the wiring is not properly performed, damage to the VFD or other devices may be caused.

The VFD models of 037G/045P and lower are equipped with built-in braking units, and those of 045G/055P and higher need to be configured with external braking units. The VFD models of 045G/055P-055G/075P can be configured with optional built-in braking units, and after a built-in braking unit is configured, the VFD model code is added with a suffix "-B", for example, GD350A-045G/055P-4-B. Select braking resistors according to the specific requirements (such as the brake torque and brake usage requirements) on site.

	Doolds a	Resistance applicable	Dissipated power of braking resistor (kW)			Min. allowable
VFD model	Braking unit model	for 100% brake torque (Ω)	10% brake usage	50% brake usage	80% brake usage	brake resistance (Ω)
GD350A-1R5G/2R2P-4		326	0.23	1.1	1.8	170
GD350A-2R2G/003P-4		222	0.33	1.7	2.6	130
GD350A-004G/5R5P-4		122	0.6	3	4.8	80
GD350A-5R5G/7R5P-4		89	0.75	4.1	6.6	60
GD350A-7R5G/011P-4	Desille in	65	1.1	5.6	9	47
GD350A-011G/015P-4	Built-in	44	1.7	8.3	13.2	31
GD350A-015G/018P-4	braking unit	32	2	11	18	23
GD350A-018G/022P-4		27	3	14	22	19
GD350A-022G/030P-4		22	3	17	26	17
GD350A-030G/037P-4		17	5	23	36	17
GD350A-037G/045P-4		13	6	28	44	11.7
GD350A-045G/055P-4	DDI IA COLL A	10	7	34	54	
GD350A-055G/075P-4	DBU100H-1	8	8	41	66	6.4
GD350A-075G-/090P4	10-4	6.5	11	56	90	
GD350A-090G/110P-4	DBU100H-1	5.4	14	68	108	4.4
GD350A-110G/132P-4	60-4	4.5	17	83	132	4.4
GD350A-132G/160P-4	DBU100H-2 20-4	3.7	20	99	158	3.2
GD350A-160G/185P-4	DDIMOOLLO	3.1	24	120	192	
GD350A-185G/200P-4	DBU100H-3 20-4	2.8	28	139	222	2.2
GD350A-200G/220P-4	20-4	2.5	30	150	240	
GD350A-220G/250P-4	DBU100H-4	2.2	33	165	264	1.8
GD350A-250G/280P-4	00-4	2.0	38	188	300	1.0
GD350A-280G/315P-4	T	3.6*2	21*2	105*2	168*2	
GD350A-315G/355P-4	Two sets	3.2*2	24*2	118*2	189*2	0.0*0
GD350A-355G/400P-4	DBU100H-3 20-4	2.8*2	27*2	132*2	210*2	2.2*2
GD350A-400G/450P-4	20-4	2.4*2	30*2	150*2	240*2	
GD350A-450G/500P-4	Two sets	2.2*2	34*2	168*2	270*2	
GD350A-500G-4	DBU100H-4 00-4	2.0*2	38*2	186*2	300*2	1.8*2

## Note:

- Select braking resistors according to the resistance and power data provided by our company.
- The braking resistor may increase the brake torque of the VFD. The preceding table describes

the resistance and power for 100% brake torque, 10% brake usage, 50% brake usage, and 80% brake usage. You can select the braking system based on the actual operation conditions.

 When using an external braking unit, set the brake voltage class of the braking unit properly by referring to the manual of the dynamic braking unit. If the voltage class is set incorrectly, the VFD may not run properly.



Do not use braking resistors whose resistance is lower than the specified minimum resistance. The VFD does not provide protection against overcurrent caused by resistors with low resistance.



In scenarios where brake is frequently implemented, that is, the brake usage is greater than 10%, you need to select a braking resistor with higher power as required by the operation conditions according to the preceding table.

## D.8.2 Braking resistor cable selection

Braking resistor cables need to be shielded cables.

### D.8.3 Braking resistor installation

All resistors need to be installed in places with good cooling conditions.




The materials near the braking resistor or braking unit must be non-flammable. The surface temperature of the resistor is high. Air flowing from the resistor is of hundreds of degrees Celsius. Prevent any materials from coming into contact with the resistor.

### Installation of braking resistors



- ♦ The VFD models of 037G/045P and lower need only external braking resistors.
- ♦ PB and (+) are the terminals for connecting braking resistors.




Installation of braking units:



- ♦ (+) and (-) are the terminals for connecting braking units.
- The connection cables between the (+) and (-) terminals of the VFD and those of a braking unit must be shorter than 5 m, and the connection cables between the BR1 and BR2 terminals of a braking unit and the terminals of a braking resistor must be shorter than 10 m.


The following figure shows the connection of one VFD to a dynamic braking unit.



# Appendix E STO function description

Reference standards: IEC 61508-1, IEC 61508-2, IEC 61508-3, IEC 61508-4, IEC 62061, ISO 13849-1, IEC 61800-5-2

You can enable the safe torque off (STO) function to prevent unexpected startups when the main power supply of the drive is not switched off. The STO function switches off the drive output by turning off the drive signals to prevent unexpected startups of the motor (see the following figure). After the STO function is enabled, you can perform some-time operations (such as non-electrical cleaning in the lathe industry) and maintain the non-electrical components of the device without switching off the drive.



## E.1 STO function logic

The following table describes the input states and corresponding faults of the STO function.

STO input state	Corresponding fault					
	The STO function is triggered, and the drive stops					
H1 and H2 opened	running.					
simultaneously	Fault code: 40: Safe torque off (STO)					
H1 and H2 algored simultaneously	The STOP function is not triggered, and the drive runs					
H1 and H2 closed simultaneously	properly.					
	The STL1, STL2, or STL3 fault occurs.					
0	Fault code:					
One of H1 and H2 opened, and the other closed	41: Channel H1 exception (STL1)					
the other closed	42: Channel H2 exception (STL2)					
	43: Channel H1 and H2 exceptions (STL3)					

## E.2 STO channel delay description

The following table describes the trigger and indication delay of the STO channels.

STO mode	STO trigger and indication delay <sup>1, 2</sup>		
CTO favilty CTI 4	Trigger delay < 10 ms		
STO fault: STL1	Indication delay < 280 ms		
CTO facility CTI 2	Trigger delay < 10 ms		
STO fault: STL2	Indication delay < 280 ms		
OTO family OTI 0	Trigger delay < 10 ms		
STO fault: STL3	Indication delay < 280 ms		
0.70 family 0.70	Trigger delay < 10 ms		
STO fault: STO	Indication delay < 100 ms		

- STO function trigger delay: Time interval between trigger the STO function and switching off the drive output
- STO instruction delay: Time interval between trigger the STO function and STO output state indication

## E.3 STO function installation checklist

Before installing the STO, check the items described in the following table to ensure that the STO function can be properly used.

ltem
Ensure that the drive can be run or stopped randomly during commissioning.
Stop the drive (if it is running), disconnect the input power supply, and isolate the drive
from the power cable through the switch.
Check the STO circuit connection according to the circuit diagram.
Check whether the shielding layer of the STO input cable is connected to the +24 V
reference ground COM.
Connect the power supply.
Test the STO function as follows after the motor stops running:
If the drive is running, send a stop command to it and wait until the shaft of the
motor stops rotating.
Activate the STO circuit and send a start command to the drive. Ensure that the
motor does not start.
Deactivate the STO circuit.
Restart the drive, and check whether the motor is running properly.
Test the STO function as follows when the motor is running:
Start the drive. Ensure that the motor is running properly.
Activate the STO circuit.
The drive reports an STO fault (for details, see 5.5.19 Fault handling). Ensure that
the motor coasts to stop rotating.
Deactivate the STO circuit.
Restart the drive, and check whether the motor is running properly.

# Appendix F Energy efficiency data

Table F-1 Power loss and IE class

	Relative loss (%)							Stand		
Model	(0;25)	(0;50)	(0;100)		,	(50;100)	(90;50)	(90;100)	by loss (W)	IE class
GD350A-1R5G/2R2P-4	1.54	1.50	1.67	1.12	1.04	1.45	0.91	1.45	3	IE2
GD350A-2R2G/003P-4	2.21	2.58	3.22	2.37	2.73	3.46	2.76	3.34	5	IE2
GD350A-004G/5R5P-4	1.13	1.40	2.05	1.14	1.43	2.14	1.41	2.28	6	IE2
GD350A-5R5G/7R5P-4	1.09	1.47	2.43	1.12	1.53	2.56	1.52	2.64	11	IE2
GD350A-7R5G/011P-4	1.06	1.37	2.06	1.11	1.45	2.45	1.46	2.69	7	IE2
GD350A-011G/015P-4	0.61	0.84	1.55	0.61	1.04	1.97	0.99	2.16	9	IE2
GD350A-015G/018P-4	0.42	0.52	1.27	0.55	0.73	1.46	0.78	1.66	9	IE2
GD350A-018G/022P-4	0.54	0.74	1.22	0.77	1.03	1.70	0.96	1.65	11	IE2
GD350A-022G/030P-4	0.47	0.67	1.21	0.67	0.90	1.54	0.87	1.38	11	IE2
GD350A-030G/037P-4	0.53	0.71	1.24	0.72	0.90	1.45	0.85	1.50	13	IE2
GD350A-037G/045P-4	0.47	0.69	1.39	0.63	0.88	1.60	0.99	1.72	14	IE2
GD350A-045G/055P-4	0.49	0.69	1.39	0.78	1.00	1.64	0.97	1.66	21	IE2
GD350A-055G/075P-4	0.51	0.69	1.26	0.71	0.89	1.47	0.88	1.40	22	IE2
GD350A-075G/090P-4	0.44	0.61	1.12	0.51	0.69	1.29	0.76	1.42	22	IE2
GD350A-090G/110P-4	0.42	0.59	1.15	0.47	0.65	1.29	0.90	1.48	25	IE2
GD350A-110G/132P-4	0.43	0.63	1.30	0.48	0.75	1.64	0.80	1.78	28	IE2
GD350A-132G/160P-4	0.47	0.59	1.06	0.61	0.71	1.28	0.85	1.43	55	IE2
GD350A-160G/185P-4	0.59	0.71	1.36	1.22	0.97	1.87	1.00	1.84	55	IE2
GD350A-185G/200P-4	0.63	0.76	1.21	1.17	1.12	1.70	1.08	1.61	55	IE2
GD350A-200G/220P-4	0.53	0.71	1.42	0.74	0.94	1.81	1.00	1.84	55	IE2
GD350A-220G/250P-4	0.33	0.42	0.69	0.85	0.95	1.33	1.10	1.18	80	IE2
GD350A-250G/280P-4	0.38	0.59	1.22	0.65	0.92	1.67	0.93	1.74	80	IE2
GD350A-280G/315P-4	0.40	0.59	1.10	0.64	0.89	1.58	1.12	1.35	80	IE2
GD350A-315G/355P-4	0.56	0.35	0.79	0.94	0.94	1.63	1.36	2.22	80	IE2
GD350A-355G/400P-4	0.37	0.47	0.98	0.91	1.11	1.95	1.42	2.44	80	IE2
GD350A-400G/450P-4	0.17	0.26	0.42	0.28	0.41	0.74	0.47	0.92	80	IE2
GD350A-450G/500P-4	0.31	0.54	0.98	0.46	0.62	1.02	0.67	0.85	80	IE2
GD350A-500G-4	0.32	0.55	0.98	0.45	0.61	1.02	0.66	0.83	80	IE2

Table F-2 Rated specifications

rable i -z ivaleu specilications									
	Apparent	Rated	ed Rated Max. work		Rated power	Rated			
Model	power	output	output	temperature	frequency	power			
	(kVA)	power (kW)	current (A)	(°C)	(Hz)	voltage (V)			
GD350A-1R5G/2R2P-4	2.4	1.5	3.7			Í			
GD350A-2R2G/003P-4	3.2	2.2	5						
GD350A-004G/5R5P-4	6.2	4	9.5						
GD350A-5R5G/7R5P-4	9.2	5.5	14						
GD350A-7R5G/011P-4	12.1	7.5	18.5						
GD350A-011G/015P-4	16.4	11	25						
GD350A-015G/018P-4	21.0	15	32						
GD350A-018G/022P-4	25.0	18.5	38						
GD350A-022G/030P-4	29.6	22	45						
GD350A-030G/037P-4	39.4	30	60						
GD350A-037G/045P-4	49.3	37	75						
GD350A-045G/055P-4	60.5	45	92	50°C					
GD350A-055G/075P-4	75.6	55	115	Derate by 1%	50Hz/60Hz Allowed				
GD350A-075G/090P-4	98.7	75	150	for every		00110001			
GD350A-090G/110P-4	118.4	90	180	increase of 1°C	range:	3PH 380V			
GD350A-110G/132P-4	141.5	110	215	when the	47–63Hz				
GD350A-132G/160P-4	171.1	132	260	temperature exceeds 40°C.					
GD350A-160G/185P-4	200.7	160	305	exceeds 40 C.					
GD350A-185G/200P-4	223.7	185	340						
GD350A-200G/220P-4	250.1	200	380						
GD350A-220G/250P-4	279.7	220	425						
GD350A-250G/280P-4	315.9	250	480						
GD350A-280G/315P-4	348.8	280	530						
GD350A-315G/355P-4	394.9	315	600						
GD350A-355G/400P-4	427.8	355	650						
GD350A-400G/450P-4	473.8	400	720						
GD350A-450G/500P-4	539.7	450	820						
GD350A-500G-4	566.0	500	860						

# **Appendix G Further information**

## G.1 Product and service queries

Should you have any queries about the product, contact the local INVT office. Provide the model and serial number of the product you query about. You can visit www.invt.com to find a list of INVT offices.

## G.2 Feedback on INVT VFD manuals

Your comments on our manuals are welcome. Visit www.invt.com, directly contact online service personnel or choose **Contact Us** to obtain contact information.

### G.3 Documents on the Internet

You can find manuals and other product documents in the PDF format on the Internet. Visit www.invt.com and choose **Support > Download**.



Service line: 86-755-23535967 E-mail: overseas@invt.com.cn Website: www.invt.com

The products are owned by Shenzhen INVT Electric Co., Ltd.

Two companies are commissioned to manufacture: (For product code, refer to the 2nd/3rd place of S/N on the name plate.)

Shenzhen INVT Electric Co., Ltd. (origin code: 01)
Address: INVT Guangming Technology Building, Songbai Road,
Matian, Guangming District, Shenzhen, China

INVT Power Electronics (Suzhou) Co., Ltd. (origin code: 06) Address: 1# Kunlun Mountain Road, Science&Technology Town, Gaoxin District, Suzhou, Jiangsu, China

Industrial Automation:

HMI

■PLC

■ VFD

■Elevator Intelligent Control System

■ Servo System ■ Rail Transit Traction System

DCIM

■Solar Inverter

■SVG

Energy & Power:

**■**UPS

■ New Energy Vehicle Powertrain System

■ New Energy Vehicle Charging System

■ New Energy Vehicle Motor

INVT Copyright. Information may be subject to change without notice during product improving.

202204 (V1.1)